

Manual No.'11•SCM-SM-110 updated November 25, 2011

# INVERTER MULTI-SPLIT SYSTEM RESIDENTIAL AIR CONDITIONERS

(Split system, air to air heat pump type)

# (OUTDOOR UNIT)

| SCM40ZJ-S      | SCM71ZJ-S1 |
|----------------|------------|
| 45 <b>ZJ-S</b> | 80ZJ-S1    |
| 50ZJ-S1        | 100ZJ-S1   |
| 60ZJ-S1        | 125ZJ-S1   |

# (INDOOR UNIT)

Wall mounted type SRK20ZJX-S 25ZJX-S 35ZJX-S 50ZJX-S1 60ZJX-S1 SRK25ZJR-S 35ZJR-S SRK20ZJ-S 25ZJ-S 35ZJ-S 50ZJ-S SRK71ZK-S

Floor standing type SRF25ZJX-S 35ZJX-S 50ZJX-S1 Ceiling concealed type SRR25ZJ-S 35ZJ-S 50ZJ-S 60ZJ-S

Ceiling cassette-4way compact type FDTC25VD 35VD 50VD 60VD

Ceiling suspended type FDEN50VD

Duct connected Low/Middle static pressure type FDUM50VF

# CONTENTS

|        | TLINE OF OPERATION CONTROL BY MICROCOMPUTER                            | 5  |
|--------|--|----|
| 1.1 \$ | SRK,SRF and SRR series   | 5  |
| (1)    | Operation control function by remote controller                        | 5  |
| (2)    | Unit ON/OFF button   | 9  |
| (3)    | Auto restart function  |    |
| (4)    | Custom cord switching procedure  |    |
| (5)    | Selection of the annual cooling function                               | 11 |
| (6)    | High power operation   | 11 |
| (7)    | Econo operation  | 12 |
| (8)    | Flap and louver control (SRK and SRF series only)                      | 12 |
| (9)    | Air outlet selection (SRF series only)                                 | 15 |
| (10)   | 3D auto operation (SRK series only)                                    | 15 |
| (11)   | Timer operation  | 16 |
| (12)   | Installation location setting (SRK series only)                        | 17 |
| (13)   | Determining the operating mode   | 17 |
| (14)   | Drain motor (DM) control (SRR series only)                             | 18 |
| 1.2 I  | FDTC, FDEN and FDUM series   | 19 |
| (1)    | Remote controller (Optional parts)                                     | 19 |
| (2)    | Operation control function by the wired remote controller              | 22 |
| (3)    | Operation control function by the indoor controller                    | 23 |
| 1.3 (  | Outline of heating operation   | 34 |
| (1)    | Summary  | 34 |
| (2)    | Operation of major functional components in heating mode               | 34 |
| (3)    | Hot keep operation   | 34 |
| (4)    | Defrosting operation   | 35 |
| 1.4 (  | Outline of cooling operation   | 36 |
| (1)    | Summary  | 36 |
| (2)    | Operation of major functional components in cooling mode               | 36 |
| 1.5 (  | Outline of automatic operation   | 37 |
| (1)    | Determination of operation mode  | 37 |
| 1.6 (  | Operation permission/prohibition control                               | 38 |
| (1)    | The operation mode is switched over between Permission and Prohibition |    |
|        | by releasing the jumper wire (J3) on the indoor PCB                    | 38 |
| (2)    | In the case of CnT input ON (Operation permission)                     | 38 |
| (3)    | In the case of CnT input OFF (Operation prohibition)                   | 38 |

| 1.7   | External control (remote display) /control of input signal             | 39 |
|-------|--|----|
| (1)   | External control (remote display) output                               | 39 |
| (2)   | Control of input signal  | 39 |
| 1.8   | Protective control function  |    |
| (1)   | Frost prevention control   | 40 |
| (2)   | Cooling overload protective control                                    |    |
| (3)   | Cooling high pressure control  | 40 |
| (4)   | Cooling low outdoor temperature protective control                     | 41 |
| (5)   | Heating high pressure control  | 42 |
| (6)   | Heating overload protective control                                    | 43 |
| (7)   | Heating low outdoor temperature protective control                     | 43 |
| (8)   | Freezing cycle system protective control                               | 44 |
| (9)   | Crankcase heater   |    |
| (10)  | Inching prevention   | 44 |
| (11)  | Compressor overheat protection   | 44 |
| (12)  | Current safe   |    |
| (13)  |  |    |
| (14)  | Outdoor unit failure   |    |
| (15)  | Indoor fan motor protection  |    |
| (16)  |  |    |
| (17)  | Regulation of outdoor air flow   | 46 |
| (18)  | Serial signal transmission error protection                            | 47 |
| (19)  | Rotor lock   | 47 |
| (20)  | Outdoor fan motor protection   |    |
| (21)  | Outdoor fan control at low outdoor temperature                         | 47 |
| (22)  | Outdoor unit fan control at overload                                   | 48 |
| (23)  | Anomalous power transistor   |    |
| (24)  |  |    |
| (25)  | Control of the flowing noise of refrigerant during cooling operation   | 49 |
| 2. MA | AINTENANCE DATA  |    |
| 2.1   | SRK,SRF and SRR series   |    |
| (1)   | Cautions   |    |
| (2)   | Items to check before troubleshooting                                  |    |
| (3)   | Troubleshooting procedure (If the air conditioner does not run at all) |    |
| (4)   | Troubleshooting procedure (If the air conditioner runs)                |    |
| (5)   | Self-diagnosis table   |    |
| (6)   | Service mode (Trouble mode access function)                            |    |
| (7)   | Inspection procedures corresponding to detail of trouble               | 64 |


| (           | (8)  | Phenomenon observed after shortcircuit, wire breakage on sensor | 68  |
|-------------|------|---|-----|
| (           | (9)  | Checking the indoor electrical equipment                        |     |
| (1          | 0)   | How to make sure of wireless remote controller                  | 70  |
| ``          | 1)   | Outdoor unit inspection points                                  |     |
| 2.2         | 2 F  | DTC, FDEN and FDUM series                                       |     |
| 2.          | .2.1 | Diagnosing of microcomputer circuit                             | 77  |
| (           | (1)  | Selfdiagnosis function  |     |
| (           | (2)  | Troubleshooting procedure                                       |     |
| (           | (3)  | Troubleshooting at the indoor unit                              | 81  |
| (           | (4)  | Check of anomalous operation deta with the remote controller    | 88  |
| (           | (5)  | Inverter checker for diagnosis of inverter output               | 89  |
| (           | (6)  | Outdoor unit inspection points                                  | 89  |
| 2.          | .2.2 | Troubleshooting flow  | 90  |
| (           | (1)  | List of troubles  |     |
| ```         | . ,  | Troubleshooting   |     |
| 3. I        |      | CTRICAL WIRINGS   |     |
| 3.′         |      | Dutdoor units   |     |
| 3.2         |      | ndoor units   |     |
| ```         |      | Wall mounted type (SRK)   |     |
|             | (2)  | Floor standing type (SRF)                                       |     |
| ```         | (3)  | Ceiling concealed type (SRR)                                    |     |
| ```         | (4)  | Ceiling cassette-4way compact type (FDTC)                       |     |
| ``          | (5)  | Ceiling suspended type (FDEN)                                   |     |
| ```         | (6)  | Duct connected Low/Middle static pressure type (FDUM)           |     |
|             |      | ING SYSTEMS   |     |
|             |      |   |     |
| <b>5</b> .′ | 1 0  | outdoor units   |     |
| (           | (1)  | Models SCM40ZJ-S, 45ZJ-S  |     |
| ```         | (2)  | Models SCM50ZJ-S1, 60ZJ-S1                                      |     |
| ```         |      | Models SCM71ZJ-S1, 80ZJ-S1                                      |     |
| ```         | (4)  | Models SCM100ZJ-S1, 125ZJ-S1                                    |     |
| _           |      | ndoor units   |     |
|             |      | Wall mounted type (SRK)   |     |
| ```         | (2)  | Floor standing type (SRF)                                       |     |
|             | (3)  | Ceiling concealed type (SRR)                                    |     |
| ```         | (4)  | Ceiling cassette-4way compact type (FDTC)                       |     |
| ``          | (5)  | Ceiling suspended type (FDEN)                                   |     |
| `           | 6)   | Duct connected Low/Middle static pressure type (FDUM)           |     |
| ```         | (7)  | Replacement procedure of the fan unit (For FDUM model)          |     |
| 6. 1        | TABL | LE OF FUNCTIONS CONNECTED WIRED REMOTE CONTROLLERS (RC-E4, E5)  | 209 |

| 7. COMPONENT REPLACEMENT         | 211 |
|----------------------------------|-----|
| 7.1 Models SCM71ZJ-S1, 80ZJ-S1   | 211 |
| 7.2 Models SCM100ZJ-S1, 125ZJ-S1 | 223 |
| 8. CHECKING PROCEDURE            | 235 |
| 8.1 Models SCM71ZJ-S1, 80ZJ-S1   | 235 |
| 8.2 Models SCM100ZJ-S1, 125ZJ-S1 | 240 |

# Table of models

| Model  | 20  | 25 | 35 | 50 | 60 | 71 |
|--|---|----|----|----|----|----|
| Wall mounted type (SRK * * ZJX-S)                        | 0   | 0  | 0  | 0  | 0  |    |
| Wall mounted type (SRK * * ZJR-S)                        |   | 0  | 0  |    |    |    |
| Wall mounted type (SRK * * ZJ-S)                         | 0   | 0  | 0  | 0  |    |    |
| Wall mounted type (SRK * * ZK-S)                         |   |    |    |    |    | 0  |
| Floor standing type (SRF)                                |   | 0  | 0  | 0  |    |    |
| Ceiling concealed type (SRR)                             |   | 0  | 0  | 0  | 0  |    |
| Ceiling cassette-4way compact type (FDTC)                |   | 0  | 0  | 0  | 0  |    |
| Ceiling suspended type (FDEN)                            |   |    |    | 0  |    |    |
| Duct connected Low/Middle static<br>pressure type (FDUM) |   |    |    | 0  |    |    |
| Outdoor unit to be combined (SCM)                        | SCM40ZJ-S, 45ZJ-S, 50ZJ-S1, 60ZJ-S1, 71ZJ-S1, 80ZJ-S1, 100ZJ-S1, 125ZJ-S1 |    |    |    |    |    |


## How to read the model name



# **1 OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER**

### 1.1 SRK, SRF and SRR series

- (1) Operation control function by remote controller
- (a) SRK series
  - Models SRK20, 25, 35ZJX-S, 50, 60ZJX-S1, 25, 35ZJR-S, 20, 25, 35, 50ZJ-S





timer and SLEEP operation


timer, and SLEEP operation.

Notes (1) In case of SCM multi system, Allergen Clear Control function is invalid.


(2) In case of SCM multi system, if [ALLERGEN CLEAR] button is pressed by mistake, the outdoor unit stops to be [All stop indoor units] mode.











Illuminates during ECONOMY operation.

#### (2) Unit ON/OFF button

When the remote controller batteries become weak, or if the remote controller is lost or malfunctioning, this button may be used to turn the unit on and off.

#### (a) Operation


Push the button once to place the unit in the automatic mode. Push it once more to turn the unit off.

#### (b) Details of operation

The unit will go into the automatic mode in which it automatically determines, from indoor temperature (as detected by sensor), whether to go into the cooling, thermal dry or heating modes.


| Function         Indoor temperature           operation mode         setting |            | Fan speed | Flap/Louver | Timer Switch |
|--|------------|-----------|-------------|--------------|
| Cooling  | About 24°C |           |             |              |
| Thermal dry  | About 25°C | Auto Auto |             | Continuous   |
| Heating  | About 26°C |           |             |              |

Model SRK20, 25, 35ZJX-S, 50, 60ZJX-S1




Unit ON/OFF button

#### Model SRK71ZK-S




Unit ON/OFF button


Model SRF25, 35ZJX-S, 50ZJX-S1



#### Model SRK25, 35ZJR-S, 20, 25, 35, 50ZJ-S



• Model SRR25, 35, 50, 60ZJ-S



#### (3) Auto restart function

(a) Auto restart function records the operational status of the air-conditioner immediately prior to be switched off by a power cut, and then automatically resumes operations after the power has been restored.

- (b) The following settings will be cancelled:
  - **1)** Timer settings
  - 2) HIGH POWER operations


Notes (1) Auto restart function is set at on when the air-conditioner is shipped from the factory. Consult with your dealer if this function needs to be switched off.

(2) When power failure ocurrs, the timer setting is cancelled. Once power is resumed, reset the timer.

(3) If the jumper wire (J170 or JA1) "AUTO RESTART" is cut, auto restart is disabled. (See next page)

#### • Model SRK20, 25, 35ZJX-S, 50, 60ZJX-S1, 71ZK-S SRF25, 35ZJX-S, 50ZJX-S1 SRR25, 35, 50, 60ZJ-S

#### • Model SRK25, 35ZJR-S, 20, 25, 35, 50ZJ-S



#### (4) Custom cord switching procedure

If two wireless remote controller are installed in one room, in order to prevent wrong operation due to mixed signals, please modify the printed circuit board in the indoor unit's controlbox and the remote controller using the following procedure. Be sure to modify both boards. If only one board is modified, receiving (and operation) cannot be done.

Jumper wire (JA2)

#### (a) Modifying the indoor printed circuit board

Take out the printed circuit board from the control box and cut off jumper wire (J171 or JA2) using wire cutters.


After cutting of the jumper wire, take measures to prevent contact with the other the lead wires, etc.

#### • Model SRK20, 25, 35ZJX-S, 50, 60ZJX-S1, 71ZK-S SRF25, 35ZJX-S, 50ZJX-S1 SRR25, 35, 50, 60ZJ-S

• Model SRK25, 35ZJR-S, 20, 25, 35, 50ZJ-S

Jumper wire (J171)

- (b) Modifying the wireless remote controller
  - **1)** Remove the battery.
  - 2) Cut the jumper wire shown in the figure at right.






- (5) Selection of the annual cooling function
- (a) The annual cooling function can be enabled or disabled by means of the jumper wire (J172 or JA3) on the indoor unit PCB and the dip switch (SW2-4) on the interface kit (optional) PCB.

| Jumper wire<br>(J172 or JA3) | Interface kit<br>(SC-BIKN-E)<br>SW2-4 | Function |
|------------------------------|---------------------------------------|----------|
| Shorted                      | ON                                    | Enabled  |
| Shorted                      | OFF                                   | Disabled |
| Open                         | ON                                    | Disabled |
| Open                         | OFF                                   | Disabled |


Note: (1) Default states of the jumper wire (J172 or JA3) and the interface kit at the shipping from factory -On the PCB, the dip switch (SW2-4) is set to enable the annual cooling function

(2) To cancel the annual cooling setting, consult your dealer.

#### Model SRK20, 25, 35ZJX-S, 50, 60ZJX-S1, 71ZK-S SRF25, 35ZJX-S, 50ZJX-S1 SRR25, 35, 50, 60ZJ-S



#### • Model SRK25, 35ZJR-S, 20, 25, 35, 50ZJ-S



#### (b) Content of control

1) If th

2) If th unit

| ) If the outdoor air temperature sensor (Th2) detects below 5°C, the indoor unit  |   |    |
|---|---|----|
| speed is switched to 9th step. (It is not possible to change.)                    | Model   | А  |
| ) If the outdoor air temperature sensor (Th2) detects higher than A°C, the indoor | SRK20, 25, 35ZJX-S, 50, 60ZJX-S1<br>SRR25, 35, 50, 60ZJ-S | 17 |
| unit speed is changed to the normal control speed.                                | SRK71ZK-S   | 7  |
| ON OFF  | SRK25, 35ZJR-S<br>SRK20, 25, 35, 50ZJ-S                   | 10 |

#### (6) High power operation

Pressing the HIGH POWER/ECONO button intensifies the operating power and initiates powerful cooling and heating operation for 15 minutes continuously. The remote control displays and the FAN SPEED display disappears.

- (a) During the HIGH POWER operation, the room temperature is not controlled. When it causes an excessive cooling and heating, press the HI POWER/ECONO button again to cancel the HIGH POWER operation.
- (b) HIGH POWER operation is not available during the DRY and the program timer operations.
- (c) When HIGH POWER operation is set after ON TIMER operation, HIGH POWER operation will start from the set time.
- (d) When the following operation are set, HIGH POWER operation will be canceled.

5

Α Outdoor air temperature (°C)

- ① When the HI POWER/ECONO button is pressed again.
- 2 When the operation mode is changed.
- ③ When it has been 15 minutes since HIGH POWER operation has started.
- (e) Not operable while the air conditioner is OFF.
- (f) After HI POWER operation, the sound of refrigerant flowing may be heard.

### (7) Econo operation

Pressing the HI POWER/ECONO button initiate a soft operation with the power suppressed in order to avoid an excessive cooling or heating. The unit operate  $1.5^{\circ}$ C higher than the setting temperature during cooling or  $2.5^{\circ}$ C lower than that during heating. The remote control displays ECONO mark and the FAN SPEED display disappears.

- (a) It will go into ECONOMY operation at the next time the air conditioner runs in the following cases.
  - 1 When the air-conditioner is stopped by ON/OFF button during ECONOMY operation.
  - 0 When the air-conditioner is stopped in SLEEP or OFF TIMER operation during ECONOMY operation.
  - 3 When the operation is retrieved from CLEAN or ALLERGEN CLEAR operation.
- (b) When the following operation are set, ECONOMY operation will be canceled.

 $(\ensuremath{\underline{1}})$  When the HI POWER/ECONO button is pressed again.

② When the operation mode is changed DRY to FAN.

- (c) Not operable while the air-conditioner is OFF.
- (d) The setting temperature is adjusted according to the following table.

| Item                      | Cooling | Heating |
|---------------------------|---------|---------|
| Temperature<br>adjustment | ①+0.5   | ①-1.0   |
|                           | 2+1.0   | 2-2.0   |
| 5                         | 3+1.5   | 3-2.5   |

 $(\ensuremath{\underline{1}})$  at the start of operation.

② one hour after the start of operation.

3 two hours after the start of operation.


#### (8) Flap and louver control (SRK and SRF series only)

#### SRK series

Control the flap and louver by AIRFLOW  $\diamondsuit$  (UP/DOWN) and  $\diamondsuit$  (LEFT/RIGHT) button on the wireless remote controller.

(a) Flap

Each time when you press the AIRFLOW  $\clubsuit$  (UP/DOWN) button the mode changes as follows.



• Angle of Flap from Horizontal

### Model SRK20, 25, 35ZJX-S, 50, 60ZJX-S1

| Remote controller display | -7          | <b>_</b>    | Ţ           | ۲,          | $\begin{bmatrix} \mathbf{J} \\ \mathbf{J} \end{bmatrix}$ |
|---------------------------|-------------|-------------|-------------|-------------|--|
| COOL , DRY, FAN           | Approx. 5°  | Approx. 20° | Approx. 35° | Approx. 45° | Approx. 60°  |
| HEAT                      | Approx. 20° | Approx. 35° | Approx. 45° | Approx. 60° | Approx. 75°  |

Model SRK25, 35ZJR-S, 20, 25, 35, 50ZJ-S

| Remote controller<br>display | -7          | <b>_</b>    | Ţ           | $\int_{\bullet}$ | $\begin{bmatrix} 1 \\ 1 \end{bmatrix}$ |
|------------------------------|-------------|-------------|-------------|------------------|--|
| COOL , DRY, FAN              | Approx. 10° | Approx. 25° | Approx. 40° | Approx. 50°      | Approx. 60°                            |
| HEAT                         | Approx. 25° | Approx. 40° | Approx. 50° | Approx. 60°      | Approx. 70°                            |


#### Model SRK71ZK-S

| Remote controller<br>display | -5          | ٦_          | ŗ           | Ŋ           | Ŋ           |
|------------------------------|-------------|-------------|-------------|-------------|-------------|
| COOL , DRY, FAN              | Approx. 5°  | Approx. 25° | Approx. 35° | Approx. 55° | Approx. 80° |
| HEAT                         | Approx. 25° | Approx. 40° | Approx. 50° | Approx. 60° | Approx. 80° |

#### (b) Louver

#### Model SRK20, 25, 35ZJX-S, 50, 60ZJX-S1, 25, 35ZJR-S, 20, 25, 35, 50ZJ-S

Each time when you press the AIRFLOW (LEFT/RIGHT) button the mode changes as follows.



#### (d) Memory flap (Flap or Louver stopped)


When you press the AIRFLOW (UP/DOWN or LEFT/RIGHT) button once while the flap or louver is operating, it stops swinging at the position. Since this angle is memorized in the microcomputer, the flap or louver will automatically be set at this angle when the next operation is started.

#### (e) When not operating

The flap returns to the position of air flow directly below, when operation has stopped.

#### (e) Multi-directional Air Flow (up/down air scroll and left/right air scroll) [SRK71ZK-S only]

Activating both up/down air swing and left/right air swing at the same time results in a multi-directional air flow.




Thick line \_\_\_\_\_: moves quickly Thin line \_\_\_\_\_: moves slowly

#### SRF series

Control the flap by AIRFLOW  $\blacklozenge$  (UP/DOWN) button on the wireless remote controller.

#### (a) Flap

Each time when you press the AIRFLOW  $\blacklozenge$  (UP/DOWN) button the mode changes as follows.



• Angle of Flap from Horizontal

| Remote controller<br>display | ď           | Ď           | Ĩ             | ٦ <sup>°</sup> |             |
|------------------------------|-------------|-------------|---------------|----------------|-------------|
| COOL , DRY, FAN              | Approx. 60° | Approx. 50° | Approx. 38°   | Approx. 21.5°  | Approx. 12° |
| HEAT                         | Approx. 44° | Approx. 32° | Approx. 21.5° | Approx. 12°    | Approx. 5°  |

#### (b) Swing

1) Swing flap

Flap moves in upward and downward directions continuously.



#### (c) Memory flap (Flap stopped)

When you press the AIRFLOW button once while the flap is operating, it stops swinging at the position. Since this angle is memorized in the microcomputer, the flap will automatically be set at this angle when the next operation is started.


#### (d) When not operating

The flap returns to the position of air flow directly below, when operation has stopped.

#### (9) Air outlet selection (SRF series only)

- (a) AIR SELECTION button can switch between the combination of upper and lower air outlets and upper air outlet. Not operable while the air conditioner is OFF.
  - 1) Each time the AIR SELECTION button is pressed. The combination of the upper and lower air outlets and the upper air outlet can be switched.
  - When the upper air outlet is selected, AIR OUTLET SELECTION light on the unit display area will light green.

| → Upper and lower air outlets — | → Upper air outlet → |
|---------------------------------|----------------------|
| AIR OUTLET SELECTION            | AIR OUTLET SELECTION |
| light : OFF                     | light : ON           |
|                                 |                      |



#### (b) Auto air outlet selection

2)

#### 1) COOL, DRY operation

- a) In case both lower and upper outlets operation is selected in Cooling or Dry operation, both outlets will be kept for sixty minutes after the start or until indoor temperature is below the setting point. And then the air outlet will change to the upper outlet. That state will be maintained until switch is turned off.
- b) In case both outlets operation with Auto fan speed mode is selected, the upper outlet will be kept for ten minutes after the start or until indoor temperature is close to reaching the setting point. And then the air outlet will change to both outlets in order to spread comfort air to every corner.



- a) In case both lower and upper outlets operation with Auto fan speed mode is selected, the lower outlet will be kept for twenty minutes after the start or until indoor temperature is close to reaching the setting point. And then the air outlet will change to both outlets. That state will be maintained until the switch is turned off.
- b) Automatic adjustment of lower air outlet direction prevents stirring up of warm air and keeps optimum comfort at floor level.

#### (10) 3D auto operation (SRK series only)

### (Except SRK71ZK-S model)

Control the flap and louver by 3D AUTO button on the wireless remote controller.

Air flow selection and air flow direction are automatically controlled, allowing the entire indoor to efficiently conditioned.

- (a) During Cooling and Heating (Including auto cooling and heating)
  - 1) Air flow selection is determined according to indoor temperature and setting temperature.

| Operation mode | Air flow selection                |   |     |     |    |  |  |  |
|----------------|-----------------------------------|---|-----|-----|----|--|--|--|
| Operation mode | A                                 | HI  | MED | LO  |    |  |  |  |
| At cooling     | Indoor temp. – Setting temp. >5°C | Indoor temp. – Setting temp. $\leq 5^{\circ}C$  |     |     |    |  |  |  |
| At cooling     | HIGH POWER AUTO                   |   | н   | MED | TO |  |  |  |
| At booting     | Setting temp. – Indoor temp. >5°C | Setting temp. – Indoor temp. $\leq 5^{\circ}$ C |     | MED | LU |  |  |  |
| At heating     | HIGH POWER                        | AUTO  | 1   |     |    |  |  |  |

2) Air flow direction is controlled according to the indoor temperature and setting temperature.

a) When 3D auto operation starts

|        | Cooling Heating                     |  |  |  |  |
|--------|-------------------------------------|--|--|--|--|
| Flap   | Up/down Swing                       |  |  |  |  |
| Louver | Wide (fixed)         Center (fixed) |  |  |  |  |

b) When Indoor temp. – Setting temp. is ≤ 5°C during cooling and when Setting temp. – Indoor temp. is ≤ 5°C during heating, the system switches to the following air flow direction control. After the louver swings left and right symmetrically for 3 cycles, control is switched to the control in c).

|        | Cooling                    | Heating                        |  |  |  |  |
|--------|----------------------------|--------------------------------|--|--|--|--|
| Flap   | Horizontal blowing (Fixed) | Slant forwardl blowing (Fixed) |  |  |  |  |
| Louver | Left/right Swing           |                                |  |  |  |  |

c) After the flap swings for 5 cycles, control is switched to the control in d).

|        | Cooling Heating |  |  |  |  |
|--------|-----------------|--|--|--|--|
| Flap   | Up/down Swing   |  |  |  |  |
| Louver | Center (Fixed)  |  |  |  |  |

d) For 5 minutes, the following air flow direction control is carried out.

|        | Cooling                    | Heating                        |  |  |  |
|--------|----------------------------|--------------------------------|--|--|--|
| Flap   | Horizontal blowing (Fixed) | Slant forwardl blowing (Fixed) |  |  |  |
| Louver | Wide (Fixed)               |                                |  |  |  |

e) After 5 minutes have passed, the air flow direction is determined according to the indoor temperature and setting temperature.

| Operation mode | Air flow direction contorol                    |  |   |  |  |  |  |
|----------------|--|--|---|--|--|--|--|
| At cooling     | Indoor temp. – Setting temp. $\leq 2^{\circ}C$ | $2^{\circ}C < Indoor temp Setting temp. \leq 5^{\circ}C$ | Indoor temp. – Setting temp. > 5°C          |  |  |  |  |
| At cooling     | The control in d) continues.                   | Control returns to the control in b).                    | Control returns to the control in a).       |  |  |  |  |
| At booting     | Setting temp. – Indoor temp. $\leq 2^{\circ}C$ | $2^{\circ}C < Setting temp Indoor temp. \leq 5^{\circ}C$ | Setting temp. – Indoor temp. $> 5^{\circ}C$ |  |  |  |  |
| At heating     | The control in d) continues.                   | Control returns to the control in b).                    | Control returns to the control in a).       |  |  |  |  |

#### (b) During DRY Operation (including auto DRY operation)

| Air flow selection | According to DRY operation. |  |  |  |  |
|--------------------|-----------------------------|--|--|--|--|
| Flap               | Horizontal blowing (Fixed)  |  |  |  |  |
| Louver             | Wide (Fixed)                |  |  |  |  |

#### (11) Timer operation

#### (a) Comfortable timer setting (ON timer)

If the timer is set at ON when the operation select switch is set at the cooling or heating, or the cooling or heating in auto mode operation is selected, the comfortable timer starts and determines the starting time of next operation based on the initial value of 15 minutes and the relationship between the indoor temperature at the setting time (temperature of room temperature sensor) and the setting temperature.

#### (b) Sleep timer operation

Pressing the SLEEP button causes the temperature to be controlled with respect to the set temperature.

#### (c) OFF timer operation

The OFF timer can be set at a specific time (in 10-minute units) within a 24-hour period.

#### (12) Installation location setting (SRK series only)

#### (Except SRK71ZK-S model)

or more.

When the indoor unit is installed at the end of a room, control the air flow direction so that it is not toward the side walls. If you set the remote controller installation position, keep it so that the air flow is within the range shown in the following figure.

#### (a) Setting

 If the air conditioning unit is running, press the ON/OFF button to stop. The installation location setting cannot be made while the unit is running.

#### 

The installation location display illuminates.

#### 3) Setting the air-conditioning installation location.

Press the AIR FLOW (LEFT/RIGHT) button and adjust to the desired location.

Each time the AIR FLOW (LEFT/RIGHT) button is pressed, the

indicator is switched in the order of:




#### AUTO FAN SPEED ON/OFF MODE FAN SPEED ON/OFF MODE EN HPOWER EN HPOWER EN HOWER EN HOWER CLEAN \$\started AUTO SLEEP CANCEL CALLERGEN CLEAN \$\started AUTO AUTO CLEAN \$\started AUTO AUTO CLEAN \$\started AUTO AU

#### 4) Press the ON/OFF button.

The air-conditioner's installation location is set.

Press within 60 seconds of setting the installation location (while the installation location setting display illuminates).




#### (13) Determining the operating mode

#### The cooling and heating operating modes are the remote controller mode that have been previously determined.

If a mode differing from these is selected after this, the selected mode will appear in the display of the remote controller, but only the fan will operate.

| Francis | First operation |                           |           | Second operation |                           |                    | Nister              |  |
|---------|-----------------|---------------------------|-----------|------------------|---------------------------|--------------------|---------------------|--|
| Example | Selected Mode   | Remote Controller Display | Operation | Selected Mode    | Remote Controller Display | Operation          | Notes               |  |
| 1       | Cooling         | Cooling                   | Cooling   | Heating          | Heating                   | Fan <sup>(1)</sup> | Different mode is   |  |
| 2       | Heating         | Heating                   | Heating   | Cooling          | Cooling                   | Fan                | only fan operation. |  |

Note (1) If the display shows heating and the operation is fan, Hot Keep will operate. **Example of operating pattern** 



#### (14) Drain motor (DM) control (SRR series only)

(a) Drain motor (DM) is operated during the cooling or dehumidifying mode operations and simultaneously wity the compressor ON. The DM continues to operate for 5 minutes after the operation stop, anomalous stop, thermostat stop or when it was switched from the cooling and dehumidifying operations to the fan or heating operation.

| Indoor unit operation mode |                     |         |               |                    |         | ]    |  |
|----------------------------|---------------------|---------|---------------|--------------------|---------|------|--|
|                            | Stop <sup>(1)</sup> | Cooling | Dehumidifying | Fan <sup>(2)</sup> | Heating | Note | (1) Including the stop from the cooling, dehumiditying, fan  |
| Compressor ON              |                     |         | Control A     |                    |         | 1    | <ul> <li>and heating, and the anomalous stop</li> <li>(2) Including the "Fan" operation according to the minimum the of constant of a standard stan</li></ul> |
| Compressor OFF             |                     |         | Control B     |                    | -       |      | mismatch of operation modes  |

#### 1) Control A

- a) If the float switch detects any anomalous draining condition, the unit stops with the anomalous stop and the drain pump starts. After detecting the anomalous condition, the drain motor comtinues to be ON.
- b) It keeps operating while the float switch is detecting the anomalous condition.

#### 2) Control B

If the float switch detects any anomalous drain condition, the drain motor is turned ON for 5 minutes, and at 10 seconds after the drain motor OFF it checks the float switch. If it is normal, the unit is stopped under the normal mode or, if there is any anomalous condition, displayed by the flashing of display lights and the drain motor is turned ON. (The ON condition is maintained during the drain detection.)

### 1.2 FDTC, FDEN and FDUM series

#### (1) Remote controller (Optional parts)


#### (a) Wired remote controller

#### (i) Remote controller (RC-E4)

The figure below shows the remote controller with the cover opened. Note that all the items that may be displayed in the liquid crystal display area are shown in the figure for the sake of explanation

Characters displayed with dots in the liquid crystal display area are abbreviated.

The figure below shows the remote control with the cover opened.




\* All displays are described in the liguid crystal display for explanation.

#### (ii) Remote controller (RC-E5)


The figure below shows the remote controller with the cover opened. Note that all the items that may be displayed in the liquid crystal display area are shown in the figure for the sake of explanation

Characters displayed with dots in the liquid crystal display area are abbreviated.



\* All displays are described in the liguid crystal display for explanation.


#### (b) Wireless remote controller



\* All displays are described in the liquid crystal display for explanation

#### (2) Operation control function by the wired remote controller

(a) Switching sequence of the operation mode switches of remote controller



#### (b) [CPU reset]

This functions when "CHECK" and "GRILL" buttons on the remote controller are pressed simultaneously. Operation is same as that of the power supply reset.

#### (c) [Power failure compensation function]...Electric power supply failure

- This becomes effective if "Power failure compensation effective" is selected with the setting of remote controller function.
- Since it memorizes always the condition of remote controller, it starts operation according to the contents of memory no sooner than normal state is recovered after the power failure. Although the auto swing stop position and the timer mode are cancelled, the weekly timer setting is restored with the holiday setting for all weekdays.

After recovering from the power failure, it readjusts the clock and resets the holiday setting for each weekday so that the setting of weekly timer becomes effective.

• Content memorized with the power failure compensation are as follows.

Note (1) Items<sup>®</sup>, <sup>(7)</sup> and <sup>®</sup> are memorized regardless whether the power failure compensation is effective or not while the setting of silent mode is cancelled regardless whether the power failure compensation is effective or not.

① At power failure – Operating/stopped


If it had been operating under the off timer mode, sleep timer mode, the state of stop is memorized. (Although the timer mode is cancelled at the recovery from power failure, the setting of weekly timer is changed to the holiday setting for all weekdays.)


- Operation mode
- ③ Airflow volume mode
- ④ Room temperature setting
- ⑤ Louver auto swing/stop

However, the stop position (4-position) is cancelled so that it returns to Position (1).

- (b) "Remote controller function items" which have been set with the remote controller function setting ("Indoor function items" are saved in the memory of indoor unit.)
- ⑦ Upper limit value and lower limit value which have been set with the temperature setting control
- <sup>®</sup> Sleep timer and weekly timer settings (Other timer settings are not memorized.)

#### [Parts layout on remote controller PCB]






#### (3) Operation control function by the indoor controller

#### (a) Auto operation


If "Auto" mode is selected by the remote controller, the heating and the cooling are automatically switched according to the difference between outdoor air temperature and setting temperature and the difference between setting temperature and return air temperature. (When the switching of cooling mode  $\leftrightarrow$  heating mode takes place within 3 minutes, the compressor does not operate for 3 minutes by the control of 3-minute timer.) This will facilitate the cooling/heating switching operation in intermediate seasons and the adaptation to unmanned operation at stores, etc (ATM corner of bank).



Room temperature (detected with ThI-A) [deg]

Note (1) Room temperature control during auto cooling/auto heating is performed according to the room temperature setting temperature. (DIFF: ±1 deg)

(2) If the indoor heat exchanger temperature rises to 59°C or higher during heating operation, it is switched automatically to cooling operation. In addition, for 1 hour after this switching, the heating operation is not performed, regardless of the temperature shown at right.



#### (b) Operations of functional items during cooling/heating

| Operation                 | Coc              | oling             |                         | Heating          |                   |                        |  |
|---------------------------|------------------|-------------------|-------------------------|------------------|-------------------|------------------------|--|
| Functional item           | Thermostat<br>ON | Thermostat<br>OFF | Fan                     | Thermostat<br>ON | Thermostat<br>OFF | Hot start<br>(Defrost) | Dehumidify   |
| Compressor                | 0                | ×                 | ×                       | 0                | ×                 | 0                      | O/×  |
| 4-way valve               | ×                | ×                 | ×                       | 0                | 0                 | $\bigcirc$ (×)         | ×  |
| Outdoor unit fan          | 0                | ×                 | ×                       | 0                | ×                 | O(×)                   | O/×  |
| Indoor unit fan           | 0                | 0                 | 0                       | O/×              | O/×               | O/×                    | O/×  |
| Louver motor              |                  | O/×               |                         | O/×              | O/x               | O/×                    | O/×  |
| Drain pump <sup>(3)</sup> | 0                | × <sup>(2)</sup>  | $\times$ <sup>(2)</sup> |                  | $O/\times^{(2)}$  |                        | Thermostat ON: O<br>Thermostat OFF: X <sup>(2)</sup> |

Note (1)  $\bigcirc$ : Operation  $\times$ : Stop  $\bigcirc/\times$ : Turned  $\bigcirc$  ON/OFF by the control other than the room temperature control.

(2) ON during the drain motor delay control.

(3) Drain pump ON setting may be selected with the indoor unit function setting of the wired remote controller.

#### (c) Dehumidifying operation

Return air temperature thermistor [ThI-A (by the remote controller when the remote controller thermistor is enabled)] controls the indoor temperature environment simultaneously.

- Operation is started in the cooling mode. When the difference between the return air temperature and the setting temperature is 2°C or less, the indoor unit fan tap is brought down by one tap. That tap is retained for 3 minutes after changing the indoor unit fan tap.
- 2) If the return air temperature exceeds the setting temperature by 3°C during defrosting operation, the indoor unit fan tap is raised. That tap is retained for 3 minutes after changing the indoor unit fan tap.
- 3) If the thermostat OFF is established during the above control, the indoor unit fan tap at the thermostat ON is retained so far as the thermostat is turned OFF.
- 4) After stopping the cooling operation, the indoor unit continues to run at Lo for 15 seconds.

#### (d) Timer operation

1) Sleep timer

Set the duration of time from the present to the time to turn off the air-conditioner.

It can be selected from 10 steps in the range from "OFF 1 hour later" to "OFF 10 hours later". After the sleep timer setting, the remaining time is displayed with progress of time in the unit of hour.

2) OFF timer

Time to turn OFF the air-conditioner can be set in the unit of 10 minutes.

3) ON timer

Time to turn ON the air-conditioner can be set. Indoor temperature can be set simultaneously.

4) Weekly timer

Timer operation (ON timer, OFF timer) can be set up to 4 times a day for each weekday.

5) Timer operations which can be set in combination

| Item Item    | Sleep timer | OFF timer | ON timer | Weekly timer |
|--------------|-------------|-----------|----------|--------------|
| Sleep timer  |             | ×         | 0        | ×            |
| OFF timer    | ×           |           | 0        | ×            |
| ON timer     | 0           | 0         |          | ×            |
| Weekly timer | ×           | ×         | ×        |              |

Note (1)  $\bigcirc$ : Allowed  $\times$  : Not

(2) Since the ON timer, sleep timer and OFF timer are set in parallel, when the times to turn ON and OFF the airconditioner are duplicated, the setting of the OFF timer has priority.

#### (e) Remote controller display during the operation stop

1) When the operation is stopped (the power supply is turned ON), it displays preferentially the "Room temperature", "Center/ Remote", "Filter sign", "Inspection" and "Timer operation".

#### Hot start (Cold draft prevention at heating)

#### (i) Operating conditions

(f)

When either one of following conditions is met, the hot start control is performed.

- **1)** From stop to heating operation
- **2)** From cooling to heating operation
- **3)** Form heating thermostat OFF to ON
- 4) After completing the defrost control (only on units with thermostat ON)

#### (ii) Contents of operation

- 1) Indoor fan motor control at hot start
  - a) Within 7 minutes after starting heating operation, the fan mode is determined depending on the condition of thermostat (fan control with heating thermostat OFF).
    - i) Thermostat OFF
    - ① Operates according to the fan control setting at heating thermostat OFF.
    - (2) Even if it changes from thermostat OFF to ON, the fan continues to operate with the fan control at thermostat OFF till the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher.
    - ③ When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher, the fan operates with the set airflow volume.
    - ii) Thermostat ON
      - ① When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 25°C or lower, the fan is turned OFF and does not operate.
      - ② When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 25°C or higher, the fan operates with the fan control at heating thermostat OFF.
      - ③ When the heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher, the fan operates with the set airflow volume.
  - iii) If the fan control at heating thermostat OFF is set at the "Set airflow volume" (from the remote controller), the fan operates with the set airflow volume regardless of the thermostat ON/OFF.

b) Once the fan motor is changed from OFF to ON during the thermostat ON, the indoor fan motor is not turned OFF even if the heat exchanger thermistor detects lower than 25°C.

Note (1) When the defrost control signal is received, it complies with the fan control during defrosting.

- c) Once the hot start is completed, it will not restart even if the temperature on the heat exchanger thermistor drops.
- 2) During the hot start, the louver horizontal control signal is transmitted.
- **3)** When the fan motor is turned OFF for 7 minutes continuously after defrosting, the fan motor is turned ON regardless of the temperatures detected with the indoor heat exchanger thermistors (ThI-R1, R2).

#### (iii) Ending condition

- 1) If one of following conditions is met during the hot start control, this control is terminated, and the fan is operated with the set airflow volume.
  - a) Heat exchanger thermistor (ThI-R1 or R2, whichever higher) detects 35°C or higher.
  - b) It has elapsed 7 minutes after starting the hot start control.

#### (g) Hot keep

Hot keep control is performed at the start of the defrost control.


- 1) Control
  - a) When the indoor heat exchanger temperature (detected with ThI-R1 or R2) drops to 35°C or lower, the speed of indoor fan is changed to the lower tap at each setting.
  - b) During the hot keep, the louver horizontal control signal is transmitted.
- 2) Ending condition

When the indoor fan is at the lower tap at each setting, it returns to the set airflow volume as the indoor heat exchanger temperature rises to 45°C or higher.

#### (h) Thermostat operation

#### (i) Cooling


- **1)** Thermostat is operated with the room temperature control.
- 2) Thermostat is turned ON or OFF relative to the set room temperature as shown below.



**3)** Thermostat is turned ON when the room temperature is in the range of -1 < Set point < +1 at the start of cooling operation (including from heating to cooling).

#### (ii) Heating

- 1) Thermostat is operated with the room temperature control.
- 2) Thermostat is turned ON or OFF relative to the set room temperature as shown below.



**3)** Thermostat is turned ON when the room temperature is in the range of -1 < Set point < +1 at the start of cooling operation (including from cooling to heating).

#### (iii) Fan control during heating thermostat OFF

1) Following fan controls during the heating thermostat OFF can be selected with the indoor function setting of the wired remote controller.

(1) Low fan speed (Factory default), (2) Set fan speed, (3) Intermittence, (4) Fan OFF

- 2) When the "Low fan speed (Factory default)" is selected, the following taps are used for the indoor fans.
  - For AC motor : Lo tap
  - For DC motor : ULo tap
- 3) When the "Set fan speed" is selected, it is operated with the set fan speed also in the thermostat OFF condition.
- 4) If the "Intermittence" is selected, following controls are performed:
  - a) If the thermostat is turned OFF during the heating operation, the indoor unit moves to the hot control and turns OFF the indoor fan if the heat exchanger thermistors (both ThI-R1 and R2) detect 25°C or lower.
  - b) Indoor fan OFF is fixed for 5 minutes. After the 5 minutes, the indoor fan is operated at Lo (AC motor) or ULo (DC motor) for 2 minutes. In the meantime the louver is controlled at level.
  - c) After operating at Lo (AC motor) or ULo (DC motor) for 2 minutes, the indoor fan moves to the state of a) above.
  - d) If the thermostat is turned ON, it moves to the hot start control.
  - e) When the heating thermostat is turned OFF, the remote controller displays the temperature detected at the fan stop and revises the temperature later when the indoor fan changes from Lo (AC motor) or ULo (DC motor) to stop. The remote controller uses the operation data display function to display temperatures and updates values of temperature even when the indoor fan is turned OFF.
  - f) When the defrosting starts while the heating thermostat is turned OFF or the thermostat is turned OFF during defrosting, the indoor fan is turned OFF. (Hot keep or hot start control takes priority.) However, the suction temperature is updated at every 7-minute.
  - g) When the heating thermostat is turned ON or the operation is changed to another mode (including stop), this control is stopped immediately, and the operating condition is restored.
- 5) When the "Fan OFF" is selected, the fan on the indoor unit of which the thermostat has been turned OFF, is turned OFF. The same occurs also when the remote control sensor is effective.

#### (i) Filter sign

As the operation time (Total ON time of ON/OFF switch) accumulates to 180 hours (1), "FILTER CLEANING" is displayed on the remote controller. (This is displayed when the unit is in trouble and under the centralized control, regardless of ON/OFF) Note (1) Time setting for the filter sign can be made as shown below using the indoor function of wired remote controller "FILTER SIGN SET". (It is set at 1 at the shipping from factory.)

| Filter sign setting Function |  |
|------------------------------|--|
| TYPE 1                       | Setting time: 180 hrs (Factory default)            |
| TYPE 2                       | Setting time: 600 hrs                              |
| TYPE 3                       | Setting time: 1,000 hrs                            |
| TYPE 4                       | Setting time: 1,000 hrs (Unit stop) <sup>(2)</sup> |

(2) After the setting time has elapsed, the "FILTER CLEANING" is displayed and, after operating for 24 hours further (counted also during the stop), the unit stops.

#### (j) Auto swing control [Applicable model: FDTC and FDEN]

- 1) Louver control
  - a) Press the "LOUVER" button to operate the swing louver when the air conditioner is operating. "SWING = "is displayed for 3 seconds and then the swing louver moves up and down continuously.
  - b) To fix the swing louver at a position, press one time the "LOUVER" button while the swing louver is moving so that four stop positions are displayed one after another per second.
    When a desired stop position is displayed, press the "LOUVER" button again. The display stops, changes to show the "STOP 1 -----" for 5 seconds and then the swing louver stops.
  - c) Louver operation at the power on with a unit having the louver 4-position control function

The louver swings one time automatically (without operating the remote controller) at the power on.

This allows inputting the louver motor (LM) position, which is necessary for the microcomputer to recognize the louver position.

2) Automatic louver level setting during heating

At the hot start with the heating thermostat OFF, regardless whether the auto swing switch is operated or not (auto swing or louver stop), the louver takes the level position (In order to prevent the cold start). The louver position display LCD continues to show the display which has been shown before entering this control.

3) Louver-free stop control

When the louver-free stop has been selected with the indoor function of wired remote controller " $\rightarrow_{71}$ " POSITION", the louver motor stops when it receives the stop signal from the remote controller. If the auto swing signal is received from the remote controller, the auto swing will start from the position where it was before the stop.

Note (1) When the indoor function of wired remote controller " $\neq_{n}$ " POSITION" has been switched, switch also the remote control function " $\neq_{n}$ " POSITION" in the same way.

#### (k) Compressor inching prevention control

#### 1) 3-minute timer

When the compressor has been stopped by the thermostat, remote controller operation switch or anomalous condition, its restart will be inhibited for 3 minutes. However, the 3-minute timer is invalidated at the power on the electric power source for the unit.

- 2) 3-minute forced operation timer
  - Compressor will not stop for 3 minutes after the compressor ON. However, it stops immediately when the unit is stopped by means of the ON/OFF switch or by when the thermister turned OFF the change of operation mode.
  - If the thermostat is turned OFF during the forced operation control of heating compressor, the louver position (with the auto swing) is returned to the level position.

Note (1) The compressor stops when it has entered the protective control.

#### (I) Drain pump control [Applicable models:FDTC and FDUM]

- 1) This control is operated when the inverter frequency is other than 0 Hz during the cooling operation and automatic cooling and dehumidifying operations.
- 2) Drain pump ON condition continues for 5 minutes even when it enters the OFF range according to 1) above after turning the drain pump ON, and then stops. The 5-minute delay continues also in the event of anomalous stop.
- 3) The drain pump is operated with the 5-minute delay operation when the compressor is changed from ON to OFF.
- 4) Even in conditions other than the above (such as heating, fan, stop, cooling thermostat OFF), the drain pump control is performed by the drain detection.
- 5) Following settings can be made using the indoor function setting of the wired remote controller.
  - (i)  $\& \diamond$ : Drain pump is run during cooling and dry.
  - (ii) 攀合部0座: Drain pump is run during cooling, dry and heating.
  - (iii) 恭合部(D美部(D慧:Drain pump is run during cooling, dry, heating and fan.
  - (iv) ②合部D 琶: Drain pump is run during cooling, dry and fan.

#### (m) Drain motor (DM) control [Applicable model: FDTC and FDUM]

(i) Drain detection switch is turned ON or OFF with the float switch (FS) and the timer.

Drain detection switch ON



- [\*1] Drain detection switch is turned "ON" when the float switch "Open" is detected for 3 seconds continuously in the drain detectable space.
- [\*2] Drain detection switch is turned "OFF" when the float switch "Close" is detected for 10 seconds continuously.
- 1) It detects always from 30 seconds after turning the power ON.
  - a) There is no detection of anomalous draining for 10 seconds after turning the drain pump OFF.
  - b) Turning the drain detection switch "ON" causes to turn ON the drain pump forcibly.
  - c) Turning the drain detection switch "OFF" releases the forced drain pump ON condition.
- (ii) Indoor unit performs the control A or B depending on each operating condition.

|                | Indoor unit operation mode |         |               |         |         |   |
|----------------|----------------------------|---------|---------------|---------|---------|---|
|                | Stop (1)                   | Cooling | Dehumidifying | Fan (2) | Heating | Note (1) Including the stop from the cooling, dehumidif                                   |
| Compressor ON  |                            |         | Control A     |         |         | and heating, and the anomalous stop<br>(2) Including the "Fan" operation according to the |
| Compressor OFF |                            | Con     | trol B        |         |         | mismatch of operation modes   |

#### 1) Control A

- a) If the float switch detects any anomalous draining condition, the unit stops with the anomalous stop (displays E9) and the drain pump starts. After detecting the anomalous condition, the drain motor continues to be ON.
- b) It keeps operating while the float switch is detecting the anomalous condition.

#### 2) Control B

If the float switch detects any anomalous drain condition, the drain motor is turned ON for 5 minutes, and at 10 seconds after the drain motor OFF it checks the float switch. If it is normal, the unit is stopped under the normal mode or, if there is any anomalous condition, E9 is displayed and the drain motor is turned ON. (The ON condition is maintained during the drain detection.)

#### (n) Operation check/drain pump test run operation mode

- 1) If the power is turned on by the dip switch (SW7-1) on the indoor PCB when electric power source is supplied, it enters the mode of operation check/drain pump test run. It is ineffective (prohibited) to change the switch after turning power on.
- 2) When the communication with the remote controller has been established within 60 seconds after turning power on by the dip switch (SW7-1) ON, it enters the operation check mode. Unless the remote controller communication is established, it enters the drain pump test run mode.

Note (1) To select the drain pump test run mode, disconnect the remote controller connector (CNB) on the indoor PCB to shut down the remote controller communication.

3) Operation check mode


There is no communication with the outdoor unit but it allows performing operation in respective modes by operating the remote controller.

4) Drain pump test run mode

As the drain pump test run is established, the drain pump only operates and during the operation protective functions by the microcomputer of indoor unit become ineffective.

#### (o) Cooling, dehumidifying frost protection

1) To prevent frosting during cooling mode or dehumidifying mode operation, the of compressor speed is reduced if the indoor heat exchanger temperature (detected with ThI-R) drops to 1.0 °C or lower at 4 minutes after the start of compressor operation. If the indoor unit heat exchanger temperature is 1.0 °C or lower after 1 minutes, the compressor speed is reduced further. If it becomes 2.5 °C or higher, the control terminates. When the indoor heat exchanger temperature has become as show below after reducing the compressor speed, it is switched to the fan operation. For the selection of indoor fan speed, refer to item 2).



#### 2) Selection of indoor fan speed

If it enters the frost prevention control during cooling operation (excluding dehumidifying), the indoor unit fan speed is switched.

- (a) In cases of FDEN
  - i) When the indoor unit return air temperature (detected with ThI-A) is 23°C or lower, this control is invalidated and, as 2 hours elapse after starting the frost prevention control, it is terminated.
  - ii) If it is detected again within 15 minutes from the start of frost prevention control, the indoor fan speed is raised by 1 tap to increase the indoor unit fan speed. If it is detected within further 15 minutes, the indoor unit fan speed is raised by 1 tap more.
    - Note (1) Indoor unit fan speed can be increased by up to 2 taps.
  - iii) **\*\***FAN SPEED SW VALID/INVALID" of this control is selectable with the function setting of remote controller.
- b) In the case of FDTC and FDUM
  - When the indoor return air detection temperature (detected with ThI-A) is 23°C or higher and the indoor heat exchanger temperature (detected with ThI-R) detects the compressor frequency drop start temperature A°C+1°C, of indoor unit fan speed is increased by 20rpm.
  - ii) If the phenomenon of i) above is detected again after the acceleration of indoor unit fan, indoor unit fan speed is increased further by 20rpm.

Note (1) Indoor unit fan speed can be increased by up to 2 taps.


· Compressor frequency drop start temperature

| Item                                | А   |
|-------------------------------------|-----|
| Temperature - Low (Factory default) | 1.0 |
| Temperature - High                  | 2.5 |

Note (1) Frost prevention temperature setting can be selected with the indoor unit function setting of the wired remote controller.

#### (p) Heating overload protection

 If the indoor heat exchanger temperature (detected with ThI-R) at 63°C or higher is detected for 2 seconds continuously, the compressor stops. When the compressor is restarted after a 3-minute delay, if a temperature at 63°C or higher is detected for 2 seconds continuously within 60 minutes after initial detection and if this is detected 5 times consecutively, the compressor stops with the anomalous stop (E8). Anomalous stop occurs also when the indoor heat exchanger temperature at 63°C or higher is detected for 6 minutes continuously.



#### 2) Indoor unit fan speed selection

If, after second detection of heating overload protection up to fourth, the indoor fan is set at Me and Lo taps when the compressor is turned ON, the indoor fan speed is increased by 1 tap.

#### (q) Anomalous fan motor [In case of FDTC and FDUM]

- 1) After starting the fan motor, if the fan motor speed is 200rpm or less is detected for 30 seconds continuously and 4 times within 60 minutes, then fan motor stops with the anomalous stop (E16).
- 2) If the fan motor fails to reach at -50 rpm less than the required speed, it stops with the anomalous stop (E20).


#### (r) Plural unit control – Control of 16 units group by one remote controller

1) Function

One remote controller switch can control a group of multiple number of unit (Max. 16 indoor units). "Operation mode" which is set by the remote controller switch can operate or stop all units in the group one after another in the order of unit No.<sup>(1)</sup>. Thermostat and protective function of each unit function independently.

Note (1) Unit No. is set by SW2 on the indoor unit control PCB. Unit No. setting by SW2 is necessary for the indoor unit only.

SW2 : For setting of 0 - 9, A - F



(2) Unit No. may be set at random unless duplicated, it should be better to set orderly like 0, 1, 2..., F to avoid mistake.

#### 2) Display to the remote controller

- a) Center or each remote controller basis, heating preparation: the youngest unit No. among the operating units in the remote mode (or the center mode unless the remote mode is available) is displayed.
- b) Inspection display, filter sign: Any of unit that starts initially is displayed.

#### c) Confirmation of connected units

Pressing "AIR CON No." button on the remote controller displays the indoor unit address. If " $\blacktriangle$ " " $\checkmark$ " button is pressed at the next, it is displayed orderly starting from the unit of youngest No.

#### d) In case of anomaly

- i) If any anomaly occurs on a unit in a group (a protective function operates), that unit stops with the anomalous stop but any other normal units continue to run as they are.
- ii) Signal wiring procedure

Signal wiring between indoor and outdoor units should be made on each unit same as the normal wiring. For the group control, lay connect with sires wiring between rooms using terminal blocks (X, Y) of remote controller.

Connect the remote controller communication wire separately from the power supply wire or wires of other electric devices (AC220V or higher).

#### (s) High ceiling control

In the case of indoor unit installed in a higher ceiling room, the airflow volume mode control can be changed with the wired remote controller indoor unit function "FAN SPEED SET".

| Fan tap       |                | Indoor unit airflow setting         |                          |                |               |  |
|---------------|----------------|-------------------------------------|--------------------------|----------------|---------------|--|
|               |                | 86 <b>011 - 8601 - 8600 - 8</b> 000 | \$**** - \$**** - \$**** | \$200 - \$200) | Stati - Stati |  |
| FAN SPEED SET | STANDARD       | PHi - Hi - Me - Lo                  | Hi - Me - Lo             | Hi - Lo        | Hi - Me       |  |
| FAN SPEED SET | HIGH SPEED1, 2 | PHi - PHi - Hi - Me                 | PHi - Hi - Me            | PHi - Me       | PHi - Hi      |  |

Note (1) Factory default is Standard.

(2) At the hot-start and heating thermostat OFF, or other, the indoor unit fan is operated at the low speed tap of each setting.

(3) This function is not able to be set with wireless remote controls or simple remote control (RCH-E3)

#### (t) Abnormal temperature thermistor (return air/indoor heat exchanger) wire/short-circuit detection

#### 1) Broken wire detection

When the return air temperature thermistor detects  $-20^{\circ}$ C or lower or the heat exchanger temperature thermistor detect  $-40^{\circ}$ C or lower for 5 seconds continuously, the compressor stops. After a 3-minute delay, the compressor restarts but, if it is detected again within 60 minutes after the initial detection for 6 minutes continuously, stops again (the return air temperature thermistor: E7, the heat exchanger temperature thermistor: E6).


#### 2) Short-circuit detection

If the heat exchanger temperature thermistor detects 70°C or higher for 5 seconds continuously at 2 minutes and 20 seconds after the compressor ON during cooling operation, the compressor stops (E6).

#### (u) Operation permission/prohibition

#### (In case of adopting card key switches or commercially available timers)

When the indoor function setting of wired remote controller for "Operation permission/prohibition" is changed from "Invalid (Factory default)" to "Valid", following control becomes effective.



|       |           | operation<br>default) | Operation permission/prohibition mode<br>"Valid" (Local setting) |                                       |  |
|-------|-----------|-----------------------|--|---------------------------------------|--|
|       | ON        | OFF                   | ON   | OFF                                   |  |
| CnT-6 | Operation | Stop                  | Operation<br>permission*1  | Operation prohibition<br>(Unit stops) |  |

\*1 **Only the "LEVEL INPUT" is acceptable for external input**, however when the indoor function setting of "Level input (Factory default)" or "Pulse input" is selected by the function for "External input" of the wired remote controller, operation status will be changed as follows.

| In case of "Level input" setting  | In case of "Pulse input" setting |
|---|----------------------------------|
| Unit operation from the wired<br>remote controller becomes<br>available*(1) | Unit starts operation *(2)       |

- \*(1) In case that "Operation permission/prohibition mode" setting is "Valid" and "External input" setting is "Level input (Factory default)";
  - ① When card key switch is ON (CnT-6 ON: Operation permission), start/stop operation of the unit from the wired remote controller becomes available.
  - 2 When card key switch is OFF (CnT-6 OFF: Operation prohibition), the unit stops operation in conjunction with OFF signal, and start/stop operation of the unit from the wired remote controller becomes not available.
- \*(2) In case that "Operation permission/prohibition mode" setting is "Valid" and "External input" setting is "Pulse input (Local setting)";
  - ① When card key switch is ON (Operation permission), the unit starts operation in conjunction with ON signal. and also start/stop operation of the unit from the wired remote controller becomes available.
  - (2) When card key switch is OFF (Operation prohibition), the unit stops operation in conjunction with OFF signal, and start/stop operation of the unit from the wired remote controller becomes not available.
- (3) This function is invalid only at "Center mode" setting done by central controller.

#### (v) External input/output control (CnT)

T

Be sure to connect the wired remote controller to the indoor unit. Without wired remote controller remote operation by CnT is not possible to perform.

|             | 1 Optional  | ①Operation output             | (CnT-2: XR1)                  |
|-------------|---|-------------------------------|-------------------------------|
|             | 2-(XR1)+  | <sup>(2)</sup> Heating output | (CnT-3: XR2)                  |
| CnT<br>Blue | 3 (XR2) •   | ③Thermostat ON output         | (CnT-4: XR3)                  |
| 12V         | 4-(XR3)•  | ④Error output                 | (CnT-5: XR4)                  |
|             | $\overset{5}{\sim}$                                     | ⑤Remote operation input       | (CnT-6: No-voltage contactor) |
| l           | $\begin{bmatrix} -2 & -2 & -2 \\ T & XR5 \end{bmatrix}$ |                               |                               |

#### 1) Output for external control (remote display)

Following output connectors (CnT) are provided on the indoor control PCB for monitoring operation status.

- ① **Operation output:** Outputs DC12V signal for driving relay during operation
- (2) Heating output: Outputs DC12V signal for driving relay during heating operation
- **3** Thermostat ON output: Outputs DC12V signal for driving relay when compressor is operating.
- (4) Error output: Outputs DC12V signal for driving relay when anomalous condition occurs.

#### 2) Remote operation input

Remote operation input connector (CnT-6) is provided on the indoor control PCB.


However remote operation by CnT-6 is not effective, when "Center mode" is selected by center controller.

In case of plural unit (twin, triple, double twin), remote operation input to CnT-6 on the slave indoor unit is invalid.

**Only the "LEVEL INPUT" is acceptable for external input**, however when the indoor function setting of "Level input (Factory default)" or "Pulse input" is selected by the function for "External input" of the wired remote controller, operation status will be changed as follows.

#### a) In case of "Level input" setting (Factory default)

Input signal to CnT-6 is OFF $\rightarrow$ ON ..... unit ON Input signal to CnT-6 is ON $\rightarrow$ OFF ..... unit OFF Operation is not inverted.




Note: The latest operation has priority

It is available to operate/stop by remote controller or center controller


#### b) In case of "Pulse input" setting (Local setting)

It is effective only when the input signal to CnT-6 is changed OFF $\rightarrow$ ON, and at that time unit operation [ON/OFF] is inverted.



#### 3) Remote operation

a) In case of multiple units (Max. 16 indoor units group) are connected to one wired remote controller When the indoor function setting of wired remote controller for "External control set" is changed from "Individual (Factory default)" to "For all units", all units connected in one wired remote controller system can be controlled by external operation input.



|       | Individual operation   | on (Factory default)  | All units operation (Local setting)                                 |  |  |
|-------|--|---|---|--|--|
|       | ON   | OFF   | ON  | OFF  |  |
| CnT-6 | Only the unit<br>directly connected<br>to the remote<br>controller can be<br>operated. | Only the unit<br>directly connected<br>to the remote<br>controller can be<br>stopped opeartion. | All units in one<br>remote controller<br>system can be<br>operated. | All units in one<br>remote controller<br>system can be<br>stopped operation. |  |
|       | Unit (1) only  | Unit (1) only   | Units (1) – (F)   | Units ① – ④  |  |

When more than one indoor unit (Max. 16 indoor units) are connected in one wired remote controller system:

- (1) With the factory default, external input to CnT-6 is effective for only the unit (0).
- (2) When setting "For all unit" (Local setting), all units in one remote controller system can be controlled by external input to CnT-6 on the indoor unit (0).
- (3) External input to CnT-6 on the other indoor unit than the unit 0 is not effective.

#### (w) Fan control at heating startup (Applicable model: FDTC and FDUM)

#### 1) Start conditions

At the start of heating operation, if the difference of setting temperature and return air temperature is 5°C or higher after the end of hot start control, this control is performed.


- 2) Contents of control
  - a) Sampling is made at each minute and, when the indoor unit heat exchanger temperature (detected with ThI-R) is 37°C or higher, present number of revolutions of indoor unit fan speed is increased by 10min<sup>-1</sup>.
  - b) If the indoor unit heat exchanger temperature drops below 37°C at next sampling, present number of revolutions of indoor unit fan speed is reduced by 10min<sup>-1</sup>.

#### 3) End conditions

Indoor fan speed is reduced to the setting airflow volume when the compressor OFF is established and at 30 minutes after the start of heating operation.

#### (x) Room temperature detection temperature compensation during heating

With the standard specification, the compressor is turned ON/OFF with the thermostat setting temperature. When the thermostat is likely to turn OFF earlier because the unit is installed at the ceiling where warm air tends to accumulate, the setting can be changed with the wired remote controller indoor unit function " $\Re P \text{ OFFSET}$ ". The compressor and the heater are turned ON/OFF at one of the setting temperature +3, +2 or +1°C in order to improve the feeling of heating. The setting temperature, however, has the upper limit of 30°C.



#### (y) Return air temperature compensation

This is the function to compensate the deviation between the detection temperature by the return air temperature thermistor and the measured temperature after installing the unit.

It is adjustable in the unit of 0.5°C with the wired remote controller indoor unit function "RETURN AIR TEMP".
 +1.0°C, +1.5°C, +2.0°C
 -1.0°C, -1.5°C, -2.0°C

2) Compensated temperature is transmitted to the remote controller and the compressor to control them. Note (1) The detection temperature compensation is effective on the indoor unit thermistor only.

# 1.3 Outline of heating operation

### (1) Summary

#### (a) Capacity control

#### 1) Indoor unit SRK \*\* ZJX models only

| Model    | SCM40ZJ-S     | SCM45ZJ-S     | SCM50ZJ-S1   | SCM60ZJ-S1   | SCM71ZJ-S1   | SCM80ZJ-     |
|----------|---------------|---------------|--------------|--------------|--------------|--------------|
| Capacity | 1.4 - 6.9 kW  | 1.4 – 7.4 kW  | 1.4 – 7.5 kW | 1.5 – 7.8 kW | 1.5 – 9.4 kW | 1.5 – 9.8 kV |
|          |               |               |              |              |              |              |
| Model    | SCM100ZJ-S1   | SCM125ZJ-S1   | -            |              |              |              |
| Capacity | 1.5 - 13.5 kW | 1.5 - 14.0 kW | -            |              |              |              |

### 2) Indoor unit except SRK \*\* ZJX models

| Model    | SCM40ZJ-S     | SCM45ZJ-S     | SCM50ZJ-S1   | SCM60ZJ-S1   | SCM71ZJ-S1   | SCM80ZJ-S1   |
|----------|---------------|---------------|--------------|--------------|--------------|--------------|
| Capacity | 1.4 – 6.7 kW  | 1.4 – 7.2 kW  | 1.4 – 7.3 kW | 1.5 – 7.6 kW | 1.5 – 9.1 kW | 1.5 – 9.5 kW |
|          |               |               |              |              |              |              |
| Model    | SCM100ZJ-S1   | SCM125ZJ-S1   |              |              |              |              |
| Capacity | 1.5 – 13.3 kW | 1.5 – 13.8 kW | -            |              |              |              |

Capacity control is within the range shown above. If demand capacity of the indoor units exceeds the maximum capacity of

the outdoor unit, the demand capacity will be proportionally distributed.

#### (b) Outdoor compressor speed control

| Indoor compressor command total speed value | Decision speed |
|---|----------------|
| 0 rps                                       | 0 rps          |
| A rps or less                               | A rps          |
| More than A rps, but B rps or less          | A rps to B rps |
| More than B rps                             | B rps          |

• Values of A, B

| Item | SCM40ZJ-S | SCM45ZJ-S | SCM50ZJ-S1 |
|------|-----------|-----------|------------|
| Α    | 30 rps    | 30 rps    | 30 rps     |
| В    | 100 rps   | 120 rps   | 120 rps    |

| Item | Model                      | SCM60ZJ-S1 | SCM71ZJ-S1 | SCM80ZJ-S1 |  |
|------|----------------------------|------------|------------|------------|--|
| •    | Two connection             | 40 rps     |            |            |  |
| Α    | More than three connection | 30 rps     |            |            |  |
| В    | One connection             | 90 rps     |            |            |  |
| В    | More than two connection   | 120 rps    |            |            |  |

| Item | Model                     | SCM100ZJ-S1 | SCM125ZJ-S1 |  |
|------|---------------------------|-------------|-------------|--|
| •    | Three connection          | 31 rps      |             |  |
| Α    | More than fore connection | 31 rps      |             |  |
| В    | One connection            | 80 rps      |             |  |
| В    | More than two connection  | 105 rps     | 110 rps     |  |

#### (2) Operation of major functional components in heating mode

| Functional components                    | Operation | Heating  | Thermostat OFF<br>(All indoor units) | Thermostat OFF<br>(Some of indoor units)   | Fan, stop, abnormal stop<br>(Some of indoor units) | Failure<br>(Outdoor unit) |
|--|-----------|--|--------------------------------------|--|--|---------------------------|
| Comman                                   |           | Multi-operation rpm calculated based<br>on the rpm required for each indoor unit | 0<br>(All indoor units)              | 0<br>(Thermostat off units)  | 0<br>(Fan, stop, abnormal stop units)              | 0<br>(All units)          |
| Indoor Fixed According to mode switching |           | Hot Keep   | According to mode switching          |  | Hot Keep   |                           |
| unit fan                                 | Automatic | According to command speed   | Hot Keep                             | According to command speed   |  | Hot Keep                  |
| Outdoor                                  | unit fan  | According to outdoor unit speed  | OFF                                  | According to outdoor unit speed  |  | OFF                       |
| Electroni<br>expansio                    |           | According to decision speed  | According to stop mode               | According to heating stop unit control (Thermostat off units) (Fan, stop, abnormal stop units) |  | According to stop mode    |
| Compres                                  | sor       | ON   | OFF                                  | ON ON  |  | OFF                       |

#### (3) Hot keep operation

If the hot keep operation is selected during the heating operation, the indoor fan is controlled based on the temperature of the indoor unit heat exchanger (Th2) to prevent blowing of cool wind. Note (1) Refer to the FDTC, FDEN and FDUM series by 25 page.

#### (4) Defrosting operation


- (a) Starting conditions (Defrosting operation can be started only when all of the following conditions are met.)
  - After start of heating operation
     When it elapsed 40 minutes. (Accumulated compressor operation time)
  - 2) After end of defrosting operation

When it elapsed 40 minutes. (Accumulated compressor operation time)

- Outdoor heat exchanger temperature (Tho-R)
   When the temperature has been below -2°C for 3 minutes continuously.
- 4) The condition of outdoor air temperature (Tho-A) and the outdoor heat exchanger temperature (Tho-R)

| $(\text{Tho-A}) - (\text{Tho-R}) \ge 0.44 \times (\text{Tho-A}) + A$ |         |  |
|--|---------|--|
| Tho-A  | A       |  |
| —2 °C ≦ Tho-A  | 4(6.5)  |  |
| _15 °C ≦ Tho-A < _2 °C   | 6(10.0) |  |
| Tho-A < −15 °C   | 6(10.0) |  |
|  |         |  |


Note (1) Values in ( ) are for the model SCM100, 125.



5) During continuous compressor operation

In addition, when the speed command from the indoor controller of the indoor unit during heating operation has counted 0 rps 10 times or more and all conditions of 1), 2), 3) and 5) above and the outdoor air temperature is  $3^{\circ}$ C or less are satisfied (note that when the temperature for outdoor heat exchanger sensor (Tho-R) is  $-2^{\circ}$ C or less: 62 rps or more,  $-2^{\circ}$ C or less: less than 62 rps), defrost operation is started.

- (b) Ending conditions (Operation returns to the heating cycle when either one of the following is met.)
  - 1) Outdoor heat exchanger sensor (Tho-R) temperature: 20°C or higher
  - 2) Outdoor heat exchanger sensor (Tho-R) temperature: 2 min. as for 10°C (model SCM71, 80, 100, 125: 1 min. as for 18°C)
  - 3) Continued operation time of defrosting  $\rightarrow$  For more than 12 minutes and 50 seconds



X Depends on an operation condition, the time can be longer than 7 minutes.

## **1.4 Outline of cooling operation**

## (1) Summary

#### (a) Capacity control

#### 1) Indoor unit SRK \*\* ZJX models only

| Model    | SCM40ZJ-S    | SCM45ZJ-S    | SCM50ZJ-S1   | SCM60ZJ-S1   | SCM71ZJ-S1   | SCM80ZJ-S1   |
|----------|--------------|--------------|--------------|--------------|--------------|--------------|
| Capacity | 1.8 – 5.9 kW | 1.8 – 6.4 kW | 1.8 – 7.1 kW | 1.8 – 7.5 kW | 1.8 – 8.8 kW | 1.8 – 9.2 kW |
|          |              |              |              |              |              |              |
| Model    | SCM100ZJ-S1  | SCM125ZJ-S1  |              |              |              |              |
|          |              |              |              |              |              |              |

#### 2) Indoor unit except SRK \*\* ZJX models

| Model    | SCM40ZJ-S    | SCM45ZJ-S    | SCM50ZJ-S1   | SCM60ZJ-S1   | SCM71ZJ-S1   | SCM80ZJ-S1   |
|----------|--------------|--------------|--------------|--------------|--------------|--------------|
| Capacity | 1.8 – 5.8 kW | 1.8 – 6.3 kW | 1.8 – 6.9 kW | 1.8 – 7.3 kW | 1.8 – 8.3 kW | 1.8 – 8.7 kW |
|          |              |              |              |              |              |              |
| Model    | SCM10071-S1  | SCM1257 LS1  |              |              |              |              |

| Model    | SCM100ZJ-S1   | SCI0125ZJ-S1  |
|----------|---------------|---------------|
| Capacity | 1.8 – 11.8 kW | 1.8 – 13.8 kW |
|          |               |               |

Capacity control is within the range shown above. If demand capacity of the indoor units exceeds the maximum capacity of

the outdoor unit, the demand capacity will be proportionally distributed.

#### (b) Outdoor compressor speed control

| Indoor compressor command total speed value | e Decision speed |  |  |  |  |
|---|------------------|--|--|--|--|
| 0 rps                                       | 0 rps            |  |  |  |  |
| A rps or less                               | A rps            |  |  |  |  |
| More than A rps, but B rps or less          | A rps to B rps   |  |  |  |  |
| More than B rps                             | B rps            |  |  |  |  |

#### • Values of A, B

| Model | SCM40ZJ-S | SCM45ZJ-S | SCM50ZJ-S1 | SCM60ZJ-S1 | SCM71ZJ-S1 | SCM80ZJ-S1 |  |  |
|-------|-----------|-----------|------------|------------|------------|------------|--|--|
| Α     | 30 rps    | 30 rps    | 30 rps     | 20 rps     | 20 rps     | 20 rps     |  |  |
| В     | 100 rps   | 120 rps   | 120 rps    | 120 rps    | 120 rps    | 120 rps    |  |  |

| Model | SCM100ZJ-S1 | SCM125ZJ-S1 |
|-------|-------------|-------------|
| Α     | 20-40 rps   | 20-45 rps   |
| В     | 110 rps     | 110 rps     |

#### (2) Operation of major functional components in cooling mode

| Functional components | Operation | Cooling  | Thermostat OFF<br>(All indoor units) | Thermostat OFF<br>(Some of indoor units)               | Fan, stop, abnormal stop<br>(Some of indoor units) | Failure<br>(Outdoor unit) |  |  |  |  |  |  |
|-----------------------|-----------|--|--------------------------------------|--|--|---------------------------|--|--|--|--|--|--|
| Commar                |           | Multi-operation rpm calculated based<br>on the rpm required for each indoor unit |                                      | 0<br>(Thermostat off units)                            | 0<br>(Fan, stop, abnormal stop units)              | 0<br>(All units)          |  |  |  |  |  |  |
| Indoor                | Fixed     | According to mode switching  |                                      |  |  |                           |  |  |  |  |  |  |
| unit fan              | Automatic | According to command speed   | According to mode switching          | According to mode switching According to command speed |  |                           |  |  |  |  |  |  |
| Outdoor               | unit fan  | According to outdoor unit speed  | OFF                                  | According to ou  | OFF  |                           |  |  |  |  |  |  |
| Electron<br>expansio  |           | According to decision speed  | According to stop mode               | All closed<br>(Thermostat off units)                   | All closed<br>(Fan, stop, abnormal stop units)     | According to stop mode    |  |  |  |  |  |  |
| Compres               | sor       | ON   | OFF                                  | ON   | ON   | OFF                       |  |  |  |  |  |  |

Unit : °C


Unit : °C

## 1.5 Outline of automatic operation

#### (1) Determination of operation mode

#### (a) SRK20, 25, 35, 50, 60ZJX, SRF and SRR series

The unit checks the indoor air temperature and the outdoor air temperature after operating the indoor and outdoor blowers for 20 seconds, determines the operation mode and the indoor air temperature setting correction value, and then enters in the automatic operation.



- 1) The unit checks the temperature every hour after the start of operation and, if the result of check is not same as the previous operation mode, changes the operation mode.
- 2) When the unit is started again within one hour after the stop of automatic operation or when the automatic operation is selected during heating, cooling or dehumidifying operation, the unit is operated in the previous operation mode.
- 3) Setting temperature can be adjusted within the following range. There is the relationship as shown below between the signals of the wireless remote controller and the setting temperature.

|             |               |    | Signals of wireless remote control (Display) |    |    |    |    |    |    |    |    |    |    |    |
|-------------|---------------|----|--|----|----|----|----|----|----|----|----|----|----|----|
|             |               |    | -5   | -4 | -3 | -2 | -1 | ±0 | +1 | +2 | +3 | +4 | +5 | +6 |
| Setting     | Cooling       | 18 | 19   | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
| temperature | Dehumidifying | 18 | 19   | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
|             | Heating       | 20 | 21   | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |


#### SRK, SRR series

|             |               | Signals of wireless remote control (Display) |    |    |    |    |    |    |    |    |    |    |    |    |
|-------------|---------------|--|----|----|----|----|----|----|----|----|----|----|----|----|
|             |               | -6   | -5 | -4 | -3 | -2 | -1 | ±0 | +1 | +2 | +3 | +4 | +5 | +6 |
| Setting     | Cooling       | 18   | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
| temperature | Dehumidifying | 19   | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 28 | 30 | 31 |
| -           | Heating       | 20   | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |

4) When the unit is operated automatically with the wired remote controller connected, the cooling operation is controlled according to the display temperatures while the setting temperature is compensated by +1°C during dehumidifying or by +2°C during heating.

#### (b) SRK25, 35ZJR-S, 20, 25, 35, 50ZJ-S, 71ZK-S series

The unit checks the indoor air temperature and setting temperature and the outdoor air temperature, determines the operation mode, and then begins in the automatic operation.



- 1) The unit checks the temperature every hour after the start of operation and, if the result of check is not same as the previous operation mode, changes the operation mode.
  - a) If the setting temperature is changed with the remote controller, the operation mode is judged immediately.
  - b) When both the indoor and the outdoor air temperatures are in the range "A", cooling or heating is switched depending on the difference between the setting temperature and the indoor air temperature.
  - c) When the operation mode has been judged following the change of setting temperature with the remote controller, the hourly judgment of operation mode is cancelled.
- 2) When the unit is started again within one hour after the stop of automatic operation or when the automatic operation is selected during heating, cooling or dehumidifying operation, the unit is operated in the previous operation mode.
- 3) Setting temperature can be adjusted within the following range. There is the relationship as shown below between the signals of the wireless remote controller and the setting temperature.

| Unit : | °C |
|--------|----|
|--------|----|

|                        | Signals of wireless remote controller (Display) |    |    |    |    |    |    |    |    |    |    |    |    |    |
|------------------------|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
|                        |   | -6 | -5 | -4 | -3 | -2 | -1 | ±0 | +1 | +2 | +3 | +4 | +5 | +6 |
| Setting<br>temperature | Cooling   | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 |
|                        | Dehumidifying                                   | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 |
|                        | Heating   | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |

4) When the unit is operated automatically with the wired remote controller connected, the cooling operation is controlled according to the display temperatures while the setting temperature is compensated by +1°C during dehumidifying or by +2°C during heating.

#### (c) FDTC, FDEN and FDUM series

Refer to page 23.

## **1.6 Operation permission/prohibition control**

#### (Refer to the FDTC, FDEN and FDUM series by 31 page)

The air conditioner operation is controlled by releasing the jumper wire (J3) on the indoor PCB and inputting the external signal into the CnT.

Note (1) Please install the separately-sold Interface kit (SC-BIK-E). Remove the jumper wire (J1 or J3) from the Interface kit circuit board.

#### (1) The operation mode is switched over between Permission and Prohibition by releasing the jumper wire (J3)

#### on the indoor PCB.

| When the jumper wire (J3) is short circuited            | When the jumper wire (J3) is released                |
|---|--|
| Normal operation is enable (when shipping)              | Permission / Prohibition mode                        |
| When CnT input is set to ON, the operation starts       | When Cnt input is set to ON, the operation mode is   |
| and if the input is set to OFF, the operation stops.    | changed to permission and if input is set to OFF the |
| For the CnT and remote control inputs, the input        | operation is prohibited.                             |
| which is activated later has priority and can start and |  |
| stop the operation.                                     |  |

#### (2) In the case of CnT input ON (Operation permission)

(a) The air conditioner can be operated or stopped by the remote control signal.

(When the "CENTER" mode is set, the operation can be controlled only by the center input.)

(b) When the CnT input is changed from OFF to ON, the air conditioner operation mode is changed depending on the status of the jumper wire (J1) on the indoor control board.

| When the jumper wire (J1) is short circuited     | When the jumper wire (J1) is released                  |
|--|--|
| The signal (1) above starts the air conditioner. | When the CnT input is set to ON, the air conditioner   |
| (Shipping status)                                | starts operation. After that, the operation of the air |
|  | conditioner depends on (a) above. (Local status)       |

#### (3) In the case of CnT input OFF (Operation prohibition)

- (a) Air-conditioner is unable to control the operation/stop, ect. in accordance with signals from the remote controller signal wire.
- (b) Air-conditioner stops as it changes CnT input  $ON \rightarrow OFF$ .

## 1.7 External control (remote display) /control of input signal

## (Refer to the FDTC, FDEN and FDUM series by 31 page)

#### (1) External control (remote display) output

Following output connectors (CNT) are provided on the printed circuit board of indoor unit.

Note (1) Please install the separately-sold Interface kit (SC-BIK-E). The output connector (CNT) is located on the circuit board of the Interface kit.

- Operation output: Power to engage DC 12V relay (provided by the customer) is outputted during operation.
- Heating output: Power to engage DC 12V relay (provided by the customer) is outputted during the heating operation.
- Compressor OPERATION output: Power to engage DC 12V relay (provided by the customer) is outputted while the

compressor is operating.

• MALFUNCTION output: When any error occurs, the power to engage DC 12V relay (provided by the customer) is outputted.


#### (2) Control of input signal

Control of input signal (switch input, timer input) connectors (CNT) are provided on the printed circuit board of indoor unit. However, when the operation of air conditioner is under the Center Mode, the remote control by CnT is invalid.

#### (a) Level input

If the factory settings (Jumper wire J1 EXTERNAL INPUT on the PCB of indoor unit) are set, or "LEVEL INPUT" is selected in the wired remote control's indoor unit settings.

- 1) Input signal to CnT OFF  $\rightarrow$  ON - - Air conditioner ON
- 2) Input signal to CnT ON  $\rightarrow$  OFF - - Air conditioner OFF




Note (1) The ON with the \* mark indicates an ON operation using the remote control unit switch, etc.

#### (b) Pulse input

When Jumper wire J1 on the PCB of indoor unit is cut at the field or "PULSE INPUT" is selected in the wired remote control's indoor unit settings.

Input signal to CnT becomes valid at OFF  $\rightarrow$  ON only and the motion of air conditioner [ON/OFF] is inverted.



#### Protective control function 1.8


#### (1) Frost prevention control (During cooling or dehumidifying)

#### (a) Operating conditions

- Indoor heat exchanger temperature (Th2) is lower than 2.5°C. 1)
- 8 minutes after reaching the compressor command speed except 0 rps. 2)

#### (b) Detail of anti-frost operation

| Operation mode       | Protective control        | Reset                     |  |
|----------------------|---------------------------|---------------------------|--|
| Compressor operation | Forced outage             | Operation instruction     |  |
| Indoor fan           | Depends on operation mode | Depends on operation mode |  |



temperature (°C)

(c) **Reset conditions:** The indoor heat exchanger temperature (Th2) is 8°C or higher.


#### (2) Cooling overload protective control

(a) Operating conditions: When the outdoor air temperature (Tho-A) has become continuously for 30 seconds at 41°C or

more, or 47°C or more with the compressor running, the lower limit speed of compressor is brought up.

| Model                   | SCM40, 45ZJ-S, 50, 60, 71, 80ZJ- |              |  |  |
|-------------------------|----------------------------------|--------------|--|--|
| Outdoor air temperature | 41°C or more                     | 47°C or more |  |  |
| Lower limit speed       | 30 rps                           | 40 rps       |  |  |

. . . . . . . .



| Item                    | SCM100, 125ZJ-S1 |              |  |
|-------------------------|------------------|--------------|--|
| Outdoor air temperature | 41°C or more     | 47°C or more |  |
| Lower limit speed       | 25 rps           | 31 rps       |  |
|                         |                  |              |  |

Model

#### (b) Detail of operation

The lower limit of compressor command speed is set to 30 (25) or 40 (31) rps and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to 30 (25) or 40 (31) rps. However, when the thermo becomes OFF, the speed is reduced to 0 rps.


Note (1) Values in ( ) are for the model SCM100, 125ZJ-S1.

- (c) Reset conditions: When either of the following condition is satisfied.
  - 1) The outdoor air temperature is lower than 40°C.
  - 2) The compressor command speed is 0 rps.

#### (3) Cooling high pressure control

#### ♦Model SCM40, 45, 50, 60, 71, 80

- (a) **Purpose:** Prevents anomalous high pressure operation during cooling.
- (b) **Detector:** Outdoor heat exchanger sensor (Tho-R)
- (c) Detail of operation:



- Notes (1) When the outdoor heat exchanger temperature is in the range of 58-60°C, the compressor command speed is reduced by 8 rps at each 20 seconds.
  - (2)When the temperature is 60°C or higher, the compressor is stopped.
    - When the outdoor heat exchanger temperature is in the range of 53-58°C, if the compressor command speed is been maintained and the operation has (3)continued for more than 30 seconds at the same speed, it returns to the normal cooling operation.

#### ♦Model SCM100, 125

- 1) Start condition: When the high pressure sensor (HPS) has risen to a specified pressure while the compressor is turned on.
- Compressor command speed is controlled according to the zones of high pressure sensor as shown by the following table.


|                          |        | HPS < P2  |          | P2        | ≦ HPS < P3  | P3 ≦ HPS | P4 ≦ HPS |
|--------------------------|--------|-----------|----------|-----------|-------------|----------|----------|
| Protection control speed | d (NP) | Normal    |          | Retention |             | NP-8rps  | Orps     |
| Sampling time (s         | 5)     | Normal    |          | rmal 30   |             | 20       | Normal   |
|                          |        | Unit: MPa |          |           |             | Pa       |          |
| NP HPS                   |        | P2        | P3       |           | P4          | -        |          |
| 20 ≦ NP < 30             | 2.94   | 4 - 3.45  | 3.07 - 3 | 3.85      | 3.15 - 4.05 |          |          |
| 30 ≦ NP < 90             |        | 3.45      | 3.85     |           | 4.05        |          |          |
| 90 ≦ NP < 100            | 3.45   | 5 - 3.25  | 3.85 - 3 | 8.60      | 4.05 - 3.81 |          |          |
| 100 ≦ NP < 110           | 3.25   | 5 - 3.07  | 3.60 - 3 | 3.33      | 3.81 - 3.53 |          |          |
| 110 ≦ NP                 |        | 3.07      | 3.33     |           | 3.53        |          |          |

#### (4) Cooling low outdoor temperature protective control

(a) **Operating conditions:** When the outdoor air temperature (Tho-A) is 22°C or lower continues for 20 seconds while compressor command speed is other than 0 rps.

#### (b) Detail of operation:

- The lower limit of compressor command speed is set to B or D rps and even if the speed becomes lower than B or D rps, the speed is kept to B or D rps. However, when the thermo becomes OFF, the speed is reduced to 0 rps.
- (2) The upper limit of compressor command speed is set to A or C rps, the speed is kept to A or C rps.



• Values of  $A \sim D$ 

| Model | SCM40ZJ-S | SCM45ZJ-S | SCM50ZJ-S1 | SCM60ZJ-S1 | SCM71ZJ-S1 | SCM80ZJ-S1 |
|-------|-----------|-----------|------------|------------|------------|------------|
| А     | 75 rps    | 75 rps    | 75 rps     | 75 rps     | 75 rps     | 75 rps     |
| В     | 35 rps    | 35 rps    | 35 rps     | 30 rps     | 30 rps     | 30 rps     |
| С     | 60 rps    | 60 rps    | 60 rps     | 60 rps     | 60 rps     | 60 rps     |
| D     | 45 rps    | 45 rps    | 45 rps     | 40 rps     | 40 rps     | 40 rps     |

| Model | SCM100ZJ-S1 | SCM125ZJ-S1 |
|-------|-------------|-------------|
| Α     | 75 rps      | 75 rps      |
| В     | 20 rps      | 20 rps      |
| С     | 60 rps      | 60 rps      |
| D     | 31 rps      | 31 rps      |

- (c) Reset conditions: When the either of the following condition is satisfied
  - ① When the outdoor air temperature (Tho-R) becomes 25°C or higher.
  - (2) When the compressor command speed is 0rps.

#### (5) Heating high pressure control

#### (a) Indoor unit side

1) Start condition: When the indoor heat exchanger temperature (Th2) has become higher than the start temperature for 1 minute continuously.

#### 2) Contents of control: Compressor stop

| Item<br>Indoor<br>air temp.(Th1) | Release temperature | Start temperature |
|----------------------------------|---------------------|-------------------|
| Th1 ≦ 24°C                       | 48.5°C              | 62°C              |
| 24°C < Th1≦27°C                  | 47.5°C (–)          | 61°C              |
| 27°C < Th1                       | 46.5°C (-)          | 60°C              |

Note (1) Values in ( ) are for the model SRK71ZK-S.

3) Release condition: When the indoor heat exchanger temperature (Th2) has become lower than the release tempera-

ture.

#### (b) Outdoor unit side

#### ♦Model SCM40, 45, 50, 60, 71, 80

- 1) Start condition: When the indoor heat exchanger temperature (Th2) has risen to a specified temperature while the compressor is turned on.
- 2) Compressor command speed is controlled according to the zones of indoor heat exchanger temperature as shown by the following table.

|                               | Th2 < P1 | P1 ≦ Th2 < P2 | P2 ≦ Th2 < P3 | P3 ≦ Th2 |
|-------------------------------|----------|---------------|---------------|----------|
| Protection control speed (NP) | Normal   | Retention     | NP-4rps       | NP-8rps  |
| Sampling time (s)             | Normal   | 20            | 20            | 20       |

#### • Model SCM40, 45, 50

| • Model SCM40, 45, 50 Unit: °C |         |         |           |  |  |
|--------------------------------|---------|---------|-----------|--|--|
| NP Th2                         | P1      | P2      | P3        |  |  |
| 10 ≦ NP < 115                  | 45      | 52      | 57.5      |  |  |
| 115 ≦ NP < 120                 | 45 - 43 | 52 - 50 | 57.5 - 55 |  |  |
| 120 ≦ NP                       | 43      | 50      | 55        |  |  |

| • Model SCM60, 71, 80 Unit: °C |           |             |         |  |  |  |
|--------------------------------|-----------|-------------|---------|--|--|--|
| NP Th2                         | P1        | P2          | P3      |  |  |  |
| 10 ≦ NP < 90                   | 45        | 52          | 57      |  |  |  |
| 90 ≦ NP < 100                  | 45 - 44.5 | 52-49.5     | 57 - 54 |  |  |  |
| 100 ≦ NP < 110                 | 44.5 – 44 | 49.5 - 47.5 | 54 - 51 |  |  |  |
| 110 ≦ NP < 120                 | 44 - 43   | 47.5 – 45   | 51 - 48 |  |  |  |
| 120 ≦ NP                       | 43        | 45          | 48      |  |  |  |

#### ♦Model SCM100, 125

- 1) Start condition: When the high pressure sensor (HPS) has risen to a specified pressure while the compressor is turned on.
- 2) Compressor command speed is controlled according to the zones of high pressure sensor as shown by the following table.

|                               | HPS < P1 | P1 ≦ HPS < P2 | P2 ≦ HPS < P3 | P3 ≦ HPS < P4 | P4 ≦ HPS |  |
|-------------------------------|----------|---------------|---------------|---------------|----------|--|
| Protection control speed (NP) | Normal   | Retention     | NP-3rps       | NP-6rps       | Orps     |  |
| Sampling time (s)             | Normal   | 20            | 20            | 20            | Normal   |  |

|                |             |             |             | Unit: MPa   |
|----------------|-------------|-------------|-------------|-------------|
| NP             | P1          | P2          | P3          | P4          |
| 20 ≦ NP < 30   | 2.81 - 2.94 | 2.94 - 3.45 | 3.07 - 3.85 | 3.15 - 4.05 |
| 30 ≦ NP < 90   | 2.94        | 3.45        | 3.85        | 4.05        |
| 90 ≦ NP < 100  | 2.94 - 2.88 | 3.45 - 3.25 | 3.85 - 3.60 | 4.05 - 3.81 |
| 100 ≦ NP < 110 | 2.88 - 2.81 | 3.25 - 3.07 | 3.60 - 3.33 | 3.81 - 3.53 |
| 110 ≦ NP       | 2.81        | 3.07        | 3.33        | 3.53        |

#### (6) Heating overload protective control

- (a) Indoor unit side
  - **1) Operating conditions :** When the outdoor air temperature (Tho-A) is 17°C or higher continues for 30 seconds while the compressor command speed other than 0 rps.
  - 2) Detail of operation : The indoor fan is stepped up by 1 speed step. [Upper limit 8th (SRK71ZK-S:10th, SRF, SRR:9th) speed]
  - **3) Reset conditions :** The outdoor air temperature (Tho-A) is lower than 16°C.

Note (1) FDTC, FDEN and FDUM serise:Refer to page 29.


#### (b) Outdoor unit side

1) Operating conditions : When the outdoor air temperature (Tho-A) is  $10^{\circ}$ C or  $17^{\circ}$ C (model 60, 71, 80:13 °C or  $17^{\circ}$ C)

or higher continues for 30 seconds while the compressor command speed other than 0 rps.

#### 2) Detail of operation

- a) Taking the upper limit of compressor command speed range at A or C, if the output speed obtained with the fuzzy calculation exceeds the upper limit, the upper limit value is maintained.
- b) The lower limit of compressor command speed is set to B or D and even if the calculated result becomes lower than that after fuzzy calculation, the speed is kept to B or D. However, when the thermo becomes OFF, the speed is reduced to 0 prs.
- c) Inching prevention control is activated and inching prevention control is carried out with the minimum speed set at B or D.
- 3) Reset conditions: The outdoor air temperature (Tho-A) is lower than 8°C (model 60, 71, 80, 100, 125:11°C).




|               |    |    |    | Unit: rps |
|---------------|----|----|----|-----------|
| Model         | А  | В  | С  | D         |
| SCM40, 45     | 90 | 35 | 75 | 40        |
| SCM50         | 90 | 35 | 75 | 40        |
| SCM60, 71, 80 | 90 | 30 | 75 | 40        |
| SCM100, 125   | 90 | 25 | 75 | 31        |

Note(1) Values in ( ) are for the model SCM40, 45.

#### (7) Heating low outdoor temperature protective control

- (a) **Operating conditions:** When the outdoor air temperature (Tho-A) is lower than 4°C or higher continues for 30 seconds while the compressor command speed is other than 0 rps.
- (b) **Detail of operation:** The lower limit compressor command speed is change as shown in the figure below.



- (c) **Reset conditions:** When either of the following condition is satisfied.
  - 1) The outdoor air temperature (Tho-A) becomes 6°C.
  - 2) The compressor command speed is 0 rps.

#### (8) Freezing cycle system protective control

- (a) Starting condition: This control starts when the following conditions are met.
  - When it has elapsed 30 minutes after the compressor was changed from OFF to ON in the cooling operation mode for more than 5 minutes.
  - 2) When the compressor command speed has met the following conditions.
  - 3) When the indoor air temperature of running indoor unit (Th1) and the indoor heat exchanger temperature (Th2) have met the following condition even on one unit.

| Unit | Compressor<br>command speed                 | Indoor air temperature<br>(Th1, ℃) | Indoor air temperature (Th1) and indoor<br>heat exchanger temperature (Th2) | Duration |
|------|---|------------------------------------|---|----------|
| 1    | 40 (60) rps                                 |                                    | Th1 - 4 < Th2   |          |
| 2    | 50 (70) rps                                 | DS                                 | 1111 - 4 < 1112   |          |
| 3    | 60 (80) rps                                 | $10 \leq \text{Th} 1 \leq 40$      | Th1 - 3 < Th2   | 5 minute |
| 4    | 70 rps                                      | $10 \equiv 1111 \equiv 40$         |   | 5 minute |
| 5    | 5         80 rps           6         90 rps |                                    | Th1 - 2 < Th2   |          |
| 6    |   |                                    |   |          |

Note (1) Values in ( ) are for the model SCM40, 45, 50.

#### (b) Contents of control

- 1) Stop the compressor and delay the start, and then restarts.
- 2) Compressor stops by the abnormal stop when the compressor stop has occurred 3 times in one hour.

#### (9) Crankcase heater

(a) Operating conditions (When all the conditions below are satisfied)

① After the operation mode is changed to stop and the compressor command speed becomes 0 rps continuously for 30 minutes.

(2) When the temperature detected by the outdoor air temperature (Tho-A) is 10°C or lower after the compressor stops.

#### (b) Detail of operation

The crankcase heater operates, warming up the compressor, then refrigerant begins circulating smoothly when the cooler starts its heating operation, and heating begins.

#### (c) Restoration conditions

When the temperature detected by the outdoor air temperature (Tho-A) reaches 12°C or higher, or the operation mode changes from stop to cooling or heating.

#### (10) Inching prevention

When the compressor becomes to the thermo operation within 5 minutes since operation start or becomes dehumidifying operation, the operation is continued with the compressor command speed of minimum rps forcibly.


#### (11) Compressor overheat protection

(a) **Purpose:** It is designed to prevent deterioration of oil, burnout of motor coil and other trouble resulting from the compressor overheat.

#### (b) Detail of operation

1) Speeds are controlled with temperature detected by the sensor (Tho-D) mounted on the discharge pipe.





- Notes (1) When the discharge pipe temperature is in the range of 105-115°C, the speed is reduced by 4 rps.
  - (2) When the discharge pipe temperature is raised and continues operation for 20 seconds without changing, then the speed is reduced again by 4 rps.
  - (3) If the discharge pipe temperature is in the range of 95-105°C even when the compressor command speed is maintained for 3 minutes when the temperature is in the range of 95-105°C, the speed is raised by 1 rps and kept at that speed for 3 minutes. This process is repeated until the command speed is reached.

(4) Lower limit speed

| Model             | Item                    | Cooling | Heating |
|-------------------|-------------------------|---------|---------|
| Lower limit speed | SCM40, 45, 50           | 32 rps  | 32 rps  |
|                   | SCM60, 71, 80, 100, 125 | 25 rps  | 32 rps  |

2) If the temperature of 115°C is detected by the sensor on the discharge pipe, then the compressor will stop immediately. When the discharge pipe temperature drops and the time delay of 3 minutes is over, the unit starts again within 1 hour but there is no start at the third time.

#### (12) Current safe

#### ♦Model SCM40, 45, 50, 60, 71, 80

- (a) **Purpose:** Current is controlled not to exceed the upper limit of the setting operation current.
- (b) Detail of operation: Input current to the converter is monitored with the current sensor fixed on the printed circuit board of the outdoor unit and, if the operation current value reaches the limiting current value, the compressor command speed is reduced.

If the mechanism is actuated when the compressor command speed is less than 30 rps, the compressor is stopped immediately. Operation starts again after a delay time of 3 minutes.

# (c) Current safe control value: Set this using the jumper wire (J1 or J2) on the outdoor PCB. Control starts when it exceeds the control value.

#### 1) Switching with jumper wire


|                  |  | Jumper wire (J2)                            |                  |  |
|------------------|--|---|------------------|--|
|                  |  | Short-circuit<br>(At shipping from factory) | Short-circuit    |  |
| lumpor wiro (11) | Short-circuit (At shipping from factory) | Current safe ①                              | Current safe (2) |  |
| Jumper wire (J1) | Open                                     | Current safe 3                              | Current safe 3   |  |

#### 2) Control value


| Cint.                    |         |            |         |         |                |         |  |  |  |  |  |
|--------------------------|---------|------------|---------|---------|----------------|---------|--|--|--|--|--|
| Model                    | Current | t safe (1) | Current | safe 2  | Current safe 3 |         |  |  |  |  |  |
|                          | Cooling | Heating    | Cooling | Heating | Cooling        | Heating |  |  |  |  |  |
| SCM40, 45ZJ-S, 50ZJ - S1 | 10.0    | 12.0       | 10.0    | 10.0    | 7.5            | 7.5     |  |  |  |  |  |
| SCM60ZJ - S1             | 11.0    | 14.0       | 10.0    | 10.0    | 7.5            | 7.5     |  |  |  |  |  |
| SCM71, 80ZJ - S1         | 13.0    | 16.0       | 10.0    | 10.0    | 7.5            | 7.5     |  |  |  |  |  |

#### ♦Model SCM100, 125

Detecting the outdoor unit inverter input (primary) current and the output (secondary) current, if the current values exceed setting values, the compressor speed (frequency) is controlled to protect the inverter.



(Fig. C) The control value "A" and the reset value vary depending on the compressor speed.



|                              | Coc                | oling            | Heating            |                  |  |
|------------------------------|--------------------|------------------|--------------------|------------------|--|
|                              | Control<br>value A | Reset value<br>B | Control<br>value A | Reset value<br>B |  |
| Primary<br>current<br>side   | 21                 | 20               | 23                 | 20               |  |
| Secandary<br>current<br>side | Fig.C              | Fig.C            | Fig.C              | Fig.C            |  |

Unit: A

#### (13) Current cut

- (a) **Purpose:** Inverter is protected from overcurrent.
- (b) **Detail of operation:** Output current from the inverter is monitored with a shunt resistor and, if the current exceeds the setting value, the compressor is stopped immediately. Operation starts again after a delay time of

3 minutes.

#### (14) Outdoor unit failure

This is a function for determining when there is trouble with the outdoor unit during air conditioning.

The compressor is stopped if any one of the following in item (a), (b) is satisfied. Once the unit is stopped by this function, it is not restarted.

- (a) When the input current is measured at 1 A or less for 3 continuous minutes or more. (Model SCM40, 45, 50, 60, 71, 80 only)
- (b) If the compressor command sends a 0 rps signal to the indoor unit 3 times or more within 20 minutes of the power being turned on.

#### (15) Indoor fan motor protection (Refer to the FDTC and FDUM series by 29 page)

When the air conditioner is operating and the indoor fan motor is turned ON, if the indoor fan motor has operated at 300 (SRF:150) rpm or under for more than 30 seconds, the unit enters first in the stop mode and then stops the entire system.

#### (16) Discharge pipe sensor disconnection protection control

- (a) When the compressor command speed is other than 0 rps.
  - 1) Tho-D(10)–Tho-D(0) < 8 °C, and Tho-D(10)–Tho-A(10) < 5 °C

The compressor command speed is set on A rps for 5 minutes. After 5 minutes, the compressor command speed is set on B rps for 5 minutes.

2) Tho-D(20)–Tho-D(15) < 5 °C :

The compressor command speed is set on 0 rps.

#### (b) Once the unit is stopped by this function, it is not restarted.

Notes (1) Tho-D(X): After compressor operation, the discharge pipe sensor temperature after X minutes.

(2) Tho-A(X): After compressor operation, the outdoor air sensor temperature after X minutes.

#### • Values of A, B

| Model | SCM40ZJ-S | SCM45ZJ-S | SCM50ZJ-S1 | SCM60ZJ-S1 | SCM71ZJ-S1 | SCM80ZJ-S1 | SCM100ZJ-S1 | SCM125ZJ-S1 |
|-------|-----------|-----------|------------|------------|------------|------------|-------------|-------------|
| Α     | 30 rps    | 30 rps    | 30 rps     | 20 rps     | 20 rps     | 20 rps     | 20 rps      | 20 rps      |
| В     | 60 rps    | 60 rps    | 60 rps     | 60 rps     | 60 rps     | 60 rps     | 60 rps      | 60 rps      |

#### (17) Regulation of outdoor air flow

(a) The fan operates as follows according to the compressor command speed. (Except during defrost.)

#### ◆Model SCM40, 45, 50, 60

|                        | Cod                       | oling                   | Heating                   |                         |  |
|------------------------|---------------------------|-------------------------|---------------------------|-------------------------|--|
|                        | Model SCM40: Less than 40 | Model SCM40: 40 or more | Model SCM40: Less than 56 | Model SCM40: 56 or more |  |
|                        | Model SCM45: Less than 40 | Model SCM45: 40 or more | Model SCM45: Less than 56 | Model SCM45: 56 or more |  |
| Compressor speed (rps) | Model SCM50: Less than 48 | Model SCM50: 48 or more | Model SCM50: Less than 61 | Model SCM50: 61 or more |  |
|                        | Model SCM60: Less than 48 | Model SCM60: 48or more  | Model SCM60: Less than 61 | Model SCM60: 61 or more |  |
| Outdoor fan speed      | 5th speed                 | 6th speed               | 5th speed                 | 6th speed               |  |

#### ♦Model SCM71, 80

|                        |              | Co                             | oling                          |            | Heating      |                                |                                |            |
|------------------------|--------------|--------------------------------|--------------------------------|------------|--------------|--------------------------------|--------------------------------|------------|
| Compressor speed (rps) | Less than 31 | More than 31<br>but 46 or less | More than 46<br>but 66 or less | 66 or more | Less than 31 | More than 31<br>but 66 or less | More than 66<br>but 85 or less | 85 or more |
| Outdoor fan speed      | 3rd speed    | 4th speed                      | 5th speed                      | 6th speed  | 3rd speed    | 4th speed                      | 5th speed                      | 6th speed  |

#### ♦Model SCM100, 125

|                        | Cooling      |           |                                |           | Heating      |           |           |                                |           |
|------------------------|--------------|-----------|--------------------------------|-----------|--------------|-----------|-----------|--------------------------------|-----------|
| Compressor speed (rps) | Less than 31 |           | More than 46<br>but 64 or less |           | Less than 31 |           |           | More than 85<br>but 96 or less |           |
| Outdoor fan speed      | 4th speed    | 5th speed | 6th speed                      | 7th speed | 4th speed    | 5th speed | 6th speed | 7th speed                      | 8th speed |

(b) If the outdoor unit's fan speed drops, the outdoor fan is run for 1 minute at that speed.

#### (18) Serial signal transmission error protection

- (a) **Purpose:** Prevents malfunction resulting from error on the indoor  $\leftrightarrow$  outdoor signals.
- (b) Detail of operation: If the compressor is operating and a serial signal cannot be received from the indoor control with

outdoor control having serial signals continues for 7 minute and 35 seconds, the compressor is stopped.

After the compressor has been stopped, it will be restarted after the compressor start delay if a serial signal can be received again from the indoor control.

#### (19) Rotor lock (Model SCM40, 45, 50, 60, 71, 80 only)

If the motor for the compressor does not turn after it has been started, it is determined that a compressor lock has occurred and the compressor is stopped.

#### (20) Outdoor fan motor protection

If the outdoor fan motor has operated at 75 rpm or under for more than 30 seconds, the compressor and fan motor are stopped.

#### (21) Outdoor fan control at low outdoor temperature

#### Cooling

#### Model SCM40, 45, 50, 60, 71, 80

- (a) **Operating conditions:** When the outdoor air temperature (Tho-A) is 22°C or lower continues for 30 seconds while the compressor command speed is other than 0 rps.
- (b) Detail of operation: After the outdoor fan operates at A speed for 60 seconds; the corresponding outdoor heat

exchanger temperature shall implement the following controls.

• Value of A

|                                | Outdoor fan |
|--------------------------------|-------------|
| Outdoor air temperature > 10°C | 2nd speed   |
| Outdoor air temperature ≦ 10°C | 1st speed   |

1) Outdoor heat exchanger temperature (Tho-R)  $\leq 22^{\circ}$ C

After the outdoor fan speed drops (down) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is lower than 22°C, gradually reduce the outdoor fan speed by 1 speed.

• lower limit speed

|                                | Lower limit speed |
|--------------------------------|-------------------|
| Outdoor air temperature > 16°C | 2nd speed         |
| Outdoor air temperature ≦ 16°C | 1st speed         |

2)  $22^{\circ}C < Outdoor heat exchanger temperature (Tho-R) \leq 40^{\circ}C$ After the outdoor for speed pointsing at A speed for 20 seconds, if the outdoor heat each

After the outdoor fan speed maintains at A speed for 20 seconds; if the outdoor heat exchanger temperature is 22°C~ 40°C, maintain outdoor fan speed.

3) Outdoor heat exchanger tempeature (Tho-R) > 40°C After the outdoor fan speed rises (up) to 1 speed for 60 seconds; if the outdoor heat exchanger temperature is higher than 40°C, gradually increase outdoor fan speed by 1 speed. (Upper limit 4th (model 71,80:3rd) speed)

#### (c) Reset conditions: When either of the following conditions is satisfied

- 1) The outdoor air temperature (Tho-A) is 24°C or higher.
- 2) The compressor command speed is 0 rps.

Model SCM100, 125

(a) **Operating conditions:** When the outdoor air temperature (Tho-A) is 22°C or lower continues for 30 seconds while the

compressor command speed is other than 0 rps.

(b) **Detail of operation:** After the outdoor fan operates at A speed for 60 seconds; the corresponding outdoor heat

exchanger temperature shall implement the following controls.

| <ul> <li>Value of A</li> </ul> |
|--------------------------------|
|--------------------------------|

|                                | Outdoor fan |
|--------------------------------|-------------|
| Outdoor air temperature > 10°C | 3rd speed   |
| Outdoor air temperature ≦ 10°C | 1st speed   |

1) High pressure sensor (HPS)  $\leq 1.50$  MPa

After the outdoor fan speed drops (down) to 1 speed for 60 seconds; if the high pressure sensor is lower than 1.50 MPa, gradually reduce the outdoor fan speed by 1 speed.

| • lower limit speed            |                   |  |  |  |  |
|--------------------------------|-------------------|--|--|--|--|
|                                | Lower limit speed |  |  |  |  |
| Outdoor air temperature > 16°C | 3rd speed         |  |  |  |  |
| Outdoor air temperature ≦ 16°C | 1st speed         |  |  |  |  |

2) 1.50MPa < High pressure sensor (HPS)  $\leq 2.72$ MPa

After the outdoor fan speed maintains at A speed for 20 seconds; if the high pressure sensor 1.50MPa  $\sim 2.72$ MPa, maintain outdoor fan speed.


- High pressure sensor (HPS) > 2.72MPa
   After the outdoor fan speed rises (up) to 1 speed for 60 seconds; if the high pressure sensor is higher than 2.72MPa, gradually increase outdoor fan speed by 1 speed. (Upper limit 4th speed)
- (c) Reset conditions: When either of the following conditions is satisfied
  - 1) The high pressure sensor (HPS) is 2.72MPa or higher.
  - 2) The compressor command speed is 0 rps.

#### Heating

- (a) **Operating conditions:** When the outdoor air temperature (Tho-A) is 3°C or lower continues for 30 seconds while the compressor command speed is other than 0 rps.
- (b) Detail of operation: The outdoor fan is stepped up by 1 speed. [Upper limit 7th (SCM100, 125:8th) speed]
- (c) Reset conditions: When either of the following conditions is satisfied
  - 1) The outdoor air temperature (Tho-A) is 5°C or higher.
  - 2) The compressor command speed is 0 rps.


#### (22) Outdoor unit fan control at overload

- Cooling
- (a) Start condition: When the outdoor air temperature (Tho-A) has risen higher than 41°C for 30 seconds continuously while the compressor is operating.



#### Outdoor air temperature(°C)

- (b) Contents of control: The outdoor unit fan tap is brought up by 3 steps (Higher limit is 6th tap.)
- (c) Release condition: When the compressor is turned off or the outdoor heat exchanger temperature (Tho-R) has dropped lower than 40°C.
- Heating
- (a) Start condition: When the outdoor air temperature (Tho-A) has risen higher than 13°C for 30 seconds continuously while the compressor is operating.



#### Outdoor heat exchanger temperature(°C)

- (b) Contents of control: The outdoor unit fan tap is brought down by 3 steps (Lower limit is 2nd tap.)
- (c) Release condition: When the compressor is turned off or the outdoor heat exchanger temperature (Tho-R) has dropped lower than 10°C.

#### (23) Anomalous power transistor (SCM100, 125 only)

When anomalous rise of the power transistor temperture is detected for 15 minutes continuosly.

#### (24) Power transistor overheat protection (SCM100, 125 only)

(a) Purpose: Prevention of malfunction, deterioration, breakage, etc. of the control

#### (b) Contents of restriction

Restricts the speed of compressor when the temperature of power transistor (Tho-AF) rises higher than 90°C.

|                               | Tho-AF < 80°C | 80°C ≦ Tho-AF < 90°C | 90°C ≦ Tho-AF < 110°C | 90°C ≦ Tho-AF < 110°C | Tho-AF ≦ 110°C |
|-------------------------------|---------------|----------------------|-----------------------|-----------------------|----------------|
| Protection control speed (NP) | Normal        | Retention            | NP-2rps               | NP-4rps               | Orps           |
| Sampling time (s)             | Normal        | 20                   | 20                    | 20                    | -              |

#### (c) Resetting condition

When the power transistor temperature is lower than 90°C or when the compressor has stopped.

#### (d) Anomalous stop

It stops anomalously if it occurs 2 times within 60 minutes or it has elapsed 60 minutes after the first establishment of the condition.

#### (25) Control of the flowing noise of refrigerant during cooling operation (SCM100, 125 only)

In order to suppress the flowing noise of refrigerant when operating 1 unit of indoor unit, the compressor is operated at the Max speed of 40 rps if the dip switch (J31) on the outdoor sub-PCB is set to open.

## **2 MAINTENANCE DATA**

## 2.1 SRK, SRF and SRR series

### (1) Cautions

- (a) If you are disassembling and checking an air conditioner, be sure to turn off the power before beginning. When working on indoor units, let the unit sit for about 1 minute after turning off the power before you begin work. When working on an outdoor unit, there may be an electrical charge applied to the main circuit (electrolytic condenser), so begin work only after discharging this electrical charge (to DC 10 V or lower).
- (b) When taking out printed circuit boards, be sure to do so without exerting force on the circuit boards or package components.
- (c) When disconnecting and connectors, take hold of the connector housing and do not pull on the lead wires.

#### (2) Items to check before troubleshooting


- (a) Have you thoroughly investigated the details of the trouble which the customer is complaining about?
- (b) Is the air conditioner running? Is it displaying any self-diagnosis information?
- (c) Is a power supply with the correct voltage connected?
- (d) Are the control lines connecting the indoor and outdoor units wired correctly and connected securely?
- (e) Is the outdoor unit's service valve open?

#### (3) Troubleshooting procedure (If the air conditioner does not run at all)


If the air conditioner does not run at all, diagnose the trouble using the following troubleshooting procedure. If the air conditioner is running but breaks down, proceed to troubleshooting step (4).

**Important** When all the following conditions are met, we say that the air conditioner will not run at all.

- (a) The RUN light does not light up.
- (b) The flaps do not open.
- (c) The indoor unit fan motors do not run.
- (d) The self-diagnosis display does not function.



#### (4) Troubleshooting procedure (If the air conditioner runs)



Note (1) Even in cases where only intermittent stop data are generated, the air conditioning system is normal. However, if the same protective operation recurs repeatedly (3 or more times), it will lead to customer complaints. Judge the conditions in comparison with the contents of the complaints.

#### (5) Self-diagnosis table

When this air conditioner performs an emergency stop, the reason why the emergency stop occurred is displayed by the flashing of display lights. If the air conditioner is operated using the remote controller 3 minutes or more after the emergency stop, the trouble display stops and the air conditioner resumes operation.  $^{\left( l\right) }$ 

| .,                            |                                 | 0. triacar                     | Wired <sup>(2)</sup>            |  |  |  |
|-------------------------------|---------------------------------|--------------------------------|---------------------------------|--|--|--|
| Indoor unit o<br>RUN<br>light | lisplay panel<br>TIMER<br>light | Outdoor<br>main PCB<br>Red LED | remote<br>controller<br>display | Description<br>of trouble                              | Cause  | Display (flashing) condition   |
| 1 time<br>flash               | ON                              | Stays<br>OFF                   | _                               | Heat exchanger<br>sensor 1 error                       | <ul> <li>Broken heat exchanger sensor<br/>1 wire, poor connector<br/>connection</li> <li>Indoor PCB is faulty</li> </ul>                                 | When a heat exchanger sensor 1 wire disconnection is detected while operation is stopped. (If a temperature of $-28^\circ$ C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)                             |
| 2 times<br>flash              | ON                              | Stays<br>OFF                   | _                               | Room<br>temperature<br>sensor error                    | <ul> <li>Broken room temperature<br/>sensor wire, poor connector<br/>connection</li> <li>Indoor PCB is faulty</li> </ul>                                 | When a room temperature sensor wire disconnection is detected while operation is stopped. (If a temperature of $-45^\circ C$ or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)                             |
| 3 times<br>flash              | ON                              | Stays<br>OFF                   | _                               | Heat exchanger<br>sensor 2 error                       | <ul> <li>Broken heat exchanger sensor<br/>2 wire, poor connector<br/>connection</li> <li>Indoor PCB is faulty</li> </ul>                                 | When a heat exchanger sensor 2 wire disconnection is detected while operation is stopped. (If a temperature of $-28^\circ$ C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)                             |
| 4 times<br>flash              | ON                              | Stays<br>OFF                   | E 9                             | Drain <sup>(3)</sup><br>trouble                        | <ul> <li>Defective drain pump (DM),<br/>broken drain pump wire</li> <li>Anomalous float switch operation</li> <li>Defective indoor PCB faulty</li> </ul> | If the float switch OPEN is defected for 3 seconds continuously or if float switch connector or wire is disconnected.  |
| 6 times<br>flash              | ON                              | Stays<br>OFF                   | E 16                            | Indoor fan<br>motor error                              | Defective fan motor, poor connector connection   | When conditions for turning the indoor unit's fan motor on exist during air conditioner operation, an indoor unit fan motor speed of $300 (SRF : 150)$ rpm or lower is measured for 30 seconds or longer. (The air conditioner stops.)                                       |
| Keeps<br>flashing             | 1 time<br>flash                 | 8 times<br>flash               | E 38                            | Outdoor air<br>temperature<br>sensor error             | <ul> <li>Broken outdoor air temp.<br/>sensor wire, poor connector<br/>connection</li> <li>Outdoor main PCB is faulty</li> </ul>                          | -55°C or lower is detected for 5 seconds continuously 3 times within<br>40 minutes after initial detection of this anomalous temperature.<br>Or -55°C or higher is detected for within 20 seconds after power ON.<br>(The compressor is stopped.)                            |
| Keeps<br>flashing             | 2 times<br>flash                | 8 times<br>flash               | E 37                            | Outdoor heat<br>exchanger<br>sensor error              | <ul> <li>Broken heat exchanger sensor<br/>wire, poor connector<br/>connection</li> <li>Outdoor main PCB is faulty</li> </ul>                             | -55°C or lower is detected for 5 seconds continuously 3 times within<br>40 minutes after initial detection of this anomalous temperature.<br>Or -55°C or higher is detected for within 20 seconds after power ON.<br>(The compressor is stopped.)                            |
| Keeps<br>flashing             | 4 times<br>flash                | 8 times<br>flash               | E 39                            | Discharge pipe<br>sensor error                         | <ul> <li>Broken discharge pipe sensor<br/>wire, poor connector<br/>connection</li> <li>Outdoor main PCB is faulty</li> </ul>                             | $-25^{\rm o}{\rm C}$ or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)   |
| Keeps<br>flashing             | 5 times<br>flash                | 8 times<br>flash               | E 53                            | Outdoor suction<br>pipe sensor error                   | <ul> <li>Broken suction pipe sensor wire,<br/>poor connector connection</li> <li>Outdoor sub PCB is faulty</li> </ul>                                    | -55°C or lower is detected for 5 seconds continuously 3 times within 40<br>minutes after initial detection of this anomalous temperature.<br>Or -55°C or higher is detected for within 20 seconds after power ON.<br>(The compressor is stopped)                             |
| ON                            | 1 time<br>flash                 | 1 time<br>flash                | E 42                            | Current cut  | <ul> <li>Compressor locking, open phase<br/>on compressor output, short<br/>circuit on power transistor,<br/>service valve is closed</li> </ul>          | The compressor output current exceeds the set value during compressor start. (The air conditioner stops.)  |
| ON                            | 2 times<br>flash                | 2 times<br>flash               | E 59                            | Trouble of outdoor unit                                | Broken compressor wire     Compressor blockage   | When there is an emergency stop caused by trouble in the outdoor unit,<br>or the input current value is found to be lower than the set value.<br>(The air conditioner stops.)  |
| ON                            | 3 times<br>flash                | 3 times<br>flash               | E 58                            | Current safe<br>stop                                   | Overload operation     Overcharge     Compressor locking   | When the compressor command speed is lower than the set value and the current safe has operated. (the compressor stops)  |
| ON                            | 4 times<br>flash                | 1 time<br>flash                | E 51                            | Power<br>transistor<br>error                           | Broken power transistor  | When the power transistor is judged breakdown while compressor<br>starts.<br>(The compressor is stopped.)  |
| ON                            | 5 times<br>flash                | 5 times<br>flash               | E 36                            | Over heat of compressor                                | Gas shortage, defective<br>discharge pipe sensor, service<br>valve is closed   | When the value of the discharge pipe sensor exceeds the set value. (The air conditioner stops.)  |
| ON                            | 6 times<br>flash                | 6 times<br>flash               | E 5                             | Error of signal transmission                           | • Defective power supply,<br>Broken signal wire, defective<br>indoor/outdoor sub PCB   | When there is no signal between the indoor PCB and outdoor PCB for<br>10 seconds or longer (when the power is turned on), or when there is no<br>signal for 7 minute 35 seconds or longer (during operation)(the<br>compressor is stopped).                                  |
| ON                            | 7 times<br>flash                | Keeps<br>flashing              | E 48                            | Outdoor fan<br>motor error                             | Defective fan motor, poor connector connection   | When the outdoor unit's fan motor speed continues for 30 seconds or longer at 75 rpm or lower. (3 times) (The air conditioner stops.)  |
| ON                            | Keeps<br>flashing               | 2 times<br>flash               | E 35                            | Cooling high<br>pressure<br>protection                 | <ul> <li>Overload operation, overcharge</li> <li>Broken outdoor heat exchange<br/>sensor wire</li> <li>Service valve is closed</li> </ul>                | When the value of the outdoor heat exchanger sensor exceeds the set value.   |
| 2 times<br>flash              | 2 times<br>flash                | 7 times<br>flash               | E 60                            | Rotor lock   | <ul> <li>Defective compressor</li> <li>Open phase on compressor</li> <li>Defective outdoor PCB</li> </ul>  | If the compressor motor's magnetic pole positions cannot be correctly detected when the compressor starts. (The air conditioner stops.)  |
| 5 times<br>flash              | ON                              | 2 times<br>flash               | E 47                            | Active filter<br>voltage error                         | Defective active filter  | When the wrong voltage connected for the power supply.<br>When the outdoor main PCB is faulty  |
| 7 times<br>flash              | ON                              | 2 times<br>flash               | E 57                            | Refrigeration<br>cycle system<br>protective<br>control | <ul><li>Service valve is closed.</li><li>Refrigerant is insufficient</li></ul>   | When refrigeration cycle system protective control operates.   |
| -                             | _                               | 4 times<br>flash               | E 45                            | Outdoor sub PCB<br>communication<br>error              | <ul> <li>Outdoor sub PCB fauly</li> <li>Poor connection of wire between<br/>outdoor sub PCB – main PCB</li> </ul>  | Communication error for 15 minutes: Detected more than 15 seconds 4 times  |
| _                             | _                               | Stays<br>OFF                   | E 1                             | Error of wired<br>remote controller<br>wiring          | Broken wired remote controller<br>wire, defective indoor PCB   | The wired remote controller wire Y is open. The wired remote<br>controller wires X and Y are reversely connected. Noise is penetrating<br>the wired remote controller lines. The wired remote controller or indoor<br>PCB is faulty. (The communications circuit is faulty.) |
| Stays<br>OFF                  | Keeps<br>flashing               | _                              | _                               | Limit switch<br>error                                  | <ul><li>Defective limit switch</li><li>Defective suction pancl set</li><li>Defective indoor control PCB</li></ul>  | Actuation of limit switch  |

## (i) SCM40, 45, 50, 60, 71, 80

Notes (1)The air conditioner cannot be restarted using the remote controller for 3 minutes after operation stops.

(1) The wired remote controller is optional parts.(3)SRR series only.

## (ii) SCM100,125

| RUN                      | lisplay panel     | Outdoor<br>main PCB<br>Red LED | Wired (2)<br>remote<br>controller | Description<br>of trouble                              | Cause   | Display (flashing) condition  |
|--------------------------|-------------------|--------------------------------|-----------------------------------|--|---|---|
| light<br>1 time<br>flash | light<br>ON       | Stays<br>OFF                   | display<br>—                      | Heat exchanger<br>sensor 1 error                       | Broken heat exchanger sensor<br>wire, poor connector<br>connection  | When a heat exchanger sensor 1 wire disconnection is detected while<br>operation is stopped. (If a temperature of -28°C or lower is detected for<br>15 seconds, it is judged that the wire is disconnected.)  |
| 2 times<br>flash         | ON                | Stays<br>OFF                   | _                                 | Room<br>temperature<br>sensor error                    | Indoor PCB is faulty     Broken room temperature sensor wire, poor connector connection   | (Not displayed during operation.)<br>When a room temperature sensor wire disconnection is detected while<br>operation is stopped. (If a temperature of -45°C or lower is detected fo<br>15 seconds, it is judged that the wire is disconnected.)<br>(Not displayed during operation.) |
| 3 times<br>flash         | ON                | Stays<br>OFF                   | _                                 | Heat exchanger<br>sensor 2 error                       | Indoor PCB is faulty     Broken heat exchanger sensor     wire, poor connector     connection     Indoor PCB is faulty                                  | When a heat exchange sensor 2 wire disconnection is detected while<br>operation is stopped. (If a temperature of -28°C or lower is detected fo<br>15 seconds, it is judged that the wire is disconnected.)<br>(Not displayed during operation.)                                       |
| 4 times<br>flash         | ON                | Stays<br>OFF                   | E 9                               | Drain <sup>(3)</sup><br>trouble                        | <ul> <li>Defective drain pump (DM),<br/>broken drain pump wire</li> <li>Anomalousfloat s witchoperation</li> <li>Defective indoor PCB faulty</li> </ul> | If the float switch OPEN is defected for 3 seconds continuously or if float switch connector or wire is disconnected.   |
| 6 times<br>flash         | ON                | Stays<br>OFF                   | E 16                              | Indoor fan<br>motor error                              | Defective fan motor, poor<br>connector connection   | When conditions for turning the indoor unit's fan motor on exist during air<br>conditioner operation, an indoor unit fan motor speed of 300 (SRF : 150) rpn<br>or lower is measured for30 seconds or longer. (The air conditioner stops.)   |
| Keeps<br>flashing        | 1 time<br>flash   | 8 times<br>flash               | E 38                              | Outdoor air<br>temperature<br>sensor error             | <ul> <li>Broken outdoor air temp.<br/>sensor wire, poor connector<br/>connection</li> <li>Outdoor main PCB is faulty</li> </ul>                         | -55℃ or lower is detected for 5 seconds continuously 3 times within<br>40 minutes after initial detection of this anomalous temperature.<br>Or -55℃ or higher is detected for within 20 seconds after power ON.<br>(The compressor is stopped.)                                       |
| Keeps<br>flashing        | 2 times<br>flash  | 8 times<br>flash               | E 37                              | Outdoor heat<br>exchanger<br>sensor error              | <ul> <li>Broken heat exchanger sensor<br/>wire, poor connector<br/>connection</li> <li>Outdoor main PCB is faulty</li> </ul>                            | -55°C or lower is detected for 5 seconds continuously 3 times within<br>40 minutes after initial detection of this anomalous temperature.<br>Or -55°C or higher is detected for within 20 seconds after power ON.<br>(The compressor is stopped.)                                     |
| Keeps<br>flashing        | 4 times<br>flash  | 8 times<br>flash               | E 39                              | Discharge pipe<br>sensor error                         | <ul> <li>Broken discharge pipe sensor<br/>wire, poor connector<br/>connection</li> <li>Outdoor main PCB is faulty</li> </ul>                            | -25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)   |
| Keeps<br>flashing        | 5 times<br>flash  | 8 times<br>flash               | E 53                              | Outdoor suction<br>pipe sensor error                   | <ul> <li>Broken suction pipe sensor wire,<br/>poor connector connection</li> <li>Outdoor sub PCB is faulty</li> </ul>                                   | -55℃ or lower is detected for 5 seconds continuously 3 times within 4 minutes after initial detection of this anomalous temperature. Or -55℃ or higher is detected for within 20 seconds after power ON. (The compressor is stopped)  |
| ON                       | 1 time<br>flash   | 1 time<br>flash                | E 42                              | Current cut  | <ul> <li>Compressor locking, open phase<br/>on compressor output, short<br/>circuit on power transistor,<br/>service valve is closed</li> </ul>         | The compressor output current exceeds the set value during compressor start. (The air conditioner stops.)   |
| ON                       | 2 times<br>flash  | 2 times<br>flash               | E 59                              | Trouble of<br>outdoor unit                             | Broken compressor wire     Compressor blockage  | When there is an emergency stop caused by trouble in the outdoor unit,<br>or the input current value is found to be lower than the set value.<br>(The air conditioner stops.)   |
| ON                       | 4 times<br>flash  | 1 time<br>flash                | E 51                              | Inverter and<br>fan motor<br>anomaly                   | <ul> <li>Outdoor inverter PCB is faulty</li> <li>Outdoor controol PCB is faulty</li> <li>Outdoor fan motor is faulty</li> </ul>                         | When power transistor anomaly is detected for 15 minutes continuosly (The compressor is stopped.)   |
| ON                       | 5 times<br>flash  | 5 times<br>flash               | E 36                              | Over heat of compressor                                | Gas shortage, defective<br>discharge pipe sensor, service<br>valve is closed  | When the value of the discharge pipe sensor exceeds the set value. (The air conditioner stops.)   |
| ON                       | 6 times<br>flash  | 6 times<br>flash               | E 5                               | Error of signal transmission                           | • Defective power supply,<br>Broken signal wire, defective<br>indoor/outdoor sub PCB  | When there is no signal between the indoor PCB and outdoor PCB for<br>10 seconds or longer (when the power is turned on), or when there is no<br>signal for 7 minute 35 seconds or longer (during operation)(the<br>compressor is stopped).   |
| ON                       | 7 times<br>flash  | Keeps<br>flashing              | E 48                              | Outdoor fan<br>motor error                             | Defective fan motor, poor<br>connector connection   | When the outdoor unit's fan motor speed continues for 30 seconds or longer at 75 rpm or lower. (3 times) (The air conditioner stops.)   |
| ON                       | Keeps<br>flashing | 2 times<br>flash               | E 35                              | Cooling high<br>pressure<br>protection                 | Overload operation, overcharge     Broken high pressure sensor     wire     Service valve is closed   | When anomalous rise of the high pressure sensor is detected 5 times<br>within 1 hour.<br>When high pressure sensor anomaly is detected for 10 minutes<br>continuously.  |
| 7 times<br>flash         | ON                | 2 times<br>flash               | E 57                              | Refrigeration<br>cycle system<br>protective<br>control | <ul><li>Service valve is closed.</li><li>Refrigerant is insufficient</li></ul>  | When refrigeration cycle system protective control operates.  |
| _                        | —                 | 1 time<br>flash                | E 41                              | Power transistor<br>error                              | Power transistor overheat   | When anomalous rise of the power transistor temperature is detected 2 times within 1 hour.  |
| _                        | _                 | 2 times<br>flash               | E 40                              | Heating high<br>pressure<br>protection                 | <ul> <li>Overload operation, overcharge</li> <li>Broken high pressure sensor<br/>wire</li> <li>Service valve is closed</li> </ul>                       | When anomalous rise of the high pressure sensor is detected 5 times<br>within 1 hour.<br>When high pressure sensor anomaly is detected for 10 minutes<br>continuously.  |
| _                        | _                 | 4 times<br>flash               | E 45                              | Outdoor sub PCB<br>communication<br>error              | <ul> <li>Outdoor sub PCB fauly</li> <li>Poor connection of wire between<br/>outdoor sub PCB – main PCB</li> </ul>                                       | Communication error for 15 minutes: Detected more than 15 seconds 4 times.  |
| _                        | _                 | 8 times<br>flash               | E 54                              | High pressure<br>sensor error                          | Broken high pressure sensor<br>wire   | If the detected for 5 second continuously within 2 minutes to 2 minute<br>and 20 seconds after the compressor ON, the compressor stops.   |
| -                        | _                 | Stays<br>OFF                   | E 1                               | Error of wired<br>remote controller<br>wiring          | Broken wired remote controller<br>wire, defective indoor PCB  | The wired remote controller wire Y is open. The wired remote<br>controller wires X and Y are reversely connected. Noise is penetrating<br>the wired remote controller lines. The wired remote controller or indoo<br>PCB is faulty. (The communications circuit is faulty.)           |
| Stays<br>OFF             | Keeps<br>flashing | _                              | _                                 | Limit switch<br>error                                  | <ul> <li>Defective limit switch</li> <li>Defective suction panel set</li> <li>Defective indoor control PCB</li> </ul>                                   | Actuation limit switch  |
|                          |                   |                                |                                   |  |   |   |

 Notes (1) The air conditioner cannot be restarted using the remote controller for 3 minutes after operation stops.

 (2) The wired remote controller is optional parts.

 (3) SRR series only.


#### (6) Service mode (Trouble mode access function)

This air conditioner is capable of recording error displays and protective stops (service data) which have occurred in the past. If self-diagnosis displays cannot be confirmed, it is possible to get a grasp of the conditions at the time trouble occurred by checking these service data.


| Term                | Explanation   |  |  |  |
|---------------------|---|--|--|--|
| Service mode        | The service mode is the mode where service data are displayed by flashing of the display lights when the operations in item (b) below are performed with the indoor controller.   |  |  |  |
| Service data        | These are the contents of error displays and protective stops which occurred in the past in the air conditioner system. Error display contents and protective stop data from past anomalous operations of the air conditioner system are saved in the indoor unit controller's non-volatile memory (memory which is not erased when the power goes off). There are two types of data, self-diagnosis data and stop data, described below.   |  |  |  |
| Self-diagnosis data | These are the data which display the reason why a stop occurred when an error display(self-<br>diagnosis display) occurred in an indoor unit. Data are recorded for up to 5 previous occurrences.<br>Data which are older than the 5th previous occurrence are erased.<br>In addition, data on the temperature of each sensor (room temperature, indoor heat exchanger,<br>outdoor heat exchanger, outdoor air temperature, discharge pipe), remote controller information<br>(operation switching, fan speed switching) are recorded when trouble occurs, so more detailed<br>information can be checked.  |  |  |  |
| Stop data           | <ul> <li>These are the data which display the reason by a stop occurred when the air conditioning system performed protective stops, etc. in the past. Even if stop data alone are generated, the system restarts automatically. (After executing the stop mode while the display is normal, the system restarts automatically.) Data for up to 10 previous occasions are stored. Data older than the 10th previous occasion are erased.</li> <li>(Important) In cases where transient stop data only are generated, the air conditioner system may still be normal. However, if the same protective stop occurs frequently (3 or more times), it could lead to customer complaints.</li> </ul> |  |  |  |

#### (a) Explanation of terms

#### (b) Service mode display procedure



\*3: To count the number of flashes in the service mode, count the number of flashes after the light lights up for 1.5 second initially (start signal). (The time that the light lights up for 1.5 second (start signal) is not counted in the number of flashes.)



\*4: When in the service mode, when the remote controller settings (operation switching, fan speed switching, temperature setting) are set as shown in the following table and sent to the air conditioner unit, the unit switches to display of service data.

#### 1) Self-diagnosis data

What are Self-.......These are control data (reasons for stops, temperature at each sensor, remote controller information) diagnosis Data? from the time when there were error displays (abnormal stops) in the indoor unit in the past.

Data from up to 5 previous occasions are stored in memory. Data older than the 5th previous occasion are erased. The temperature setting indicates how many occasions previous to the present setting the error display data are and the operation switching and fan speed switching data show the type of data.

| Remote cont         | roller setting      | Contents of output data   |  |
|---------------------|---------------------|---|--|
| Operation switching | Fan speed switching | Contents of output data   |  |
|                     | MED                 | Displays the reason for stopping display in the past (error code).  |  |
| Cooling             | HI                  | Displays the room temperature sensor temperature at the time the error code was displayed in the past.        |  |
| AUTO                |                     | Displays the indoor heat exchanger sensor temperature at the time the error code was displayed in the past.   |  |
|                     | LO                  | Displays the remote controller information at the time the error code was displayed in the past.              |  |
| Heating             | MED                 | Displays the outdoor air temperature sensor temperature at the time the error code was displayed in the past. |  |
| Heating             | HI                  | Displays the outdoor heat exchanger sensor temperature at the time the error code was displayed in the past.  |  |
|                     | AUTO                | Displays the discharge pipe sensor temperature at the time the error code was displayed in the past.          |  |

| Remote controller setting | Indicates the number of<br>occasions previous to the present |  |
|---------------------------|--|--|
| Temperature setting       | the error display data are from.                             |  |
| 21°C                      | 1 time previous (previous time)                              |  |
| 22°C                      | 2 times previous   |  |
| 23°C                      | 3 times previous   |  |
| 24°C                      | 4 times previous   |  |
| 25°C                      | 5 times previous   |  |

#### Only for indoor heat exchanger sensor 2

| Remote controller setting | Indicates the number of<br>occasions previous to the present |  |
|---------------------------|--|--|
| Temperature setting       | the error display data are from.                             |  |
| 26°C                      | 1 time previous (previous time)                              |  |
| 27°C                      | 2 times previous   |  |
| 28°C                      | 3 times previous   |  |
| 29°C                      | 4 times previous   |  |
| 30°C                      | 5 times previous   |  |

## (Example)

| Remo                | te controller       | setting                |   |
|---------------------|---------------------|------------------------|---|
| Operation switching | Fan speed switching | Temperature<br>setting | Displayed data  |
|                     |                     | 21°C                   | Displays the reason for the stop (error code) the previous time an error was displayed.     |
|                     |                     | 22°C                   | Displays the reason for the stop (error code) 2 times previous when an error was displayed. |
| Cooling             | MED                 | 23°C                   | Displays the reason for the stop (error code) 3 times previous when an error was displayed. |
|                     |                     | 24°C                   | Displays the reason for the stop (error code) 4 times previous when an error was displayed. |
|                     |                     | 25°C                   | Displays the reason for the stop (error code) 5 times previous when an error was displayed. |

## 2) Stop data

| Remo                | te controller s     | etting                 |   |  |
|---------------------|---------------------|------------------------|---|--|
| Operation switching | Fan speed switching | Temperature<br>setting | Displayed data  |  |
|                     |                     | 21°C                   | Displays the reason for the stop (stop code) the previous time when the air conditioner was stopped by protective stop control. |  |
|                     |                     | 22°C                   | Displays the reason for the stop (stop code) 2 times previous when the air conditioner was stopped by protective stop control.  |  |
|                     |                     | 23°C                   | Displays the reason for the stop (stop code) 3 times previous when the air conditioner was stopped by protective stop control.  |  |
|                     |                     |                        | 24°C  | Displays the reason for the stop (stop code) 4 times previous when the air conditioner was stopped by protective stop control. |
| Cooling             | LO                  | 25°C                   | Displays the reason for the stop (stop code) 5 times previous when the air conditioner was stopped by protective stop control.  |  |
| Cooling             | LU                  | 26°C                   | Displays the reason for the stop (stop code) 6 times previous when the air conditioner was stopped by protective stop control.  |  |
|                     |                     | 27°C                   | Displays the reason for the stop (stop code) 7 times previous when the air conditioner was stopped by protective stop control.  |  |
|                     |                     | 28°C                   | Displays the reason for the stop (stop code) 8 times previous when the air conditioner was stopped by protective stop control.  |  |
|                     |                     | 29°C                   | Displays the reason for the stop (stop code) 9 times previous when the air conditioner was stopped by protective stop control.  |  |
|                     |                     | 30°C                   | Displays the reason for the stop (stop code) 10 times previous when the air conditioner was stopped by protective stop control. |  |

(c) Error code, stop code table (Assignment of error codes and stop codes is done in common for all models.)
(i) Model SCM40, 45, 50, 60, 71, 80


|  | shes when in  |                               |   |  |   |           |                 |
|--|---|-------------------------------|---|--|---|-----------|-----------------|
| service<br>RUN<br>light<br>10's digit) | TIMER<br>light  | Stop coad<br>or<br>Error coad | Error content   | Cause  | Occurrence conditions   |           | Auto<br>recover |
|  | OFF   | 0                             | Normal  | -  | —   | -         | -               |
| OFF                                    | 5 times<br>flash  | 05                            | Can not receive signals for 35<br>seconds<br>(if communications have recovered)       | Power supply is faulty.<br>Power supply cables and signal lines are improperly wired.<br>Indoor or outdoor sub PCB are faulty  | When 35 seconds passes without<br>communications signals from either the outdoor unit or<br>the indoor unit being detected correctly.   | 0         | -               |
|  | 5 times<br>flash  | 35                            | Cooling high pressure control   | Cooling overload operation.<br>Outdoor unit fan speed drops.<br>Outdoor heat exchanger sensor is short circuit.  | When the outdoor heat exchanger sensor's value exceeds the set value.   |           | 0               |
|  | 6 times<br>flash  | 36                            | Compressor overheat 115°C   | Refrigerant is insufficient.<br>Discharge pipe sensor is faulty.<br>Service valve is closed.   | When the discharge pipe sensor's value exceeds the set value.   |           | 0               |
| 3 times<br>flash                       | 7 times<br>flash     37     Outdoor heat exchanger sensor<br>is abnormal     Outdoor heat exchanger sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor main PCB is faulty     -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous<br>temperature.<br>Or-55°C ligher is detected for 5 seconds continuously<br>within 20 seconds after power ON. |                               | (3 times)   | 0  |   |           |                 |
|  | 8 times<br>flash  | 38                            | Outdoor air temperature sensor<br>is abnormal   | Outdoor air temperature sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor main PCB is faulty   | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous<br>temperature.<br>0r-55°C higher is detected for 5 seconds continuously<br>within 20 seconds after power ON.      | (3 times) | 0               |
|  | 9 times<br>flash  | 39                            | Discharge pipe sensor is<br>abnormal (anomalous stop)                                 | Discharge pipe sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor main PCB is faulty  | -25°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous<br>temperature.  | (3 times) | 0               |
| 4 times                                | 2 times<br>flash  | 42                            | Current cut   | Compressor lock.<br>Compressor wiring short circuit.<br>Compressor output is open phase.<br>Outdoor main PCB is faulty<br>Service valve is closed.<br>Electronic expansion valve is faulty.<br>Compressor is faulty. | Compressor start fails 42 times in succession and the reason for the final failure is current cut.  | (2 times) | 0               |
| flash                                  | 5 times<br>flash  | 45                            | Anomalous outdoor sub<br>PCB commuication   | Outdoor sub PCB fauly.<br>Poor connection of wire between<br>outdoor sub PCB-main PCB.   | Communication error for 15 minutes: Detected more than 15 seconds 4 times.  |           | 0               |
|  | 7 times<br>flash  | 47                            | Active filter voltage error   | Defective active filter.   | When the wrong voltage connected for the power supply.<br>When the outdoor main PCB is faulty.  |           | _               |
|  | 8 times<br>flash  | 48                            | Outdoor unit's fan motor is<br>abnormal   | Outdoor fan motor is faulty.<br>Connector connections are poor.<br>Outdoor main PCB is faulty.   | When a fan speed of 75 rpm or lower continues for 30 seconds or longer.   |           | 0               |
|  | 1 time<br>flash   | 51                            | Short circuit in the power<br>transistor (high side)<br>Current cut circuit breakdown | Outdoor main PCB is faulty<br>Power transistor is damaged.   | When it is judged that the power transistor was damaged at the time the compressor started.   |           | _               |
|  | 3 times<br>flash  | 53                            | Suction pipe sensor<br>is abnormal  | Suction pipe sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor sub PCB is faulty.  | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous<br>temperature.<br>Or-55°C higher is detected for 5 seconds continuously<br>within 20 seconds after compressor ON. | (3 times) | 0               |
| 5 times<br>flash                       | 7 times<br>flash  | 57                            | Refrigeration cycle system<br>protective control                                      | Service valve is closed.<br>Refrigerant is insufficient.   | When refrigeration cycle system protective control operates.  | (3 times) | 0               |
|  | 8 times<br>flash  | 58                            | Current safe  | Refrigerant is overcharge.<br>Compressor lock.<br>Overload operation.  | When there is a current safe stop during operation.   | _         | 0               |
|  | 9 times<br>flash  | 59                            | Compressor wiring is unconnection<br>Voltage drop                                     | Compressor wiring is disconnected.<br>Power transistor is damaged.<br>Power supply construction is defective.<br>Outdoor main PCB is faulty.<br>Compressor is faulty.  | When the current is 1A or less at the time the compressor started.<br>When the power supply voltage drops during operation.   | 0         | 0               |
|  | OFF   | 60                            | Rotor lock  | Compressor is faulty.<br>Compressor output is open phase.<br>Electronic expansion valve is faulty.<br>Overload operation.<br>Outdoor main PCB is faulty.   | After the compressor starts, when the compressor stops due to rotor lock.   | (2 times) | 0               |
| 6 times<br>flash                       | 1 time<br>flash   | 61                            | Connection lines between the indoor and outdoor units are faulty                      | Connection lines are faulty.<br>Indoor or outdoor sub PCB are faulty.  | When 10 seconds passes after the power is turned on<br>without communications signals from the indoor or<br>outdoor unit being detected correctly.  | 0         | _               |
|  | 2 times<br>flash  | 62                            | Serial transmission error   | Indoor or outdoor sub PCB are faulty.<br>Noise is causing faulty operation.  | When 7 minute 35 seconds passes without<br>communications signals from either the outdoor unit or<br>the indoor unit being detected correctly.  |           | -               |
|  | OFF   | 80                            | Indoor unit's fan motor is<br>abnormal  | Indoor fan motor is faulty.<br>Connector connections are poor.<br>Indoor PCB is faulty.  | When the indoor unit's fan motor is detected to be running<br>at 300 (SRF : 150) rpm or lower speed with the fan motor<br>in the ON condition while the air conditioner is running.   | 0         | _               |
|  | 2 times<br>flash  | 82                            | Indoor heat exchanger sensor<br>is abnormal (anomalous stop)                          | Indoor heat exchanger sensor wire is<br>disconnected.<br>Connector connections are poor  | When a temperature of -28°C or lower is sensed<br>continuously for 40 minutes during heating operation.<br>(the compressor stops).  | 0         | _               |
| 8 times<br>flash                       | 4 times<br>flash  | 84                            | Anti-condensation control   | High humidity condition.<br>Humidity sensor is faulty.   | Anti-condensation prevention control is operating.  | _         | 0               |
|  | 5 times<br>flash  | 85                            | Anti-frost control  | Indoor unit fan speed drops.<br>Indoor heat exchanger sensor is broken wire.   | When the anti-frost control operates and the compressor stops during cooling operation.   | _         | 0               |
|  | 6 times<br>flash  | 86                            | Heating high pressure control   | Heating overload operation.<br>Indoor unit fan speed drops.<br>Indoor heat exchanger sensor is short circuit.  | When high pressure control operates during heating operation and the compressor stops.  | -         | 0               |

## (ii) SCM100,125

|                             |   | Stop coad                         |   |   |   | _                | .    |
|-----------------------------|---|-----------------------------------|---|---|---|------------------|------|
| RUN<br>light<br>10's digit) | TIMER<br>light  | or<br>Error coad                  | Error content   | Cause   | Occurrence conditions   | Error<br>display | Auto |
|                             | OFF   | 0                                 | Normal  | —   | —   | -                | -    |
| OFF                         | 5 times<br>flash  | 05                                | Can not receive signals for 35<br>seconds<br>(if communications have recovered) | Power supply is faulty.<br>Power supply cables and signal lines are improperly wired.<br>Indoor or outdoor PCB are faulty.  | When 35 seconds passes without<br>communications signals from either the outdoor unit or<br>the indoor unit being detected correctly.   |                  | -    |
|                             | 5 times<br>flash  | 35                                | Cooling high pressure control   | Cooling overload operation.<br>Outdoor unit fan speed drops.<br>Outdoor high pressure sensor is short circuit.  | the set value.  |                  | 0    |
|                             | 6 times flash 36 Compressor overheat 115°C Refrigerant is insufficient. Discharge pipe sensor is faulty. Service valve is closed. When the discharge pipe sensor's value exceeds the set value. |                                   | (2 times)   | 0   |   |                  |      |
| 3 times<br>flash            |   |                                   | Or-55°C higher is detected for 5 seconds continuously                           | (3 times)   | 0   |                  |      |
|                             | 8 times<br>flash  | 38                                | Outdoor air temperature sensor<br>is abnormal                                   | Outdoor air temperature sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor control PCB is faulty.  | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous<br>temperature.<br>0r-55°C higher is detected for 5 seconds continuously<br>within 20 seconds after power ON.      | (3 times)        | 0    |
|                             | 9 times<br>flash  | 39                                | Discharge pipe sensor is abnormal (anomalous stop)                              | Discharge pipe sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor control PCB is faulty.   | -25°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after intial detection of this anomalous<br>temperature.   |                  | 0    |
|                             | OFF   | 40                                | Heating high pressure control   | Heating overload operation.<br>Outdoor unit fan speed drops.<br>Outdoor high pressure sensor is short circuit.  | When the outdoor high pressure sensor's value exceeds the set value.  |                  | 0    |
|                             | 1 time<br>flash   | 41                                | Power transistor error  | Power transistor overheat.<br>Power transistor sensor is short circuit.   | When anomalous rise of the power transistor temperature<br>is detected 2 times within 1 hour.   |                  | 0    |
| 4 times<br>flash            | 2 times<br>flash  | 4/ Outdoor inverter PCB is faulty |   |   | (2 times)   | 0                |      |
|                             | 5 times<br>flash  | 45                                | Anomalous outdoor sub<br>PCB commuication                                       | Outdoor sub PCB fauly.<br>Poor connection of wire between<br>outdoor sub PCB-control PCB.   | Communication error for 15 minutes: Detected more than 15 seconds 4 times.  |                  | 0    |
|                             | 8 times<br>flash  | 48                                | Outdoor unit's fan motor is<br>abnormal   | Outdoor fan motor is faulty.<br>Connector connections are poor.<br>Outdoor control PCB is faulty.   | When a fan speed of 75 rpm or lower continues for 30 seconds or longer.   | (3 times)        | 0    |
|                             | 1 time<br>flash   | 51                                | Inverter and fan motor anomaly  | Outdoor inverter PCB is faulty.<br>Outdoor control PCB is faulty.<br>Outdoor fan motor is faulty.   | When power transistor anomaly is detected for 15 minutes continuosly.   | 0                | _    |
|                             | 3 times<br>flash  | 53                                | Suction pipe sensor<br>is abnormal  | Suction pipe sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor control PCB is faulty.   | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous<br>temperature.<br>Or-55°C higher is detected for 5 seconds continuously<br>within 20 seconds after compressor ON. | (3 times)        | 0    |
| 5 times<br>flash            | 4 times<br>flash  | 54                                | High pressure sensor<br>is abnormal   | High pressure sensor wire is<br>disconnected.<br>Connector connections are poor.<br>Outdoor control PCB is faulty.  | within 20 seconds after compressor ON.<br>If the detected for 5 second continuously within 2 minutes<br>to 2 minutes and 20 seconds after the compressor ON, the<br>compressor stops.   |                  | 0    |
|                             | 7 times<br>flash  | 57                                | Refrigeration cycle system<br>protective control                                | Service valve is closed.<br>Refrigerant is insufficient.  | When refrigeration cycle system protective control operates.  |                  | 0    |
|                             | 9 times<br>flash  | 59                                | Compressor wiring is unconnection<br>Voltage drop                               | Compressor wiring is disconnected.<br>Power transistor is damaged.<br>Power supply construction is defective.<br>Outdoor inverter PCB is faulty.<br>Compressor is faulty. | When the current is 1A or less at the time the<br>compressor started.<br>When the power supply voltage drops during operation.  |                  | 0    |
| 6 times                     | 1 time<br>flash   | 61                                | Connection lines between the indoor and outdoor units are faulty                | Connection lines are faulty.<br>Indoor or outdoor sub PCB are faulty.   | When 10 seconds passes after the power is turned on<br>without communications signals from the indoor or<br>outdoor unit being detected correctly.  | 0                | _    |
| flash                       | 2 times<br>flash  | 62                                | Serial transmission error   | Indoor or outdoor sub PCB are faulty.<br>Noise is causing faulty operation.   | When 7 minute 35 seconds passes without<br>communications signals from either the outdoor unit or<br>the indoor unit being detected correctly.  | 0                | -    |

| service<br>RUN<br>light | ashes when in<br>e mode<br>TIMER<br>light<br>(1's digit) | Stop coad<br>or<br>Error coad | Error content  | Cause  | Occurrence conditions                              | Error<br>display | Auto<br>recovery |
|-------------------------|--|-------------------------------|--|--|--|------------------|------------------|
|                         | OFF  | 80                            | Indoor unit's fan motor is<br>abnormal                       | ndoor fan motor is faulty.<br>Connector connections are poor.<br>ndoor PCB is faulty.<br>When the indoor unit's fan motor is detected to be running<br>at 300 (SRF : 150) rpm or lower speed with the fan motor<br>in the ON condition while the air conditioner is running. |  | 0                | _                |
|                         | 2 times<br>flash   | 82                            | Indoor heat exchanger sensor<br>is abnormal (anomalous stop) | Indoor heat exchanger sensor wire is<br>disconnected.<br>Connector connections are poor.<br>When a temperature of -28°C or lower is sensed<br>continuously for 40 minutes during heating operation.<br>(the compressor stops).   |  | 0                | _                |
| 8 times<br>flash        | 4 times<br>flash   | 84                            | Anti-condensation control                                    | High humidity condition.<br>Humidity sensor is faulty.   | Anti-condensation prevention control is operating. | _                | 0                |
|                         | 5 times<br>flash   | 85                            | Anti-frost control   | Indoor unit fan speed drops.<br>Indoor heat exchanger sensor is broken wire. stops during cooling operation.   |  | _                | 0                |
|                         | 6 times<br>flash   | 86                            | Heating high pressure control                                | Heating overload operation.<br>Indoor unit fan speed drops.<br>Indoor heat exchanger sensor is short circuit.  |  | _                | 0                |

Note (1) The number of flashes when in the Service Mode do not include the 1.5 second period when the lights light up at first (starting signal). (See the example shown below.)



(a) Auto Recovery:
 (b) Displayed, the error display shows the number of times that an auto recovery occurred for the same reason has reached the number of times in ( ). If no ( ) is displayed, the error display shows that the trouble has occurred once.
 (3) Auto Recovery:
 (3) Auto recovery occurs.

#### (d) Remote controller information tables

1) Operation switching


| 2 | ) Fan  | sneed | switching |
|---|--------|-------|-----------|
| _ | 1 I an | specu | Switching |

| Display pattern when<br>in service mode | Operation switching            | Display pattern when<br>in service mode | Fan speed<br>switching wh   |  |  |
|---|--------------------------------|---|-----------------------------|--|--|
| RUN light<br>(Operation switching)      | when there is an abnormal stop | TIMER light<br>(Fan speed switching)    | there is an<br>abnormal sto |  |  |
| 0                                       | AUTO                           | 0                                       | AUTO                        |  |  |
| 1                                       | DRY                            | 2                                       | HI                          |  |  |
| 2                                       | COOL                           | 3                                       | MED                         |  |  |
| 3                                       | FAN                            | 4                                       | LO                          |  |  |
| 4                                       | HEAT                           | 6                                       | HI POWER                    |  |  |
|   |                                | 7                                       | ECONO                       |  |  |

\* If no data are recorded (error code is normal), the information display in the remote controller becomes as follows.

| Remote controller setting | Display when error code is normal. |
|---------------------------|------------------------------------|
| Operation switching       | AUTO                               |
| Fan speed switching       | AUTO                               |

(Example): Operation switching, fan speed switching, cooling HI




|                                |                                    |     |     |     |     |     |     |     |     | Ur  | nits: ° |
|--------------------------------|------------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|---------|
| RUN liq<br>(10's d             | TIMER light<br>(1's digit)<br>git) | 0   | 1   | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9       |
|                                | 6                                  | -60 | -61 | -62 | -63 | -64 |     |     |     |     |         |
|                                | 5                                  | -50 | -51 | -52 | -53 | -54 | -55 | -56 | -57 | -58 | -59     |
|                                | 4                                  | -40 | -41 | -42 | -43 | -44 | -45 | -46 | -47 | -48 | -49     |
| Yes<br>(sounds for 0.1 second) | 3                                  | -30 | -31 | -32 | -33 | -34 | -35 | -36 | -37 | -38 | -39     |
|                                | 2                                  | -20 | -21 | -22 | -23 | -24 | -25 | -26 | -27 | -28 | -29     |
|                                | 1                                  | -10 | -11 | -12 | -13 | -14 | -15 | -16 | -17 | -18 | -19     |
|                                | 0                                  |     | -1  | -2  | -3  | -4  | -5  | -6  | -7  | -8  | -9      |
|                                | 0                                  | 0   | 1   | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9       |
|                                | 1                                  | 10  | 11  | 12  | 13  | 14  | 15  | 16  | 17  | 18  | 19      |
|                                | 2                                  | 20  | 21  | 22  | 23  | 24  | 25  | 26  | 27  | 28  | 29      |
|                                | 3                                  | 30  | 31  | 32  | 33  | 34  | 35  | 36  | 37  | 38  | 39      |
| No                             | 4                                  | 40  | 41  | 42  | 43  | 44  | 45  | 46  | 47  | 48  | 49      |
| (does not sound)               | 5                                  | 50  | 51  | 52  | 53  | 54  | 55  | 56  | 57  | 58  | 59      |
|                                | 6                                  | 60  | 61  | 62  | 63  | 64  | 65  | 66  | 67  | 68  | 69      |
|                                | 7                                  | 70  | 71  | 72  | 73  | 74  | 75  | 76  | 77  | 78  | 79      |
|                                | 8                                  | 80  | 81  | 82  | 83  | 84  | 85  | 86  | 87  | 88  | 89      |
|                                | 9                                  | 90  | 91  | 92  | 93  | 94  | 95  | 96  | 97  | 98  | 99      |

(e) Room temperature sensor, indoor heat exchanger sensor, outdoor air temperature sensor, outdoor heat exchanger sensor , suction pipe sensor table

\* If no data are recorded (error code is normal), the display for each sensor becomes as shown below.

| Sensor name                    | Sensor value displayed when the error code is normal |
|--------------------------------|--|
| Room temperature sensor        | -64°C  |
| Indoor heat exchanger sensor   | -64°C  |
| Outdoor air temperature sensor | -64°C  |
| Outdoor heat exchanger sensor  | -64°C  |
| Outdoor suction pipe sensor    | -64°C  |

(Example) Room temperature, indoor heat exchanger, outdoor air temperature, outdoor heat exchanger, outdoor suction pipe : "-9°C"



#### (f) Discharge pipe sensor table


|                                     |   |     |     |     |     |     |     |     |     | Uni | ts: °C |
|-------------------------------------|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|--------|
| RUN lig<br>(10's di<br>Buzzer sound | TIMER light<br>(1's digit)<br>Jht<br>git) | 0   | 1   | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9      |
|                                     |   | 60  |     |     |     |     |     |     |     |     |        |
|                                     | 3   | -60 | -62 | -64 |     |     |     |     |     | 1   |        |
| Yes                                 | 2   | -40 | -42 | -44 | -46 | -48 | -50 | -52 | -54 | -56 | -58    |
| (sounds for 0.1 second)             | 1   | -20 | -22 | -24 | -26 | -28 | -30 | -32 | -34 | -36 | -38    |
|                                     | 0   |     | -2  | -4  | -6  | -8  | -10 | -12 | -14 | -16 | -18    |
|                                     | 0   | 0   | 2   | 4   | 6   | 8   | 10  | 12  | 14  | 16  | 18     |
|                                     | 1   | 20  | 22  | 24  | 26  | 28  | 30  | 32  | 34  | 36  | 38     |
|                                     | 2   | 40  | 42  | 44  | 46  | 48  | 50  | 52  | 54  | 56  | 58     |
| No                                  | 3   | 60  | 62  | 64  | 66  | 68  | 70  | 72  | 74  | 76  | 78     |
| (does not sound)                    | 4   | 80  | 82  | 84  | 86  | 88  | 90  | 92  | 94  | 96  | 98     |
|                                     | 5   | 100 | 102 | 104 | 106 | 108 | 110 | 112 | 114 | 116 | 118    |
|                                     | 6   | 120 | 122 | 124 | 126 | 128 | 130 | 132 | 134 | 136 | 138    |
|                                     | 7   | 140 | 142 | 144 | 146 | 148 | 150 |     |     |     |        |

\* If no data are recorded (error code is normal), the display for each sensor becomes as shown below.

| Sensor name           | Sensor value displayed when the error code is normal |
|-----------------------|--|
| Discharge pipe sensor | -64°C  |

(Example) Discharge pipe temperature: "122°C"

\* In the case of discharge pipe data, multiply the reading value by 2. (Below,  $61 \times 2 = (122^{\circ}C)$ )





#### Service data record form


| Customer                   |                     |                     |  | Model           |                  |                   |                     |               |
|----------------------------|---------------------|---------------------|--|-----------------|------------------|-------------------|---------------------|---------------|
| Date of inv                | estigation          |                     |  |                 |                  |                   |                     |               |
| Machine na                 |                     |                     |  |                 |                  |                   |                     |               |
| Content of                 | complaint           |                     |  |                 |                  |                   |                     |               |
| Remote controller settings |                     | ettings             | Content of displayed d                                     | ata             |                  | Display results   |                     |               |
| Cemperature setting        | Operation switching | Fan speed switching | Content of displayed d                                     |                 | Buzzer (Yes/No.) | RUN light (Times) | TIMER light (Times) | Display conte |
|                            |                     | MED                 | Error code on previous occasion.                           |                 |                  |                   |                     |               |
|                            | Cooling             | HI                  | Room temperature sensor on previous occasi                 | on.             |                  |                   |                     |               |
|                            |                     | AUTO                | Indoor heat exchanger sensor 1 on previous o               | ccasion.        |                  |                   |                     |               |
| 21                         |                     | LO                  | Remote controller information on previous or               | casion.         |                  |                   |                     |               |
|                            | Heating             | MED                 | Outdoor air temperature sensor on previous o               | ccasion.        |                  |                   |                     |               |
|                            | Heating             | HI                  | Outdoor heat exchanger sensor on previous occasion.        |                 |                  |                   |                     |               |
|                            |                     | AUTO                | Discharge pipe sensor on previous occasion.                |                 |                  |                   |                     |               |
| 26                         | Cooling             | AUTO                | Indoor heat exchanger sensor 2 on previous o               | ccasion.        |                  |                   |                     |               |
|                            |                     | MED                 | Error code on second previous occasion.                    |                 |                  |                   |                     |               |
|                            | Cooling             | HI                  | Room temperature sensor on second previous                 | occasion.       |                  |                   |                     |               |
|                            |                     | AUTO                | Indoor heat exchanger sensor 1 on second previ             | ous occasion.   |                  |                   |                     |               |
| 22                         |                     | LO                  | Remote controller information on second pre-               | vious occasion. |                  |                   |                     |               |
|                            | Heating             | MED                 | Outdoor air temperature sensor on second pre               | vious occasion. |                  |                   |                     |               |
|                            | meaning             | HI                  | Outdoor heat exchanger sensor on second previous occasion. |                 |                  |                   |                     |               |
|                            |                     | AUTO                | Discharge pipe sensor on second previous occ               | easion.         |                  |                   |                     |               |
| 27                         | Cooling             | AUTO                | Indoor heat exchanger sensor 2 on second occ               | easion.         |                  |                   |                     |               |
|                            |                     | MED                 | Error code on third previous occasion.                     |                 |                  |                   |                     |               |
|                            | Cooling             | HI                  | Room temperature sensor on third previous of               | ccasion.        |                  |                   |                     |               |
|                            |                     | AUTO                | Indoor heat exchanger sensor 1 on third previ              | ous occasion.   |                  |                   |                     |               |
| 23                         |                     | LO                  | Remote controller information on third previo              | ous occasion.   |                  |                   |                     |               |
|                            | Heating             | MED                 | Outdoor air temperature sensor on third previ              | ous occasion.   |                  |                   |                     |               |
|                            | meaning             | HI                  | Outdoor heat exchanger sensor on third previous occasion.  |                 |                  |                   |                     |               |
|                            |                     | AUTO                | Discharge pipe sensor on third previous occas              | sion.           |                  |                   |                     |               |
| 28                         | Cooling             | AUTO                | Indoor heat exchanger sensor 2 on third occas              | ion.            |                  |                   |                     |               |
|                            |                     | MED                 | Error code on fourth previous occasion.                    |                 |                  |                   |                     |               |
|                            | Cooling             | HI                  | Room temperature sensor on fourth previous                 | occasion.       |                  |                   |                     |               |
|                            |                     | AUTO                | Indoor heat exchanger sensor 1 on fourth prev              | vious occasion. |                  |                   |                     |               |
| 24                         |                     | LO                  | Remote controller information on fourth prev               | ious occasion.  |                  |                   |                     |               |
|                            | Heating             | MED                 | Outdoor air temperature sensor on fourth prev              | vious occasion. |                  |                   |                     |               |
|                            | meaning             | HI                  | Outdoor heat exchanger sensor on fourth prev               | ious occasion.  |                  |                   |                     |               |
|                            |                     | AUTO                | Discharge pipe sensor on fourth previous occa              | asion.          |                  |                   |                     |               |
| 29                         | Cooling             | AUTO                | Indoor heat exchanger sensor 2 on fouth occa               | sion.           |                  |                   |                     |               |
|                            | Cooling             | MED                 | Error code on fifth previous occasion.                     |                 |                  |                   |                     |               |
|                            |                     | HI                  | Room temperature sensor on fifth previous or               | casion.         |                  |                   |                     |               |
|                            |                     | AUTO                | Indoor heat exchanger sensor 1 on fifth previo             | ous occasion.   |                  |                   |                     |               |
| 25                         | Heating             | LO                  | Remote controller information on fifth previo              | us occasion.    |                  |                   |                     |               |
|                            |                     | MED                 | Outdoor air temperature sensor on fifth previo             | ous occasion.   |                  |                   |                     |               |
|                            |                     | HI                  | Outdoor heat exchanger sensor on fifth previo              | ous occasion.   |                  |                   |                     |               |
|                            |                     | AUTO                | Discharge pipe sensor on fifth previous occas              | ion.            |                  |                   |                     |               |
| 30                         | Cooling             | AUTO                | Indoor heat exchanger sensor 2 on fifth occas              | ion.            |                  |                   |                     |               |
| 21                         |                     |                     | Stop code on previous occasion.                            |                 |                  |                   |                     |               |
| 22                         |                     | ooling Lo           | Stop code on second previous occasion.                     |                 |                  |                   |                     |               |
| 23                         |                     |                     | Stop code on third previous occasion.                      |                 |                  |                   |                     |               |
| 24                         |                     |                     | Stop code on fourth previous occasion.                     |                 |                  |                   |                     |               |
| 25                         | Cooling             |                     | Stop code on fifth previous occasion.                      |                 |                  |                   |                     |               |
| 26                         |                     |                     | Stop code on sixth previous occasion.                      |                 |                  |                   |                     |               |
| 27                         |                     |                     | Stop code on seventh previous occasion.                    |                 |                  |                   |                     |               |
| 28                         |                     |                     | Stop code on eighth previous occasion.                     |                 |                  |                   |                     |               |
| 29                         |                     |                     | Stop code on ninth previous occasion.                      |                 |                  |                   |                     |               |
| 30                         |                     |                     | Stop code on tenth previous occasion.                      |                 |                  |                   |                     |               |
| Judgment                   |                     |                     |  |                 |                  |                   |                     | Examiner      |


Note (1) In the case of indoor heat exchanger sensor 2, match from 26 to 30 the temperature setting of remote controller. (Refor to page 55)

#### (7) Inspection procedures corresponding to detail of trouble












## Outdoor fan motor error






#### '11 • SCM-SM-110



## Drain abnormality (SRR only)

[Drain piping defective,pump defect, float switch, indoor PCB]



#### (8) Phenomenon observed after shortcircuit, wire breakage on sensor


#### (a) Indoor unit

| Sensor                         | Operation | Phenomenon   |  |  |  |
|--------------------------------|-----------|--|--|--|--|
| Sensor                         | mode      | Shortcircuit   | Disconnected wire  |  |  |
| Room temperature               | Cooling   | Release of continuous compressor operation command.      | Continuous compressor operation command is not released.                     |  |  |
| sensor                         | Heating   | Continuous compressor operation command is not released. | Release of continuous compressor operation command.                          |  |  |
| Heat exchanger sensor          | Cooling   | System can be operated normally.                         | Continiuous compressor operation command is not released.<br>(Anti-frosting) |  |  |
| 301301                         | Heating   | High pressure control mode (Compressor stop command)     | Hot keep (Indoor fan stop)   |  |  |
| Humidity concer <sup>(1)</sup> | Cooling   | Refer to the table below.                                | Refer to the table below.  |  |  |
| Humidity sensor <sup>(1)</sup> | Heating   | Normal system operation is possible.                     |  |  |  |

Note (1) SRK35ZJR-S, 35, 50ZJ-S, 50, 60ZJX-S1, 71ZK-S,SRF25, 35, 50 only

#### Humidity sensor operation

| Failu                | ure mode                     | Control input circuit resding | Air conditioning system operation      |  |  |
|----------------------|------------------------------|-------------------------------|--|--|--|
| Disconnected<br>wire | 1 Disconnected wire          |                               |  |  |  |
|                      | <li>② Disconnected wire</li> | Humidity reading is 0%        | Anti-condensation control is not done. |  |  |
|                      | 12 Disconnected wire         |                               |  |  |  |
| Short<br>Circuit     | 1) and 2) are shot circuited | Humidity reading is 100%      | Anti-condensation control keep doing.  |  |  |




Remark: Do not perform a continuity check of the humidity sensor with a tester. If DC current is applied, it could damage the sensor.

#### (b) Outdoor unit

| Compar                   | Operation | Phenomenon  |   |  |
|--------------------------|-----------|---|---|--|
| Sensor                   | mode      | Shortcircuit  | Disconnected wire   |  |
| Heat exchanger           | Cooling   | System can be operated normally.                                  | Compressor stop.  |  |
| sensor                   | Heating   | Defrosting is not performed.                                      | Defrosting is performed for 10 minutes at approx. 40 minutes. |  |
| Ourdoor air              | Cooling   | System can be operated normally.                                  | Compressor stop.  |  |
| temperature sensor       | Heating   | Defrosting is not operated.                                       | Defrosting is performed for 10 minutes at approx. 40 minutes. |  |
| Discharge pipe<br>sensor | All modes | Compressor overload protection is disabled.<br>(Can be operated.) | Compressor stop   |  |

#### (9) Checking the indoor electrical equipment

#### (a) Indoor PCB check procedure




#### (b) Indoor unit fan motor check procedure

This is a diagnostic procedure for determining if the indoor unit's fan motor or the indoor PCB is broken down.

#### 1) Indoor PCB output check

- a) Turn off the power.
- b) Remove the front panel, then disconnect the fan motor lead wire connector.
- c) Turn on the power. If the unit operates when the ON/OFF button is pressed, if trouble is detected after the voltages in the following figure are output for approximately 30 seconds, it means that the indoor PCB is normal and the fan motor is broken down.

If the voltages in the following figure are not output at connector pins No. (1), (4) and (5), the indoor PCB has failed and the fan motor is normal.



#### 2) Fan motor resistance check

| _ | Measuring point       | Resistance when normal          |  |  |
|---|-----------------------|---------------------------------|--|--|
|   | ① - ③ (Red - Black)   | 20 M $\Omega$ or higher         |  |  |
|   | ④ - ③ (White - Black) | $20 \mathrm{k}\Omega$ or higher |  |  |

- Notes (1) Remove the fan motor and measure it without power connected to it. (2) If the measured value is below the value when the motor is normal, it means
  - that the fan motor is faulty.

#### (C) Power transistor inspection procedure


[Use a tester with a needle indicator for the inspection. (Do not use a digital tester. Check in the AC 300 volt range.)]

(1) If there is a self-diagnosis display, inspect the compressor system (burns, wiring mistakes, etc.) If no problems are found, check the output of the power transistor.


#### (2) Output inspection procedure


Disconnect the terminals for the compresseor.

If an output such as the one shown in the figure on the below can be measured, the power transistor and the circuit board for the outdoor unit are normal.



#### (10) How to make sure of wireless remote controller





expansion valve

See page 76.

1 71 1

Remove the connector and check the resistance value.

See the section of sensor characteristics on page 64.

High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

#### **Color Marks** Mark Color BK Black Power supply BL Blue 1 Phase RD Red 220-240V 50Hz WH White FUSE 250V 15A/ 250V 20A OR Orange BR TB1 Brown BK ΒK YE Yellow WH WH Y/G Yellow/Green Ν Ϋ́ ΨŢ Y∕G Y∕G Y/G TB2 ΒK 1

UNIT A

UNIT B

UNIT C

◆Power source and serial

(1) to (2): AC 220/230/240V

2 to 3 : Normal if the voltage

oscillates between DC 0


and approx. 20V

signal inspection

-----

----<u>-</u>

----<u>-</u>




See the section of sensor characteristics on page 64.

expansion valve

See page 76.

High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.




High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

### Color Marks

1

74 -



High voltage is produced in the control box. Don't touch electrical parts in the control box for 5 minutes after the unit is stopped.

#### Color Marks Mark Color ΒK Black POWER SOURCE BL Blue $\sim 220/230/240V$ Circuit breaker BR Brown 50Hz GN Green arth leakage breaker L OR Orange \_\_\_\_\_ Fı ΡK Pink L2 CNAC (BK) TB3 TB CNACTI RD Red PWB5 PWB3 ∼ AC DS NOISE FILTER NOISE FILTER White WH TB6 YE Yellow A/F + CT1 TB7 TB8 TB7 MODULE Y/G Yellow/Green -1 //G ÷ -1\_\_\_\_ - I N2 PWB2 INV PWB L-IN N-IN CNW (BK) UNIT A CNA1 (WH) CNTRI (WH) LED1 TR 体 UNIT B CNTR (WH) CNA2 (GN) LED2 LED3 UNIT C CNS2 (BK) *11* CNS1 (BK) *•i*本 PWB4 PWB1 CNI1 (WH) CNI2 SUB PWB CONTROL PWB BK CNX2 (YE) CNX1 (YE) WH CNI3 (WH) UNIT D CNI4 CHECKER CNE PC CNV UNIT E IPM ÷ 30A 600V CN EEV3 JNIT F CNFAN1 CNR1 (WH) EEV CNEEVI CNL1 (BL) CNN1 (RD) **−** Ē Ē \$\$ ₿ß Tho-AF HPS CH 20S ◆Power source and serial Tho-R Tho-D [ho−A Tho-S M EEV-H D EEV E EEV F signal inspection (1) to (2): AC 220/230/240V 2 to 3 : Normal if the voltage oscillates between DC 0 and approx. 20V ◆Inspection of electronic ◆Inspection of resistance value of sensor ♦Inspection of outdoor Inspection power transistor expansion valve Remove the connector and check the fan motor Remove the fasten terminal and test See page 76. resistance value. See page 76. output voltage See the section of sensor characteristics


on page 64.

### (a) Inspection of electronic expansion valve

Electronic expansion valve operates for approx. 10 seconds after the power on, in order to determine its aperture. Check the operating sound and voltage during the period of time. (Voltage cannot be checked during operation in which only the aperture change occurs.)

1) If it is heard the sound of operating electronic expansion valve, it is almost normal.

2) If the operating sound is not heard, check the output voltage.



3) If voltage is detected, the outdoor sub PCB is normal.

4) If the expansion valve does not operate (no operating sound) while voltage is detected, the expansion valve is defective.

### • Inspection of electronic expansion valve as a separate unit

Measure the resistance between terminals with an analog tester.

| Measuring point | Resistance when normal |
|-----------------|------------------------|
| 1-6             |                        |
| 1-4             | $46 \pm 4\Omega$       |
| 1-3             | (at 20°C)              |
| 1-5             |                        |

### (b) Outdoor unit fan motor check procedure


When the outdoor unit fan motor error is detected, diagnose which of the outdoor unit fan motor or outdoor main PCB is defective.
Diagnose this only after confirming that the indoor unit is normal.

- Diagnose this only after commining that the indoor unit is no
- (1) Outdoor main PCB output check
  - 1) Turn off the power.
  - 2) Disconnect the outdoor unit fan motor connector CNFAN.

3) When the outdoor unit is operated by inserting the power supply plug and pressing (ON) the backup switch for more than 5 seconds, if the voltage of pin No. ② (SCM100,125: ⑥) in the following figure is output for 30 seconds at 20 seconds after turning "ON" the backup switch, the outdoor main PCB is normal but the fan motor is defective.

If the voltage is not detected, the outdoor main PCB is defective but the fan motor is normal.

Note (1) The voltage is output 3 times repeatedly. If it is not detected, the indoor unit displays the error message.



(2) If the measured value is below the value when the motor is normal, it means that the fan motor is fauly.

(5-4) (Brown - Blue)

20 k  $\Omega$  or higher

## 2.2 FDTC, FDEN and FDUM series

## 2.2.1 Diagnosing of microcomputer circuit

### (1) Selfdiagnosis function

### (a) Check indicator table

Whether a failure exists or not on the indoor unit and outdoor unit can be know by the contents of remote controller error code, indoor/outdoor unit green LED (power pilot lamp and microcomputer normality pilot lamp) or red LED (check pilot lamp). (i) Indoor unit

| Remote controller      |   | Indoor co        | ontrol PCB            | Outdoor<br>main PCB |  |   |   | Reference |
|------------------------|---|------------------|-----------------------|---------------------|--|---|---|-----------|
| Error code             | Red LED   | Red LED          | Green<br>LED (1)      | Red LED             | Location of trouble  | Description of trouble  | Repair method   | page      |
|                        |   | Stays OFF        | Keeps<br>flashing     | Stays OFF           | _  | Normal operation  | _   | _         |
| No-indication Stays OF |   | Stays OFF        | Stays OFF             | Stays OFF           | Indoor unit power supply   | Power OFF, broken wire/blown fuse, broken transformer wire  | Repair  | 98        |
|                        |   | *                | Keeps                 |                     | Remote controller wires  | Poor connection, breakage of remote controller wire * For wire breaking at power ON, the LED is OFF.  | Repair  |           |
|                        |   | 3 times<br>flash | flashing              | Stays OFF           | Remote controller  | Defective remote controller PCB   | Replacement of<br>remote controller                   | 99        |
| (B) WAIT               |   | Stays OFF        | Keeps<br>flashing     | Stays OFF           | Indoor-outdoor units connection<br>wire  | Poor connection, breakage of indoor-outdoor units connection wire   | Repair  | 100~104   |
| intoi Ec               |   |                  | nasining              |                     | Remote controller  | Improper setting of master and slave by remote controller   |   |           |
| <b>C</b> 1             |   |                  | *                     |                     | Remote controller wires (Noise)  | Poor connection of remote controller signal wire (White)     * For wire breaking at power ON, the LED is OFF     Intrusion of noise in remote controller wire                     | Repair  |           |
| Ε Ι                    |   | Stays OFF        | Keeps<br>flashing     | Stays OFF           | Remote controller indoor con-<br>trol PCB  | *• Defective remote controller or indoor control PCB (defective communication circuit)?   | Replacement of<br>remote controller<br>or PCB         | 105       |
|                        |   | 2 times<br>flash | Keeps<br>flashing     | 6 times<br>flash    | Indoor-outdoor units connection<br>wire  | Poor connection of wire between indoor-outdoor units during operation<br>(disconnection, loose connection)<br>Anomalous communication between indoor-outdoor units by noise, etc. | Repair  |           |
| ES                     |   | 2 times          | Keeps                 | 6 times             | (Noise)  | CPU-runaway on outdoor control PCB  | Power reset or<br>Repair                              |           |
|                        |   | flash            | flashing              | flash               | Outdoor control PCB  | *• Occurrence of defective outdoor control PCB on the way of power supply (defective communication<br>circuit)?   | Replacement of<br>PCB                                 | 106       |
|                        |   | 2 times<br>flash | Keeps                 | 6 times<br>flash    | Outdoor control PCB  | Defective outdoor control PCB on the way of power supply  | Replacement   |           |
|                        |   | Tlash            | flashing              | flash               | Fuse   | • Blown fuse  |   |           |
| E6                     |   | 1 time           | Keeps                 | Stays OFF           | Indoor heat exchanger tempera-<br>ture thermistor  | Defective indoor heat exchanger temperature thermistor (defective element, broken wire,<br>short-circuit)     Poor contact of temperature thermistor connector                    | Replacement,<br>repair of temper-<br>ature thermistor | 107       |
|                        |   | flash            | flashing              | Jourgeon            | Indoor control PCB *• Defective indoor control PCB (Defective temperature thermistor input circuit)? |   | Replacement of<br>PCB                                 |           |
| Ε7                     |   | 1 time<br>flash  | Keeps<br>flashing     | Stays OFF           | Indoor return air temperature<br>thermistor  | Defective indoor return air temperature thermistor (defective element, broken wire, short-<br>circuit)     Poor contact of temperature thermistor connector                       | Replacement,<br>repair of temper-<br>ature thermistor | 108       |
|                        | Keeps   |                  | intoining             |                     | Indoor control PCB   | *• Defective indoor control PCB (Defective temperature thermistor input circuit)?   |   |           |
|                        | flashing  |                  |                       |                     | Installation or operating condi-<br>tion   | Heating over-load (Anomalously high indoor heat exchanger temperature)  | Repair  |           |
| E8                     |   | 1 time<br>flash  | Keeps<br>flashing     | Stays OFF           | Indoor heat exchanger tempera-<br>ture thermistor  | Defective indoor heat exchanger temperature thermistor (short-circuit)  | Replacement<br>of temperature<br>thermistor           | 109       |
|                        |   |                  |                       |                     | Indoor control PCB   | *• Defective indoor control PCB (Defective temperature thermistor input circuit)?   | Replacement of<br>PCB                                 |           |
|                        |   |                  |                       |                     | Drain trouble  | Defective drain pump (DM), broken drain pump wire, disconnected connector   | Replacement,<br>repair of DM                          |           |
| FQ                     |   | 1 time           | Keeps                 | Store OFF           | Float switch   | Anomalous float switch operation (malfunction)     (In case of FDTC, FDUM)  | Repair  | 110       |
|                        |   | flash            | flashing              | Stays OFF           | Indoor control PCB   | *• Defective indoor control PCB (Defective float switch input circuit)<br>*• Defective indoor control PCB (Defective DM drive output circuit)?                                    | Replacement of<br>PCB                                 | 110       |
|                        |   |                  |                       |                     | Option   | Defective optional parts (At optional anomalous input setting)  | Repair  |           |
| E 10                   |   | Stays OFF        | Keeps<br>flashing     | Stays OFF           | Number of connected indoor<br>units  | • When multi-unit control by remote controller is performed, the number of units is over  |   | 111       |
| E 16                   |   | 1 time<br>flash  | Keeps<br>flashing     | Stays OFF           | Fan motor  | Defective fan motor     (In case of FDTC, FDUM)   | Replacement,<br>repair                                | 112       |
|                        |   |                  |                       |                     | Indoor control PCB   | Defective indoor control PCB  |   |           |
| E 19<br>E20<br>E28     |   | 1 time<br>flash  | Keeps<br>flashing     | Stays OFF           | Indoor control PCB   | Improper operation mode setting   |   | 113       |
| FZN                    |   | 1 time           | Keeps                 | Stays OFF           | Fan motor  | Indoor fan motor rotation speed anomaly     (In case of FDTC, FDUM)   | Replacement, repair                                   | 114       |
|                        | Indoor power PCB         Defective indoor power PCB |                  | Replacement<br>Repair |                     |  |   |   |           |
| 228                    |   | Stays OFF        | Keeps<br>flashing     | Stays OFF           | Remote controller temperature<br>thermistor  | Broken wire of remote controller temperature thermistor   |   | 115       |

Note (1) Normal indicator lamp (Indoor unit: Green) extinguishes (or lights continuously) only when CPU is anomalous. It keeps flashing in any trouble other than anomalous CPU.

(2) \* mark in the Description of trouble means that, in ordinary diagnosis, it cannot identify the cause definitely, and, if the trouble is repaired by replacing the part, it is judged consequently that the replaced part was defective.

(3) Value in ( ) is for the FDUM series only.

## (ii) Outdoor unit

## (a) Model SCM40, 45, 50, 60, 71, 80

| Remote controller |          | Indoor control PCB  |                   | Outdoor<br>main PCB          |  |   |   | Reference |  |
|-------------------|----------|---|-------------------|------------------------------|--|---|---|-----------|--|
| Error code        | Red LED  | Red LED   | Green<br>LED      | Red LED                      | Location of trouble                                      | Description of trouble  | Repair method                                   | page      |  |
|                   |          |   |                   |                              | Installation, operation status                           | Higher outdoor heat exchanger temperature   | Repair  |           |  |
| E35               |          | Stays OFF   | Keeps<br>flashing | 2 times<br>flash             | Outdoor heat exchanger<br>temperature sensor             | Defective outdoor heat exchanger temperature sensor   | Replacement, repair<br>of temperature<br>sensor | 116       |  |
|                   |          |   |                   |                              | Outdoor main PCB   | *• Defective outdoor main PCB (Defective temperature sensor input circuit)?                   | Replacement of<br>PCB                           |           |  |
|                   |          | Installation, operation status • Higher discharge temperature |                   | Higher discharge temperature | Repair   |   |   |           |  |
| E36               |          | Stays OFF   | Keeps<br>flashing | 5 times<br>flash             | Discharge pipe temperature<br>sensor                     | Defective discharge pipe temperature sensor   | Replacement, repair<br>of temperature<br>sensor | 118       |  |
|                   |          |   |                   |                              | Outdoor main PCB   | *• Defective outdoor main PCB (Defective temperature sensor input circuit)?                   | Replacement of<br>PCB                           |           |  |
| E37               |          | Stays OFF   | Keeps             | 8 times                      | Outdoor heat exchanger<br>temperature sensor             | Defective outdoor heat exchanger temperature sensor, broken wire or poor connector connection | Replacement, repair<br>of temperature<br>sensor | 119       |  |
|                   |          |   | flashing          | flash                        | Outdoor main PCB   | *• Defective outdoor main PCB (Defective temperature sensor input circuit)?                   | Replacement of<br>PCB                           |           |  |
| E 38              |          | Stays OFF   | Keeps             | 8 times                      | Outdoor air temperature<br>sensor                        | Defective outdoor air temperature sensor, broken wire or poor connector connection            | Replacement, repair<br>of temperature<br>sensor | 120       |  |
|                   |          |   | flashing          | flash                        | Outdoor main PCB   | *• Defective outdoor main PCB (Defective temperature sensor input circuit)?                   | Replacement of<br>PCB                           |           |  |
| E 3 9             |          | Stays OFF   | Keeps             | 8 times                      | Discharge pipe temperature<br>sensor                     | Defective discharge pipe temperature sensor, broken wire or poor connector connection         | Replacement, repair<br>of temperature<br>sensor | 121       |  |
|                   | Keeps    |   | flashing          | flash                        | Outdoor main PCB   | *• Defective outdoor main PCB (Defective temperature sensor input circuit)?                   | Replacement of<br>PCB                           |           |  |
| ЕЧ2               | flashing | Stays OFF   | Keeps<br>flashing | 1 time<br>flash              | Outdoor main PCB,<br>compressor                          | Current cut (Anomalous compressor over-current)   | Replacement of<br>PCB                           | 124 • 125 |  |
|                   |          |   | nasning           | masn                         | Installation, operation status                           | Service valve closing operation   | Repair  |           |  |
| EYS               |          | Stay OFF  | Keeps             | 4 times                      | Outdoor main PCB   | Anomalous outdoor main PCB commuication   | Replacement of                                  | 126       |  |
|                   |          | Sury OII  | flashing          | flash                        | Outdoor sub PCB  | Anomalous outdoor sub PCB commuication  | PCB   | 120       |  |
| ЕЧЛ               |          | Stays OFF   | Keeps<br>flashing | 2 times<br>flash             | Outdoor sub PCB  | Defective active filter   | Repair<br>PCB replacement                       | 127       |  |
| E48               |          | Stays OFF   | Keeps             | Keeps                        | Fan motor  | Defective fan motor   | Replacement                                     | 128       |  |
|                   |          |   | flashing          | flashing                     | Outdoor main PCB   | Defective outdoor main PCB  | · · · · · · ·                                   |           |  |
| E5 I              |          | Stays OFF   | Keeps<br>flashing | 1 time<br>flash              | Power transistor error<br>(outdoor main PCB)             | Power transistor error  | Replacement of<br>PCB                           | 129       |  |
| E53               |          | Stays OFF   | Keeps<br>flashing | 8 times<br>flash             | Outdoor suction pipe sensor                              | Defective suction pipe temperature sensor, broken wire or poor connector connection           | Replacement, repair<br>of temperature<br>sensor | 131       |  |
|                   |          |   | nashing           | nasn                         | Outdoor sub PCB  | Defective outdoor sub PCB (Defective temperature sensor input circuit)?                       | Replacement of<br>PCB                           |           |  |
|                   |          |   | Keens             | 2 times                      | Operation status   | Shortage in refrigerant quantity  | Repair  |           |  |
| E57               |          | Stays OFF   | flashing          | flash                        | Installation status                                      | tion status • Service valve closing operation   |   | 133       |  |
| E 58              |          | Stays OFF   | Keeps<br>flashing | 3 times<br>flash             | Overload operation     Overcharge     Compressor locking | Current safe stop   | Replacement                                     | 134       |  |
| E59               |          | Stays OFF   | Keeps<br>flashing | 2 times<br>flash             | Compressor, outdoor main<br>PCB                          | ain • Anomalous compressor startup Replace  |   | 135       |  |
| E60               |          | Stays OFF   | Keeps<br>flashing | 7 times<br>flash             | Compressor   | Anomalous compressor rotor lock   | Replacement                                     | 136       |  |

Note (1) \* mark in the Description of trouble means that, in ordinary diagnosis, it cannot identify the cause definitely, and, if the trouble is repaired by replacing the part, it is judged consequently that the replaced part was defective.

### (b) Model SCM100, 125

| Remote co    | ontroller         | Indoor co                   | ntrol PCB         | Outdoor<br>control PCB |  |   |   | Reference |  |
|--------------|-------------------|-----------------------------|-------------------|------------------------|--|---|---|-----------|--|
| Error code   | Red LED           | Red LED                     | Green<br>LED      | Red LED                | Location of trouble                          | Description of trouble  | Repair method                                       | page      |  |
|              |                   |                             |                   |                        | Installation, cooling operation status       | Higher outdoor high pressure  | Repair  |           |  |
| E35          |                   | Stays OFF                   | Keeps<br>flashing | 2 times<br>flash       | High pressure sensor                         | Defective high pressure sensor  | Replacement, repair<br>of temperature<br>sensor     | 117       |  |
|              |                   |                             |                   |                        | Outdoor control PCB                          | *• Defective outdoor control PCB (Defective high pressure sensor input circuit)?              | Replacement of<br>PCB                               |           |  |
|              |                   |                             |                   |                        | Installation, operation status               | Higher discharge temperature  | Repair  |           |  |
| E 36         |                   | Stays OFF Keeps<br>flashing |                   | 5 times<br>flash       | Discharge pipe temperature<br>sensor         | Defective discharge pipe temperature sensor   | Replacement, repair<br>of temperature<br>sensor     | 118       |  |
|              |                   |                             |                   |                        | Outdoor control PCB                          | *• Defective outdoor control PCB (Defective temperature sensor input circuit)?                | Replacement of<br>PCB                               |           |  |
| ЕЗТ          |                   | Stays OFF Keeps<br>flashing |                   | 8 times<br>flash       | Outdoor heat exchanger<br>temperature sensor | Defective outdoor heat exchanger temperature sensor, broken wire or poor connector connection | Replacement, repair<br>of temperature<br>sensor 119 |           |  |
|              |                   |                             | incoming          | muon                   | Outdoor control PCB                          | *• Defective outdoor control PCB (Defective temperature sensor input circuit)?                | Replacement of<br>PCB                               |           |  |
| E 38         |                   | Stays OFF                   | Keeps<br>flashing | 8 times<br>flash       | Outdoor air temperature<br>sensor            | Defective outdoor air temperature sensor, broken wire or poor connector connection            | Replacement, repair<br>of temperature<br>sensor     | 120       |  |
|              |                   |                             | nasning           | nasn                   | Outdoor control PCB                          | B *• Defective outdoor control PCB (Defective temperature sensor input circuit)?              |   |           |  |
| E 3 9        |                   | Stays OFF                   | Keeps             | 8 times                | Discharge pipe temperature<br>sensor         | Defective discharge pipe temperature sensor, broken wire or poor connector connection         | Replacement, repair<br>of temperature<br>sensor     | 121       |  |
|              |                   |                             | flashing          | flash                  | Outdoor control PCB                          | *• Defective outdoor control PCB (Defective temperature sensor input circuit)?                | Replacement of<br>PCB                               |           |  |
|              |                   |                             |                   |                        | Installation, Heating operation<br>status    | Higher outdoor high pressure  | Repair  |           |  |
| ЕЧО          | Keeps<br>flashing | Stays OFF                   | Keeps<br>flashing | 2 times<br>flash       | High pressure sensor                         | Defective high pressure sensor  | Replacement, repair<br>of temperature<br>sensor     | 122       |  |
|              |                   |                             |                   |                        | Outdoor control PCB                          | Defective outdoor control PCB (Defective high pressure sensor input circuit)?                 | Replacement of<br>PCB                               |           |  |
| E41          |                   | Stays OFF                   | Keeps<br>flashing | 1 time<br>flash        | Power transistor                             | Power transistor overheat   | Replacement of<br>PCB or Repair                     | 123       |  |
| ЕЧ2          |                   | Stays OFF                   | Keeps             | 1 time                 | Outdoor main PCB,<br>compressor              | Current cut (Anomalous compressor over-current)   | Replacement of<br>PCB                               | 124•125   |  |
|              |                   |                             | flashing          | flash                  | Installation, operation status               | Service valve closing operation   | Repair  | 124*123   |  |
| E45          |                   | Stay OFF                    | Keeps             | 4 times                | Outdoor control PCB                          | Anomalous outdoor control PCB commuication  | Replacement of                                      | 126       |  |
| <u> </u>     |                   |                             | flashing          | flash                  | Outdoor sub PCB                              | Anomalous outdoor sub PCB commuication  | PCB   |           |  |
| E48          |                   | Stays OFF                   | Keeps<br>flashing | Keeps<br>flashing      | Fan motor<br>Outdoor control PCB             | Defective fan motor     Defective outdoor control PCB   | Replacement   | 128       |  |
| E5 /         |                   | Stays OFF                   | Keeps<br>flashing | 1 time<br>flash        | Power transistor error<br>(Inverter PCB)     | Inverter and fan motor anomaly  | Replacement of<br>PCB                               | 130       |  |
| E53          |                   | Stays OFF                   | Keeps             | 8 times<br>flash       | Outdoor suction pipe sensor                  | Defective suction pipe temperature sensor, broken wire or poor connector connection           | Replacement, repair<br>of temperature<br>sensor     |           |  |
|              |                   |                             | masning           | nasn                   | Outdoor sub PCB                              | Defective outdoor sub PCB (Defective temperature sensor input circuit)?                       | Replacement of<br>PCB                               |           |  |
| CCU          |                   |                             | Keeps             | 8 times                | High pressure sensor                         | Defective high pressure sensor  | Replacement of<br>sensor                            |           |  |
| ESY          |                   | Stays OFF                   | flashing          |                        | Outdoor control PCB                          | Defective outdoor control PCB (Defective temperature sensor input circuit)?                   | Replacement of<br>PCB                               | 132       |  |
|              |                   |                             | Keeps             | 2 times                | Operation status                             | Shortage in refrigerant quantity  | Repair  |           |  |
| E 57<br>E 59 |                   | Stays OFF                   | flashing          | flash                  | Installation status                          | Service valve closing operation   | Service valve<br>opening check                      | 133       |  |
| E59          |                   | Stays OFF                   | Keeps<br>flashing | 2 times<br>flash       | Compressor, outdoor main<br>PCB              | Anomalous compressor startup  | Replacement   | 135       |  |
| L            |                   |                             |                   |                        |  | 1   |   |           |  |

Note (1) \* mark in the Description of trouble means that, in ordinary diagnosis, it cannot identify the cause definitely, and, if the trouble is repaired by replacing the part, it is judged consequently that the replaced part was defective.

## (iv) Display sequence of error codes or inspection indicator lamps

## Occurrence of one kind of error

Displays are shown respectively according to errors.

| Section                                  | Category of display  |
|--|--|
| Error code on remote<br>controller       | • Displays the error of higher priority (When plural errors are persisting)                      |
| Red LED on indoor<br>control PCB         | Е І Е 5 ·····Е 10 - Е 3 - ····ЕЬО  |
| Red LED on outdoor<br>main (control) PCB | • Displays the present errors. (When a new error has occurred after the former error was reset.) |

### Error detecting timing

| Section | Error description   | Error code | Error detecting timing   |  |  |
|---------|---|------------|--|--|--|
|         | Drain trouble (Float switch activated)  | 69         | Whenever float switch is activated after 30 second had past since power ON.  |  |  |
|         | Communication error at initial operation  | "''BWAIT'' | No communication between indoor and outdoor units is established at initial operation.   |  |  |
|         | Remote controller<br>communication circuit error  | ΕI         | Communication between indoor unit and remote controller is<br>interrupted for mote than 2 minutes continuously after initial<br>communication was established.   |  |  |
| Indoor  | Communication error during operation  | ES         | Communication between indoor and outdoor units is interrupted<br>for mote than 2 minutes continuously after initial communication<br>was established.  |  |  |
|         | Excessive number of<br>connected indoor units by<br>controlling with one remote<br>controller | E 10       | Whenever excessively connected indoor units is detected after power ON.  |  |  |
|         | Return air temperature thermistor anomaly   | 67         | -50°C or lower is detected for 5 seconds continuously within 60 minutes after initial detection of this anomalous temperature.   |  |  |
|         | Indoor heat exchanger<br>temperature thermistor<br>anomaly                                    | 68         | -50°C or lower is detected for 5 seconds continuously within 60 minutes after initial detection of this anomalous temperature. Or 70°C or higher is detected for 5 seconds continuously.   |  |  |
|         | Outdoor air temperature sensor anomaly  | 638        | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous sensor.<br>Or -55°C or higher is detected for 5 seconds continuously within<br>20 seconds after power ON. |  |  |
| Outdoor | Outdoor heat exchanger<br>temperature sensor anomaly  | 637        | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous sensor.<br>Or -55°C or lower is detected for 5 seconds continuously within<br>20 seconds after power ON.  |  |  |
|         | Discharge pipe temperature sensor anomaly   | 639        | -25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous sensor.  |  |  |
|         | Suction pipe temperature sensor anomaly   |            | -55°C or lower is detected for 5 seconds continuously 3 times<br>within 40 minutes after initial detection of this anomalous sensor.<br>Or -55°C or higher is detected for 5 seconds continuously within<br>20 seconds after power ON. |  |  |

### Error log and reset

| Error indicator                       | Memorized error log                    | Reset  |  |
|---------------------------------------|--|--|--|
| Remote controller display             | Higher priority error is memorized.    | • Stop the unit by pressing the ON/OFF   |  |
| Red LED on indoor control PCB         | • Not memorized.                       | <ul><li>switch of remote controller.</li><li>If the unit has recovered from anomaly, it can be operated.</li></ul> |  |
| Red LED on outdoor main (control) PCB | • Memorizes a mode of higher priority. |  |  |

### Resetting the error log

• Resetting the memorized error log in the remote controller

Holding down "CHECK" button, press "TIMER" button to reset the error log memorized in the remote controller.


• Resetting the memorized error log

The remote controller transmits error log erase command to the indoor unit when "VENTI" button is pressed while holding down "CHECK" button.

Receiving the command, the indoor unit erase the log and answer the status of no error.

### (2) Troubleshooting procedure

When any trouble has occurred, inspect as follows. Details of respective inspection method will be described on later pages.



### (3) Troubleshooting at the indoor unit

With the troubleshooting, find out any defective part by checking the voltage (AC, DC), resistance, etc. at respective connectors at around the indoor PCB, according to the inspection display or operation status of unit (the compressor does not run, fan does not run, the 4-way valve does not switch, etc.), and replace or repair in the unit of following part.

### (a) Replacement part related to indoor PCB's

Control PCB, power supply PCB, temperature thermistor (return air, indoor heat exchanger), remote controller switch and fuse

Note (1) With regard to parts of high voltage circuits and refrigeration cycle, judge it according to ordinary inspection methods.

### (b) Instruction of how to replace indoor control PCB

### SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the replacement in order to protect yourself.
  - The precautionary items mentioned below are distinguished into two levels, WARNING and CAUTION.
  - Both mentions the important items to protect your health and safety so strictly follow them by any means.
  - WARNING Wrong installation would cause serious consequences such as injuries or death.
  - CAUTION Wrong installation might cause serious consequences depending on circumstances.
  - After completing the replacement, do commissioning to confirm there are no anomaly.
  - Replacement should be performed by the specialist.
  - If you replace the PCB by yourself, it may lead to serious trouble such as electric shock or fire.
  - Replace the PCB correctly according to these instructions.
  - Improper replacement may cause electric shock or fire.
  - Shut off the power before electrical wiring work.
  - Replacement during the applying the current would cause the electric shock, unit failure or improper running.
  - It would cause the damage of connected equipment such as fan motor,etc. • Fasten the wiring to the terminal securely, and hold the cable securely so as not to apply unexpected stress on the terminal
- Loose connections or hold could result in abnormal heat generation or fire.
- Check the connection of wiring to PCB correctly before turning on the power, after replacement.
  - Defectiveness of replacement may cause electric shock or fire.

#### 

- In connecting connector onto the PCB, connect not to deform the PCB. It may cause breakage or malfunction.
- Insert connector securely, and hook stopper. It may cause fire or improper running.
   Pundle the applies together as an entry to be simpled as the transmission.

Bundle the cables together so as not to be pinched or be tensioned. It may cause malfunction or electric shock for disconnection or deformation.

## (i) FDTC series

Control PCB

Replace and set up the PCB according to this instruction.

① Set to an appropriate address and function using switch on PCB. Select the same setting with the removed PCB.

| item       | switch | Content of control                                 |                                      |  |  |  |
|------------|--------|--|--------------------------------------|--|--|--|
| Address    | SW2    | Plural indoor units control by 1 remote controller |                                      |  |  |  |
| Test run   | SW7-1  | _  | Normal                               |  |  |  |
|            | 5007-1 | 0  | Operation check/drain motor test run |  |  |  |
| O:ON -:OFF |        |  |                                      |  |  |  |

② Set to an appropriate capacity using the model selector switch(SW6).

Select the same capacity with the PCB removed from the unit.

| SW6  | -1 | -2 | -3 | -4 | SW6 |
|------|----|----|----|----|-----|
| 25VD | 0  | _  | -  | _  | ON  |
| 35VD | —  | 0  | -  | -  |     |
| 50VD | 0  | —  | 0  | -  |     |
| 60VD | 0  | 0  | 0  | _  |     |



③ Replace the PCB


1. Fix the PCB so as not to pitch the cords.

2. Connect connectors to the PCB. Connect a cable connector with the PCB connector of the same color.

3. Do not pass CPU surrounding about wirings.

### ④ Control PCB

Parts mounting are different by the kind of PCB.



## PSB012D931F

PSB012D953A


### • Power PCB

This PCB is a general PCB. Replace the PCB according to this instruction.

### ① Replace the PCB (refer to right dwg.)

- 1. Unscrew terminal of the wiring(yellow/green) soldered to PCB from the box.
- 2. Cut the band that binds the wiring (red and blue) from connector CNW1 and CNW2, and the wiring (yellow/green) from PCB (T2/T3). (Note 1) (However, do not cut the band that binds only the red and blue wirings.)
- 3. Replace the PCB only after all the wirings connected to the connector are removed.
- 4. Fix the board such that it will not pinch any of the wires.
- 5. Reconnect the wirings to the PCB. Wiring connector color should match with the color of connector of the PCB. (Note 2)
- 6. Let the wiring (red and blue) pass beneath the (yellow/green) wiring and bind together with band.
- 7. Screw back the terminal of wiring (yellow/green) from PCB(T1, T2/T3), that was removed in 1.
  - In that case, do not place the crimping part of the wiring under the PCB.
  - (Note 1): It might not be applicable on some models.
  - (Note 2): After replacing PCB, connection between capacitor assy and connector CNP is no longer needed.

### 2 Power PCB




## (ii) FDEN series

1 Set to an appropriate address and function using switch on PCB.

- 1. There is a unit having plural applicable PCB depending on a model.
- 2. Set the function setting corresponding the spare PCB and the applicable model.

| item                      | switch | Content of control                                 |                                      |  |  |
|---------------------------|--------|--|--------------------------------------|--|--|
| Address                   | SW2    | Plural indoor units control by 1 remote controller |                                      |  |  |
| Test run                  | SW7-1  | —  | Normal                               |  |  |
|                           | 3007-1 | 0  | Operation check/drain motor test run |  |  |
| $\bigcirc$ : ON $-$ : OFF |        |  |                                      |  |  |

② Set to an appropriate capacity using the model selector switch(SW6). Select the same capacity with the PCB removed from the unit.



### ③ Replace the PCB


1. Fix the PCB so as not to pitch the cords.

2. Connect connectors to the PCB. Connect a cable connector with the PCB connector of the same color.

 $\ensuremath{\mathsf{3.Do}}$  not pass CPU surrounding about wirings.

### ④ Control PCB

Parts mounting are different by the kind of PCB.



## PSB012D974

### (iii) FDUM series

### PSB012D990

Control PCB


Replace and set up the PCB according to this instruction.


1 Set to an appropriate address and function using switch on PCB.

### Select the same setting with the removed PCB.

| item       | switch | Content of control                                 |                                      |  |  |
|------------|--------|--|--------------------------------------|--|--|
| Address    | SW2    | Plural indoor units control by 1 remote controller |                                      |  |  |
| Test run   | SW7-1  | —  | Normal                               |  |  |
|            |        | 0  | Operation check/drain motor test run |  |  |
| 0:0N —:0FF |        |  |                                      |  |  |


(2) Set to an appropriate capacity using the model selector switch(SW6).





- ③ Replace the PCB
  - 1. Exchange PCB after detaching all connectors connected with the PCB.
  - 2. Fix the PCB so as not to pitch the wiring.
  - 3. Connect connectors to the PCB. Match the wiring connector to the connector color on the PCB and connect it.
- ④ Control PCB

Parts mounting are different by the kind of PCB.



## • Power PCB

This PCB is a general PCB. Replace the PCB according to this instruction.


### PSB012D992

### 1 Replace the PCB

- 1. Unscrew terminal of the wiring(yellow/green) connected to Terminal block (CNWO) from the box.
- 2. Replace the PCB only after all the wirings connected to the connector are removed.
- 3. Fix the board such that it will not pinch any of the wires.
- 4. Reconnect the wirings to the PCB. Wiring connector color should match with the color of connector of the PCB.
- 5. Screw back the terminal of wiring, that was removed in 1.

### 2 Power PCB

Parts mounting are different by the kind of PCB.



## DIP switch setting list

| Switches | Descriptio                             | D                       | efault setting | Remarks     |          |
|----------|--|-------------------------|----------------|-------------|----------|
| SW2      | Address No. setting at plural indoor u | 0                       |                | 0-F         |          |
| SW6-1    |  |                         |                |             |          |
| SW6-2    | Model selection                        | As per model            |                | See table 1 |          |
| SW6-3    | Wodel selection                        |                         |                |             |          |
| SW6-4    |  |                         |                |             |          |
| SW7-1    | Test run, Drain motor                  | Normal*/Test run        | OFF            | Normal      |          |
| SW7-2    | Reserved                               |                         | OFF            |             | keep OFF |
| SW7-3    | Powerful mode Valid*/Invalid           |                         |                | Valid       |          |
| SW7-4    | Reserved                               |                         |                |             | keep OFF |
| JSL1     | Superlink terminal spare               | Normal*/switch to spare | With           |             |          |

\* Default setting

Table 1: Indoor unit model selection with SW6-1-SW6-4 0: OFF 1:ON

|       | 0: OFF | T:UN |      |      |
|-------|--------|------|------|------|
|       | 25VD   | 35VD | 50VD | 60VD |
| SW6-1 | 1      | 0    | 1    | 1    |
| SW6-2 | 0      | 1    | 0    | 1    |
| SW6-3 | 0      | 0    | 1    | 1    |
| SW6-4 | 0      | 0    | 0    | 0    |

(4) Check of anomalous operation data with the remote controller

Operation data can be checked with remote control unit operation.

- ① Press the CHECK button. The display change " OPER DATA
- ② Press the  $\bigcirc$  (SET) button while "  $\bigcirc$   $\bigcirc$   $\bigcirc$   $\bigcirc$  is displayed.
- ③ When only one indoor unit is connected to remote controller, "DATALDADING" is displayed (blinking indication during data loading).

Next, operation data of the indoor unit will be displayed. Skip to step 7.

 When plural indoor units is connected, the smallest address number of indoor unit among all connected indoor unit is displayed. [Example]:

" ⓑ\$ SELECT I/U " (blinking 1 seconds) → " I/U000 ▲ " blinking.

- Select the indoor unit number you would like to have data displayed with the button.
- 6 Determine the indoor unit number with the O (SET) button.

(The indoor unit number changes from blinking indication to continuous indication)

" I/U000 " (The address of selected indoor unit is blinking for 2 seconds.)

↓

"DATA LDADING" (A blinking indication appears while data loaded.) Next, the operation data of the indoor unit is indicated.

Upon operation of the button, the current operation data is displayed in order from data number 01.

The items displayed are in the above table.

\*Depending on models, the items that do not have corresponding data are not displayed.

- ③ To display the data of a different indoor unit, press the AIR CON NO. button, which allows you to go back to the indoor unit selection screen.
- Pressing the OON/OFF button will stop displaying data.

Pressing the *(RESET)* button during remote control unit operation will undo your last operation and allow you to go back to the previous screen.

 $\odot$ If two (2) remote controllers are connected to one (1) inside unit, only the master controller is available for trial operation and confirmation of operation data. (The slave remote controller is not available.)

| Number |   | Data Item  |
|--------|---|--|
| 01     | жж<br>Жж  | (Operation Mode)                                 |
| 02     | SET TEMPోం                                      | (Set Temperature)                                |
| 03     | RETURN AIRర                                     | (Return Air Temperature)                         |
| 04     | 🗏 SENSOR~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~       | (Remote Controller Thermistor Tempeature)        |
| 05     | THI-R1°   | (Indoor Heat Exchanger Thermistor / U Bend)      |
| 06     | THI-R2°   | (Indoor Heat Exchanger Thermistor /Capillary)    |
| 07     | THI-R3c   | (Indoor Heat Exchanger Thermistor /Gas Header)   |
| 08     | I/U FANSPEED                                    | (Indoor Unit Fan Speed)                          |
| 09     | DEMAND <u>H</u> z                               | (Frequency Requirements)                         |
| 10     | ANSWERHz  | (Response Frequency)                             |
| 11     | I/U EEVP  | (Pulse of Indoor Unit Expansion Value)           |
| 12     | TOTAL I/U RUN                                   | _H (Total Running Hours of The Indoor Unit)      |
| 21     | OUTDOOR°C                                       | (Outdoor Air Temperature)                        |
| 22     | THO-R1ి   | (Outdoor Heat Exchanger Thermistor)              |
| 23     | <u>THD-R2°c</u>                                 | (Outdoor Heat Exchanger Thermistor)              |
| 24     | COMPHz  | (Compressor Frequency)                           |
| 25     | HPMPa   | (High Pressure)                                  |
| 26     | LPMPa   | (Low Pressure)                                   |
| 27     | گ   | (Discharge Pipe Temperature)                     |
| 28     |   | (Comp Bottom Temperature)                        |
| 29     | AMP   | (Current)  |
| 30     | TARGET SH`ర                                     | (Target Super Heat)                              |
| 31     | SHč   | (Super Heat)                                     |
| 32     | <u>    TDSH                                </u> | (Discharge Pipe Super Heat)                      |
| 33     | PROTECTION No                                   | (Protection State No. of The Compressor)         |
| 34     | 0/UFANSPEED                                     | (Outdoor Unit Fan Speed)                         |
| 35     | <u>63H1</u>                                     | (63H1 On/Off)                                    |
| 36     | DEFROST   | (Defrost Control On/Off)                         |
| 37     | TOTAL COMP RUN_                                 | H (Total Running Hours of The Compressor)        |
| 38     | 0/UEEV1P  | (Pulse of The Outdoor Unit Expansion Valve EEVC) |
| 39     | 0/UEEV2P  | (Pulse of The Outdoor Unit Expansion Valve EEVH) |

O OFF

### (5) Inverter checker for diagnosis of inverter output

### Checking method

- (a) Setup procedure of checker.
  - 1) Power OFF (Turn off the breaker).
  - 2) Remove the terminal cover of compressor and disconnect the wires (U, V, W) from compressor.
  - 3) Connect the wires U (Red), V (White) and W (Black) of the checker to the terminal of disconnected wires (U, V, W) from compressor respectively.
- (b) Operation for judgment.
  - 1) Power ON and start check operation on cooling or heating mode.
  - 2) Check ON/OFF status of 6 LED's on the checker.
  - 3) Judge the PCB by ON/OFF status of 6 LED's on the checker.

|            | , 0                     | 5   |  |  |  |
|------------|-------------------------|---|--|--|--|
|            | ON/OFF<br>status of LED | If all of LED are ON/OFF according to following pattern | If all of LED stay OFF or some of LED are ON/OFF           |  |  |
|            | Outdoor main<br>PCB     | Normal  | Anomalous  |  |  |
|            | Power O                 | N 3 min.  | During this period, ON/OFF s repeated cyclically according |  |  |
|            |                         |   |  |  |  |
|            | Start cl                | T<br>neck operation Sto                                 | p check operation  |  |  |
|            | 4) Stop chec            | k operation within about 2minutes                       | s after starting check operation.                          |  |  |
| <b>⟨In</b> | verter Checke           | LED   | (LED ON/OFF pattern)                                       | )  |  |
|            |                         |   |  | $\begin{array}{c} 101\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\ 0\\$ | LED1<br>LED2<br>LED3<br>LED4<br>LED5<br>LED6<br>LED6 |
|            |                         | (Pad  |  | Cyclically   | • ON   |

Faston terminal *W* W Connect to the terminal of the wires which are disconnected from compressor.

Black

### (6) Outdoor unit inspection points


•See page 71 to 75


# 2.2.2 Troubleshooting flow


| (1) List of troubles |  |
|----------------------|--|
|----------------------|--|


| Remote controller display | Description of trouble  | Reference page |
|---------------------------|---|----------------|
| None                      | Operates but does not cool.   | 91             |
| None                      | Operates but does not heat.   | 92             |
| None                      | Earth leakage breaker activated   | 93             |
| None                      | Excessive noise/vibration (1/3)   | 94             |
| None                      | Excessive noise/vibration (2/3)   | 95             |
| None                      | Excessive noise/vibration (3/3)   | 96             |
| None                      | Louver motor failure (FDTC and FDEM only)   | 97             |
| None                      | Power supply system error (Power supply to indoor control PCB)  | 98             |
| None                      | Power supply system error (Power supply to remote controller)   | 99             |
| INSPECT I/U               | INSPECT I/U (When 1 or 2 remote controllers are connected)  | 100            |
| INSPECT I/U               | INSPECT I/U (Connection of 3 units or more remote controllers)  | 101            |
| டூwait டூ                 | Communication error at initial operation  | 102~104        |
| E1                        | Remote controller communication circuit error   | 105            |
| E5                        | Communication error during operation  | 106            |
| E6                        | Indoor heat exchanger temperature thermistor anomaly  | 107            |
| E7                        | Return air temperature thermistor anomaly   | 108            |
| E8                        | Heating overload operation  | 109            |
| Е9                        | Drain trouble (FDTC and FDUM only)  | 110            |
| E10                       | Excessive number of connected indoor units (more than 17 units) by controlling with one remote controller | 111            |
| E16                       | Indoor fan motor anomaly (FDTC and FDUM only)   | 112            |
| E19                       | Indoor unit operation check, drain motor check setting error  | 113            |
| E20                       | Indoor fan motor rotation speed anomaly (FDTC and FDUM only)  | 114            |
| E28                       | Remote controller temperature thermistor anomaly  | 115            |
| E35                       | Cooling high pressure operation   | 116, 117       |
| E36                       | Discharge pipe temperature error  | 118            |
| E37                       | Outdoor heat exchanger temperature sensor anomaly   | 119            |
| E38                       | Outdoor air temperature sensor anomaly  | 120            |
| E39                       | Discharge pipe temperature sensor anomaly   | 121            |
| E40                       | Heating high pressure operation (SCM100, 125 only)  | 122            |
| E41                       | Power transistor overheat (SCM100, 125 only)  | 123            |
| E42                       | Current cut   | 124, 125       |
| E45                       | Outdoor sub PCB communication error   | 126            |
| E47                       | Active filter voltage error (SCM40, 45, 50, 60, 71, 80 only)  | 127            |
| E48                       | Outdoor fan motor anomaly   | 128            |
| E51                       | Power transistor anomaly (SCM40, 45, 50, 60, 71, 80 only)   | 129            |
| E51                       | Inverter and fan motor anomaly (SCM100, 125 only)   | 130            |
| E53                       | Suction pipe temperature error  | 131            |
| E54                       | High pressure sensor anomly (SCM100, 125 only)  | 132            |
| E57                       | Insufficient refrigerant amount or detection of service valve closure                                     | 133            |
| E58                       | Current safe stop (SCM40, 45, 50, 60, 71, 80 only)  | 134            |
| E59                       | Compressor startup failure  | 135            |
| E60                       | Anomalous compressor rotor lock (SCM40, 45, 50, 60, 71, 80 only)  | 136            |

## (2) Troubleshooting



























|   |                         |         |       |     |  | 1 |
|---|-------------------------|---------|-------|-----|--|---|
| ſ | Error code              | LED     | Green | Red | Content  |   |
|   | Remote controller: None | Indoor  | -     | -   | Excessive noise/vibration (3/3)  |   |
|   |                         | Outdoor | _     | -   | $\mathbf{L}_{\mathbf{X}} = \mathbf{L}_{\mathbf{X}} = $ |   |




|   |                         |         |                |           | G                      |
|---|-------------------------|---------|----------------|-----------|------------------------|
| β | Error code              | LED     | Green          | Red       | Content                |
|   | Remote controller: None | Indoor  | Keeps flashing | Stays OFF | Louver motor failure   |
|   |                         | Outdoor | -              | Stays OFF | (FDTC and FDEN series) |




 $\bigcirc$ 


|   | _ |                         |         |           |           | P7                                   |
|---|---|-------------------------|---------|-----------|-----------|--------------------------------------|
| ſ | ρ | Error code              | LED     | Green     | Red       | Content Power supply system error    |
|   |   | Remote controller: None | Indoor  | Stays OFF | Stays OFF | (Dewer supply to indeer central DCD) |
|   |   |                         | Outdoor | -         | Stays OFF | (Power supply to indoor control PCB) |
| l | ſ |                         |         |           |           |                                      |



|   | _ |                         |         |                |           | Q  |
|---|---|-------------------------|---------|----------------|-----------|--|
| { | 9 | Error code              | LED     | Green          | Red       | Content Dower supply system error                                |
|   |   | Remote controller: None | Indoor  | Keeps flashing | Stays OFF | Power supply system error<br>(Power supply to remote controller) |
|   |   |                         | Outdoor | _              | Stays OFF | (Fower suppry to remote controller)                              |
| l | ſ |                         |         |                |           |  |




|   |                                |         |                |           | G  |
|---|--------------------------------|---------|----------------|-----------|--|
| μ | Error code                     | LED     | Green          | Red       | Content  |
|   | Remote controller: INSPECT I/U | Indoor  | Keeps flashing | Stays OFF | INSPECT I/U                                    |
|   |                                | Outdoor | _              | Stays OFF | (When 1 or 2 remote controllers are connected) |




Note: If any error is detected 30 minutes after displaying "WAIT" on the remote controller, the display changes to "INSPECT I/U".

|   |                                |         |                |           | M   | 4 |
|---|--------------------------------|---------|----------------|-----------|---|---|
| F | Error code                     | LED     | Green          | Red       | Content   |   |
|   | Remote controller: INSPECT I/U | Indoor  | Keeps flashing | Stays OFF | INSPECT I/U                                       |   |
|   |                                | Outdoor | -              | Stays OFF | (Connection of 3 units or more remote controller) | J |




Note: If any error is detected 30 minutes after displaying "WAIT" on the remote controller, the display changes to "INSPECT I/U".







matters related to connection) When the power supply is reset after the occurrence of E5, the LED will display " @WAIT @" if the anomaly continues. If the breaker ON/OFF is repeated in a short period of time (within 1 minute), " @WAIT @" may be displayed. In such occasion, turn the breaker off and wait for 3 minutes.

|   |   |                          |         |                |           |                           | D |
|---|---|--------------------------|---------|----------------|-----------|---------------------------|---|
| F | 9 | Error code               | LED     | Green          | Red       | Content                   |   |
|   |   | Remote controller: "WAIT | Indoor  | Keeps flashing | Stays OFF |                           |   |
|   |   |                          | Outdoor | -              | Stays OFF | initial operation $(2/3)$ | J |
| l | J |                          |         |                |           |                           | - |














Note: If the indoor unit cannot communicate normally with the remote controller for 180 seconds, the indoor contnrol PCB starts to reset automatically.























Note: During heating operation; After starting compressor, compressor rotation speed is decreased by detecting indoor heat exchanger temperature (ThI-R) in order to control high pressure.






Note: When this error occurred at power ON, disconnection of wire or connector of the float switch is suspected. Check and correct it (or replace it, if necessary).


| ſ | Error code             | LED     | Green          | Red       | Content Excessive number of connected     |
|---|------------------------|---------|----------------|-----------|---|
|   | Remote controller: E10 | Indoor  | Keeps flashing | Stays OFF |   |
|   |                        | Outdoor | -              | Stays OFF | by controlling with one remoto controller |




| _ |                        |         |                |              | G                        | ) |
|---|------------------------|---------|----------------|--------------|--------------------------|---|
| ſ | Error code             | LED     | Green          | Red          | Content                  |   |
|   | Remote controller: E16 | Indoor  | Keeps flashing | 1 time flash | Indoor fan motor anomaly |   |
|   |                        | Outdoor | _              | Stays OFF    | (FDTC and FDUM series)   | J |
| L |                        |         |                |              |                          |   |








|   |                        |         |                |              | Q                                 |
|---|------------------------|---------|----------------|--------------|-----------------------------------|
| F | Error code             | LED     | Green          | Red          | Content Indoor fan motor rotation |
|   | Remote controller: E20 | Indoor  | Keeps flashing | 1 time flash | speed anomaly                     |
|   |                        | Outdoor | Keeps flashing | Stays OFF    | (FDTC and FDUM series)            |
| l |                        |         |                |              |                                   |



M


| ſ | Error code             | LED     | Green          | Red       | Content                        |
|---|------------------------|---------|----------------|-----------|--------------------------------|
|   | Remote controller: E28 | Indoor  | Keeps flashing | Stays OFF |                                |
|   |                        | Outdoor | -              | Stays OFF | temperature thermistor anomaly |
| L | J                      |         |                |           |                                |




Note: After 10 seconds has passed since remote controller thermistor was switched from valid to invalid, E28 will not be displayed even if the thermistor harness is disconnected. At same time the thermistor, which is effective, is switched from remote controller thermistor to indoor return air temperature thermistor. Even though the remote controller thermistor is set to be Effective, the return air temperature displayed on remote controller for checking still shows the value detected by indoor return air temperature thermistor, not by remote controller temperature thermistor.

M


| β | 7[ | Error code             | LED     | Green          | Red           | Content                           |
|---|----|------------------------|---------|----------------|---------------|-----------------------------------|
|   |    | Remote controller: E35 | Indoor  | Keeps flashing | Stays OFF     | Cooling high pressure operation   |
|   |    |                        | Outdoor | _              | 2 times flash | (Model SCM40, 45, 50, 60, 71, 80) |





| _ |                        |         |                |               | Q                   |
|---|------------------------|---------|----------------|---------------|---------------------|
| β | Error code             | LED     | Green          | Red           | Content             |
|   | Remote controller: E35 | Indoor  | Keeps flashing | Stays OFF     |                     |
|   |                        | Outdoor | -              | 2 times flash | (Model SCM100, 125) |
|   | <u></u>                |         |                |               |                     |





| F | Error code             | LED     | Green          | Red           | Content                          |
|---|------------------------|---------|----------------|---------------|----------------------------------|
|   | Remote controller: E36 | Indoor  | Keeps flashing | Stays OFF     | Discharge pipe temperature error |
|   |                        | Outdoor | _              | 5 times flash | Disenarge pipe temperature error |














| F | Error | code              | LED     | Green          | Red           | Content                         |  |
|---|-------|-------------------|---------|----------------|---------------|---------------------------------|--|
|   | Remot | e controller: E40 | Indoor  | Keeps flashing | Stays OFF     | Heating high pressure operation |  |
|   |       |                   | Outdoor | -              | 2 times flash | (Model SCM100, 125)             |  |





| _ |                        |         |                |              |                           | Ð |
|---|------------------------|---------|----------------|--------------|---------------------------|---|
| μ | Error code             | LED     | Green          | Red          | Content                   |   |
|   | Remote controller: E41 | Indoor  | Keeps flashing | Stays OFF    | Power transistor overheat |   |
|   |                        | Outdoor | _              | 1 time flash | (Model SCM100, 125)       |   |
| L | J                      |         |                |              |                           |   |































Note: When E48 error occurs, in almost cases F3 (SCM100, 125: F4) fuse on the outdoor main (control) PCB is blown. There are a lot of cases that fuse is blown and E48 occurs due to defective fan motor. And even though only the outdoor main (control) PCB ( or fuse) is replaced,, another trouble could occur. Therefore when fuse is blown, check whether the fan motor is OK or not. After confirming the fan motor normal, check by power ON. (Don't power ON without confirming the fan motor normal.)


|   |                        | -       |                |              | <u> </u>                          |
|---|------------------------|---------|----------------|--------------|-----------------------------------|
| ſ | Error code             | LED     | Green          | Red          | Content                           |
|   | Remote controller: E51 | Indoor  | Keeps flashing | Stays OFF    | Power transistor anomaly          |
|   |                        | Outdoor | _              | 1 time flash | (Model SCM40, 45, 50, 60, 71, 80) |




| _ |                        |         |                |              |                     | Ð |
|---|------------------------|---------|----------------|--------------|---------------------|---|
| β | Error code             | LED     | Green          | Red          | Content             |   |
|   | Remote controller: E51 | Indoor  | Keeps flashing | Stays OFF    |                     |   |
|   |                        | Outdoor | _              | 1 time flash | (Model SCM100, 125) |   |
| L |                        |         |                |              |                     |   |



















Note

G

| P | Error code             | LED     | Green          | Red           | Content                           |
|---|------------------------|---------|----------------|---------------|-----------------------------------|
|   | Remote controller: E58 | Indoor  | Keeps flashing | Stays OFF     | Current safe stop                 |
|   |                        | Outdoor | -              | 3 times flash | (Model SCM40, 45, 50, 60, 71, 80) |
| L | J                      |         |                |               |                                   |








Note: Insulation resistance

The unit is left for long period without power supply or soon after installation, migrated liquid refrigerant may dissolve in the refrigerant oil in the compressor. In such case insulation resistance decreases upto several M $\Omega$  or lower. If the electric leakage breaker is activated due to low insulation resistance, check followings. ① Check whether the electric leakage breake conforms to high-hermonic specifications


(As units has inverter, in order to prevent from improper operation, be sure to use high-hermonic one.)

M

| ſ | Error code             | LED     | Green          | Red           | Content                           |
|---|------------------------|---------|----------------|---------------|-----------------------------------|
|   | Remote controller: E60 | Indoor  | Keeps flashing | Stays OFF     | 1                                 |
|   |                        | Outdoor | -              | 7 times flash | (Model SCM40, 45, 50, 60, 71, 80) |
|   |                        |         |                |               |                                   |



- Note: Insulation resistance
  - The unit is left for long period without power supply or soon after installation, migrated liquid refrigerant may dissolve in the refrigerant oil in the compressor. In such case insulation resistance decreases upto several MQ or lower. If the electric leakage breaker is activated due to low insulation resistance, check followings.
  - Other whether the electric leakage breaks upon soften into the intermonic specifications (As units has inverter, in order to prevent from improper operation, be sure to use high-hermonic one.)



1


# Meaning of Marks

| Mark | Color                | Mark  | Color  |
|------|----------------------|---|--|
| BK   | Black                | YE  | Yellow   |
| RD   | Red                  | Y∕G   | Yellow/Green   |
| WH   | White                |   |  |
| OR   | Orange               |   |  |
| BR   | Brown                |   |  |
|      |                      |   |  |
|      | BK<br>RD<br>WH<br>OR | BK Black<br>RD Red<br>WH White<br>OR Orange | BK         Black         YE           RD         Red         Y/G           WH         White            OR         Orange |

| Item        | Description              | Item    | Description                 |
|-------------|--------------------------|---------|-----------------------------|
| CNA-CN20S   | Connector                | R       | Reactor                     |
| 20S         | 4 Way valve (coil)       | TB1-TB3 | Terminal block              |
| CM          | Compressor motor         | Tho-R   | Heat exchanger sensor       |
| EEV A,EEV B | Electric expansion valve |         | (outdoor unit)              |
|             | (coil)                   | Tho-A   | Outdoor air temp. sensor    |
| FMo         | Fan motor                | Tho-D   | Discharge pipe temp. sensor |
| HEATER      | Crank case heater        | Tho-S   | Suction pipe temp. sensor   |

3 ELECTRICAL WIRINGS 3.1 Outdoor units

'11 • SCM-SM-110



RWC000Z252

- 138

1


Color Marks

## Meaning of Marks

|   | Mark | Color  | Mark | Color        |   |
|---|------|--------|------|--------------|---|
|   | BK   | Black  | BR   | Brown        | C |
| 1 | BL   | Blue   | YE   | Yellow       |   |
|   | RD   | Red    | Y⁄G  | Yellow/Green |   |
|   | WH   | White  |      |              | E |
|   | OR   | Orange |      |              |   |
|   |      |        |      |              |   |

| Item        | Description              | Item    | Description                 |
|-------------|--------------------------|---------|-----------------------------|
| CNA-CN20S   | Connector                | R       | Reactor                     |
| 20S         | 4 Way valve (coil)       | TB1,TB2 | Terminal block              |
| CM          | Compressor motor         | Tho-R   | Heat exchanger sensor       |
| EEV A,EEV B | Electric expansion valve |         | (outdoor unit)              |
| EEV C       | (coil)                   | Tho-A   | Outdoor air temp. sensor    |
| FMo         | Fan motor                | Tho-D   | Discharge pipe temp. sensor |
| HEATER      | Crank case heater        | Tho-S   | Suction pipe temp. sensor   |

'11 • SCM-SM-110



RWC000Z250


## Meaning of Marks

| Mark | Color  | Mark | Color        |
|------|--------|------|--------------|
| BK   | Black  | RD   | Red          |
| BL   | Blue   | WH   | White        |
| BR   | Brown  | YE   | Yellow       |
| GN   | Green  | Y/G  | Yellow/Green |
| OR   | Orange |      |              |

| mouning     |                          |       |                             |
|-------------|--------------------------|-------|-----------------------------|
| ltem        | Description              | Item  | Description                 |
| CNA-CN20S   | Connector                | R     | Reactor                     |
| 20S         | 4 Way valve (coil)       | TB1~5 | Terminal block              |
| CM          | Compressor motor         | Tho-R | Heat exchanger sensor       |
| EEV A,EEV B | Electric expansion valve |       | (outdoor unit)              |
| EEV C,EEV D | (coil)                   | Tho-A | Outdoor air temp. sensor    |
| FMo         | Fan motor                | Tho-D | Discharge pipe temp. sensor |
| HEATER      | Crank case heater        | Tho-S | Suction pipe temp. sensor   |

139 -

1



| Mark                | Name   |  |
|---------------------|--|--|
| A/F MODULE          | Active filter module                                     |  |
| CH Crankcase heater |  |  |
| CM                  | Compressor motor   |  |
| CNA~Z               | Connector  |  |
| CT                  | Current sensor   |  |
| DS                  | Diode stack  |  |
| EEV                 | Electronic expansion coil                                |  |
| EEV-H               | Electronic expansion coil (For heating)                  |  |
| F                   | Fuse   |  |
| FM                  | Fan motor  |  |
| HPS                 | High pressure sensor                                     |  |
| IPM                 | Intelligent power module                                 |  |
| L                   | Reactor  |  |
| LED1                | Indicator lamp (Red-Inspection indicator)                |  |
| LED2                | Indicator lamp (Green-Microcomputer normality indicator) |  |
| LED3                | Indicator lamp (Green-For service)                       |  |
| TB                  | Terminal block   |  |
| Tho-A               | Thermistor (outdoor air temperature)                     |  |
| Tho-D               | Thermistor (discharge pipe)                              |  |
| Tho-R               | Thermistor (heat exchanger)                              |  |
| Tho-S               | Thermistor (suction pipe)                                |  |
| Tho-AF              | Thermistor (power transistor)                            |  |
| TR                  | Trance former  |  |
| 20S                 | 4-way valve coil   |  |

Model SCM100ZJ-S1

| Mark | Color        |
|------|--------------|
| BK   | Black        |
| BL   | Blue         |
| BR   | Brown        |
| GN   | Green        |
| OR   | Orange       |
| PK   | Pink         |
| RD   | Red          |
| WH   | White        |
| Y    | Yellow       |
| Y⁄G  | Yellow/Green |

tory

1.Instructions for correct operation

- O Before you turn on power, please carefully read the installation manual and the operation manual supplied with the unit.
- O Please check the following points before operation.
- ① This unit is designed exclusively for use with R410A. Do not use any refrigerant other than R410A.
- (2) To protect the compressor, turn on power for the air conditioner 6 hours before operation so as warm up sufficiently the dome temperature of compressor.
- (3) Open the service values of liquid pipe at first. Secondarily open the one of gas pipe. Before you operate the unit, make sure again that the service valves are in open position.
- ④ Please note that the pressure valves detected at the charge port in the unit and the gas service valves are different during the cooling operation and the heating operation. High pressure is replaced with the low pressure depending on whether it is in the cooling or heating operation.

| NDICATION LAMP | COLOR                    | FUNCTION       |  |
|----------------|--------------------------|----------------|--|
| LED E (1)      | RED                      | WARNING LAMP   |  |
| SELF DIAGN     | IOSIS FUNCTION BY LE     | ED E           |  |
| 1 TIME FLASH   | CURRENT CUT              |                |  |
| 2 TIME FLASH   | TROUBLE OF OUTDO         | DOR UNIT       |  |
| 3 TIME FLASH   | OVER CURRENT             |                |  |
| 4 TIME FLASH   | FLASH TRANSMISSION ERROR |                |  |
| 5 TIME FLASH   | OVER HEAT OF COMPRESSOR  |                |  |
| 6 TIME FLASH   | ERROR OF SIGNAL T        | RANSMISSION    |  |
| 8 TIME FLASH   | SENSOR ERROR             |                |  |
|                | (EXCEPT DISCHARG         | E PIPE SENSOR) |  |
| LIGHT ON       | OUTDOOR FAN MOT          | OR FRROR       |  |

DISCHARGE PIPE SENSOR ERROR

### 2.Error indication

FOUR SEC LIGHT


AND

FOUR SEC OFF

IN

| used on | ly at o | our fact |
|---------|---------|----------|
|---------|---------|----------|

RWC000Z247



2.Error indication

| Mark       | Name   |  |
|------------|--|--|
| A/F MODULE | Active filter module                                     |  |
| CH         | Crankcase heater   |  |
| CM         | Compressor motor   |  |
| CNA~Z      | Connector  |  |
| CT         | Current sensor   |  |
| DS         | Diode stack  |  |
| EEV        | Electronic expansion coil                                |  |
| EEV-H      | Electronic expansion coil (For heating)                  |  |
| F          | Fuse   |  |
| FM         | Fan motor  |  |
| HPS        | High pressure sensor                                     |  |
| IPM        | Intelligent power module                                 |  |
| L          | Reactor  |  |
| LED1       | Indicator lamp (Red-Inspection indicator)                |  |
| LED2       | Indicator lamp (Green-Microcomputer normality indicator) |  |
| LED3       | Indicator lamp (Green-For service)                       |  |
| TB         | Terminal block   |  |
| Tho-A      | Thermistor (outdoor air temperature)                     |  |
| Tho-D      | Thermistor (discharge pipe)                              |  |
| Tho-R      | Thermistor (heat exchanger)                              |  |
| Tho-S      | Thermistor (suction pipe)                                |  |
| Tho-AF     | Thermistor (power transistor)                            |  |
| TR         | Trance former  |  |
| 20S        | 4-way valve coil   |  |

Model SCM125ZJ-S1


| Mark | Color        |
|------|--------------|
| BK   | Black        |
| BL   | Blue         |
| BR   | Brown        |
| GN   | Green        |
| OR   | Orange       |
| PK   | Pink         |
| RD   | Red          |
| WH   | White        |
| Y    | Yellow       |
| Y⁄G  | Yellow/Green |

used only at our factory

1.Instructions for correct operation

- O Before you turn on power, please carefully read the installation manual and the operation manual supplied with the unit.
- O Please check the following points before operation.
- ① This unit is designed exclusively for use with R410A. Do not use any refrigerant other than R410A.
- (2) To protect the compressor, turn on power for the air conditioner 6 hours before operation so as warm up sufficiently the dome temperature of compressor.
- 3 Open the service valves of liquid pipe at first. Secondarily open the one of gas pipe. Before you operate the unit, make sure again that the service valves are in open position.
- ④ Please note that the pressure valves detected at the charge port in the unit and the gas service valves are different during the cooling operation and the heating operation. High pressure is replaced with the low pressure depending on whether it is in the cooling or heating operation.


| INDICATION LAMP                  | COLOR                        | FUNCTION       |  |  |
|----------------------------------|------------------------------|----------------|--|--|
|                                  |                              | WARNING LAMP   |  |  |
| LED E (1)                        | RED                          |                |  |  |
| SELF DIAGNOSIS FUNCTION BY LED E |                              |                |  |  |
| 1 TIME FLASH                     | CURRENT CUT                  |                |  |  |
| 2 TIME FLASH                     | TROUBLE OF OUTDOOR UNIT      |                |  |  |
| 3 TIME FLASH                     | OVER CURRENT                 |                |  |  |
| 4 TIME FLASH                     | TRANSMISSION ERROR           |                |  |  |
| 5 TIME FLASH                     | OVER HEAT OF COMPRESSOR      |                |  |  |
| 6 TIME FLASH                     | ERROR OF SIGNAL TRANSMISSION |                |  |  |
| 8 TIME FLASH                     | SENSOR ERROR                 |                |  |  |
|                                  | (EXCEPT DISCHARG             | E PIPE SENSOR) |  |  |
| LIGHT ON                         | OUTDOOR FAN MOTOR ERROR      |                |  |  |
| FOUR SEC LIGHT                   |                              |                |  |  |
| AND                              | DISCHARGE PIPE SE            | NSOR ERROR     |  |  |
| FOUR SEC OFF                     |                              |                |  |  |



| Item    | Description       |
|---------|-------------------|
| CNE-CNY | Connector         |
| FM      | Fan motor         |
| SM1,2   | Flap motor        |
| LM1,2   | Louver motor      |
| IM      | Inlet motor       |
| Th1     | Room temp. sensor |
| Th2 1,2 | Heat exch. sensor |
| LS      | Limit switch      |
| DS      | Diode stack       |
| F       | Fuse              |
| Т       | Terminal block    |
| Va      | Varistor          |

# 3.2 Indoor units (1) Wall mounted type (SRK) Models SRK20ZJX-S, 25ZJX-S, 35ZJX-S


| Color Marks |              |  |
|-------------|--------------|--|
| Mark        | Color        |  |
| BK          | Black        |  |
| BL          | Blue         |  |
| RD          | Red          |  |
| WH          | White        |  |
| Y           | Yellow       |  |
| Y⁄G         | Yellow/Green |  |



Models SRK50ZJX-S1, 60ZJX-S1

'11 • SCM-SM-110

RWA000Z236




| Item              | Description       |  |  |  |  |  |
|-------------------|-------------------|--|--|--|--|--|
| CNE-CNY           | Connector         |  |  |  |  |  |
| FM                | Fan motor         |  |  |  |  |  |
| SM                | Flap motor        |  |  |  |  |  |
| LM1,2             | Louver motor      |  |  |  |  |  |
| HD                | Humidity sensor   |  |  |  |  |  |
| Thi               | Room temp. sensor |  |  |  |  |  |
| Th <sub>2,3</sub> | Heat exch. sensor |  |  |  |  |  |
| DS                | Diode stack       |  |  |  |  |  |
| F                 | Fuse              |  |  |  |  |  |
| Т                 | Terminal block    |  |  |  |  |  |
| Va                | Varistor          |  |  |  |  |  |

| Mark | Color        |
|------|--------------|
| BK   | Black        |
| BL   | Blue         |
| RD   | Red          |
| WH   | White        |
| Y    | Yellow       |
| Y/G  | Yellow/Green |

Models SRK25ZJR-S, 35ZJR-S, 20ZJ-S, 25ZJ-S, 35ZJ-S, 50ZJ-S

RWA000Z226 🛕




| Item     | Description       |  |  |  |  |  |  |
|----------|-------------------|--|--|--|--|--|--|
| CNE-CNX2 | Connector         |  |  |  |  |  |  |
| FMI      | Fan motor         |  |  |  |  |  |  |
| SM1      | Flap motor        |  |  |  |  |  |  |
| LM1,2    | Louver motor      |  |  |  |  |  |  |
| Th1      | Room temp. sensor |  |  |  |  |  |  |
| Th21,2   | Heat exch. sensor |  |  |  |  |  |  |
| Th3      | Humidity sensor   |  |  |  |  |  |  |
| DS       | Diode stack       |  |  |  |  |  |  |
| F        | Fuse              |  |  |  |  |  |  |
| Т        | Terminal block    |  |  |  |  |  |  |
| Va       | Varistor          |  |  |  |  |  |  |

| 5        |
|----------|
| ō        |
| Q        |
| <u>@</u> |
|          |
| S        |
| Л        |
|          |
| x        |
| 2.1      |
| $\sim$   |
| <u> </u> |
| Ν        |
|          |
| $\sim$   |
| 1 I I I  |
| (n       |
| ~        |

| Color Marks |              |  |  |  |
|-------------|--------------|--|--|--|
| Mark        | Color        |  |  |  |
| BK          | Black        |  |  |  |
| BL          | Blue         |  |  |  |
| RD          | Red          |  |  |  |
| WH          | White        |  |  |  |
| Y           | Yellow       |  |  |  |
| Y/G         | Yellow/Green |  |  |  |


RWA000Z400



| Item            | Description       |  |  |  |  |  |  |
|-----------------|-------------------|--|--|--|--|--|--|
| CNE-CNX2        | Connector         |  |  |  |  |  |  |
| FM              | Fan motor         |  |  |  |  |  |  |
| SM1,2           | Flap motor        |  |  |  |  |  |  |
| DM1             | Damper motor      |  |  |  |  |  |  |
| DM <sub>2</sub> | Damper arm motor  |  |  |  |  |  |  |
| Th1             | Room temp. sensor |  |  |  |  |  |  |
| Th2 1,2         | Heat exch. sensor |  |  |  |  |  |  |
| Th3             | Humidity sensor   |  |  |  |  |  |  |
| DS              | Diode stack       |  |  |  |  |  |  |
| F               | Fuse              |  |  |  |  |  |  |
| Т               | Terminal block    |  |  |  |  |  |  |
| Va              | Varistor          |  |  |  |  |  |  |


(2) Floor standing type (SRF) Models SRF25ZJX-S, 35ZJX-S

| Color Marks |              |  |  |  |
|-------------|--------------|--|--|--|
| Mark        | Color        |  |  |  |
| BK          | Black        |  |  |  |
| BL          | Blue         |  |  |  |
| RD          | Red          |  |  |  |
| WH          | White        |  |  |  |
| YE          | Yellow       |  |  |  |
| Y⁄G         | Yellow/Green |  |  |  |



| Item     | Description       |  |  |  |  |  |  |
|----------|-------------------|--|--|--|--|--|--|
| CNE-CNX2 | Connector         |  |  |  |  |  |  |
| FM       | Fan motor         |  |  |  |  |  |  |
| SM1,2    | Flap motor        |  |  |  |  |  |  |
| DM1      | Damper motor      |  |  |  |  |  |  |
| DM2      | Damper arm motor  |  |  |  |  |  |  |
| Th1      | Room temp. sensor |  |  |  |  |  |  |
| Th2 1,2  | Heat exch. sensor |  |  |  |  |  |  |
| Th3      | Humidity sensor   |  |  |  |  |  |  |
| DS       | Diode stack       |  |  |  |  |  |  |
| F        | Fuse              |  |  |  |  |  |  |
| Т        | Terminal block    |  |  |  |  |  |  |
| Va       | Varistor          |  |  |  |  |  |  |

| Color | Marks        |  |  |  |
|-------|--------------|--|--|--|
| Mark  | Color        |  |  |  |
| BK    | Black        |  |  |  |
| BL    | Blue         |  |  |  |
| RD    | Red          |  |  |  |
| WH    | White        |  |  |  |
| Y     | Yellow       |  |  |  |
| Y/G   | Yellow/Green |  |  |  |



(3) Ceiling concealed type (SRR) Models SRR25ZJ-S, 35ZJ-S, 50ZJ-S, 60ZJ-S

1 phase 220 - 240 V 50Hz

TO OUTDOOR UNIT




## Meaning of Marks

| Mark | Color  | Mark | Color        | ltem    | Description  | Item | Description         |
|------|--------|------|--------------|---------|--------------|------|---------------------|
| BK   | Black  | YE   | Yellow       | CNE-CNY | Connector    | Th1  | Room temp. sensor   |
| BL   | Blue   | Y⁄G  | Yellow/Green | F       | Fuse         | Th2  | Heat exch. sensor 1 |
| OR   | Orange |      |              | FΜι     | Fan motor    | Th3  | Heat exch. sensor 2 |
| RD   | Red    |      |              | DM      | Drain motor  | Т    | Terminal block      |
| WH   | White  |      |              | FS      | Float Switch | Va   | Varistor            |


Power source

|          |                          |       |                                       |            |                                      | COIC |
|----------|--------------------------|-------|---------------------------------------|------------|--------------------------------------|------|
| CNB~Z    | Connector                | LED•3 | Indication lamp (Red-Inspection)      | TB1        | Terminal block (Power source)        | Ма   |
| DM       | Drain motor              | LM1~4 | Louver motor                          |            | ( mark)                              | В    |
| F200~203 | Fuse                     | SW2   | Remote controller communication       | TB2        | Terminal block (Signal line) ( mark) | В    |
| FM       | Fan motor                |       | address                               | Thc        | Thermistor (Remote controller)       | BF   |
| FS       | Float switch             | SW5   | Plural units Master / Slave setting   | Thi-A      | Thermistor(Return air)               | 0    |
| LED·2    | Indication lamp          | SW6   | Model capacity setting                | Thi-R1,2,3 | Thermistor(Heat exchanger)           | R    |
|          | (Green-Normal operation) | SW7-1 | Operation check, Drain motor test run | Х4         | Relay for DM                         | W    |
|          |                          |       |                                       | mark       | Closed-end connector                 | Y    |



4


Ceiling cassette-4way compact type (FDTC)



inside unit and outside unit.

4. Use twin core cable (0.3mm<sup>2</sup>X2) at remote controller line. See spec sheet of remote controller in case that the total length is more than 100m. 5. Do not put remote controller line alongside power source line.

'11 • SCM-SM-110



| CFI 1       | Capacitor for FMI                        |  |  |  |  |
|-------------|--|--|--|--|--|
| CNB~Z       | Connector                                |  |  |  |  |
| F           | Fuse                                     |  |  |  |  |
| FMI 1       | Fan motor (with thermostat)              |  |  |  |  |
| LED•2       | Indication lamp (Green-Normal operation) |  |  |  |  |
| LED•3       | Indication lamp (Red-Inspection)         |  |  |  |  |
| LM          | Louver motor                             |  |  |  |  |
| SW2         | Remote controller communication address  |  |  |  |  |
| SW5         | Plural units Master / Slave setting      |  |  |  |  |
| SW6         | Model capacity setting                   |  |  |  |  |
| SW7-1       | Operation check, Drain motor test run    |  |  |  |  |
| TB1         | Terminal block (Power source) (Dmark)    |  |  |  |  |
| TB2         | Terminal block (Signal line) ( mark)     |  |  |  |  |
| Thc         | Thermistor (Remote controller)           |  |  |  |  |
| ThI -A      | Thermistor (Return air)                  |  |  |  |  |
| Thl -R1,2,3 | Thermistor (Heat exchanger)              |  |  |  |  |
| Trl         | Transformer                              |  |  |  |  |
| X1~3,6      | Relay for FM                             |  |  |  |  |
| Х4          | Relay for DM                             |  |  |  |  |

3. Use twin core cable (0.3mm<sup>2</sup>) at remote controller line. (Refer to page 30)

of remote controller in case that the total length is more than 100m.

4. Do not put remote controller line alongside power source line.

| Color Mark | S      |      |              |
|------------|--------|------|--------------|
| Mark       | Color  | Mark | Color        |
| BK         | Black  | RD   | Red          |
| BL         | Blue   | WH   | White        |
| BR         | Brown  | Y    | Yellow       |
| OR         | Orange | Y/GN | Yellow/Green |
| Р          | Pink   |      |              |

not be able to make any indication.

1 150

1

PFA003Z819  $\bowtie$ 

|                               |                    |                          |                                  |            |            |                                     |   | 0.01              |                 |               |                        |
|-------------------------------|--------------------|--------------------------|----------------------------------|------------|------------|-------------------------------------|---|-------------------|-----------------|---------------|------------------------|
|                               |                    |                          |                                  |            |            |                                     |   | F1~3              | Fuse            |               |                        |
|                               |                    |                          |                                  |            |            |                                     |   | FM <sub>1</sub> 1 | Fan motor (     | (with thermc  | ostat)                 |
|                               |                    |                          |                                  |            |            |                                     |   | FS                | Float switch    | 1             |                        |
|                               |                    | Remote controller<br>Thc |                                  | Contro     | I PCB      | 1                                   |   | L                 | Reactor         |               |                        |
|                               |                    |                          |                                  |            |            | CNN <sup>2</sup>                    | Th⊦R1   | LED · E2          | Indication I    | amp (Greer    | -Normal operation)     |
|                               |                    | t° Y                     |                                  | vn         |            | V 3                                 | Y Th-R2   | LED · E3          | Indication I    | amp (Red-Ir   | nspection)             |
| L                             |                    |                          | TB2                              |            | D•E2 LED•E | 3 4                                 | Ý <u>···</u>                                      | SW2               | Remote co       | ntroller com  | munication address     |
| Connecting line between CNWR2 | Y/GN T 1 WH        |                          | Power PCB                        | -          | Ĥ K        | 5                                   | ten Thi-R3  | SW5               | Plural units    | Master/Slav   | ve setting             |
| indoor unit and outdoor unit  | RD 3 F1 (3.15A)    | Deven sinovit            |                                  |            | SW2        | 6                                   |   | SW6               | Model capa      | acity setting |                        |
|                               | WH 5<br>F2 (3.15A) | Power circuit            | CNW1 <sup>3</sup> / <sub>5</sub> |            |            | 1                                   |   | SW7-1             | Operation       | check, Drair  | n motor test run       |
|                               |                    |                          | WH 6 V                           | 5 WH       |            | CNH bK 2                            | BK to Thi-A                                       | TB1               | Terminal bl     | ock (Powerr   | ce) (□mark)            |
| Earth D TB1                   | BL 3 WH            |                          | 8 V<br>9 V                       | H 8<br>H 0 | SW5        | -                                   |   | TB2               | Terminal bl     | ock (Signal   | line) ( 🗆 mark)        |
|                               |                    |                          | 10 V<br>11 V<br>12 V             | 1 11       | SW6        | CNI <sup>1</sup>                    | RD FS   | Thc               | Thermistor      | (Remote co    | ntroller)              |
|                               | F3<br>(2A)         |                          | 12                               | 12         | SW7        | BL 2                                | RD  | ThI-A             | Thermistor      | (Return air)  |                        |
|                               |                    |                          |                                  |            |            |                                     |   | ThI-R1,2,3        | Thermistor      | (Heat excha   | anger)                 |
|                               |                    |                          |                                  |            | For HA     | CNR <sup>1</sup>                    | WH M  | ■ mark            | Closed-end      | d connector   |                        |
|                               | HD BK WH Y BL (    | CNM1<br>WH               |                                  |            | CNZ WH     | WH 2                                |   |                   |                 |               |                        |
|                               |                    |                          |                                  |            |            | +12 1                               |   | Color Marks       |                 |               |                        |
|                               | FM 1               |                          |                                  |            |            | 2                                   | XR1+ (Operation)                                  | Mark              | Color           | Mark          | Color                  |
|                               |                    |                          |                                  |            |            | CNT <sup>3</sup><br>BL <sup>4</sup> | XR3+(Heating)<br>XR3+(Compressor ON)              |                   | Black           | RD            | Red                    |
|                               |                    |                          |                                  |            | CNTA<br>BL | 5                                   | (XR4 - + (Inspection)                             |                   | Blue            | WH            | White                  |
|                               |                    |                          |                                  |            | 1 2        |                                     | XR5 (Remote operation<br>input:volt-free contact) | BR                | Brown<br>Orange | Y<br>Y/GN     | Yellow<br>Yellow/Green |
|                               |                    |                          |                                  |            |            |                                     |   | I OH I            | Ulange          | T/GIN I       | reliuw/dreen           |

1

(6)

Model FDUM50VF

CNB~Z


DM


Connector

Drain motor


- Notes 1.---- indicates wiring on site.
  2. See the wiring diagram of outside unit about the line between inside unit and outside unit.
  3. Use twin core cable (0.3mm<sup>2</sup> X2) at remote controller line. See spec sheet of remote controller in case that the total length is more than 100m.
  4. Do not put remote controller line alongside power source line.

'11 • SCM-SM-110







- 153 -



- 154 -



1



## 5. INSTALLATION MANUAL 5.1 Outdoor units

(1) Models SCM40ZJ-S, 45ZJ-S

RPC012A915A MULTI TYPE AIR CONDITIONER

R410A REFRIGERANT USED

• This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 173 to 198. • When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

## SAFETY PRECAUTIONS


- work in order to protect yourself. The precautionary items mentioned below are distinguished into two levels, A WARNING and For installing qualified personnel, take precautions in respect to themselves by using suitable

CAUTION . WARNING : Wrong installation would cause serious consequences such as injuries or death. ACAUTION : Wrong installation might cause serious consequences depending on circumstances.

Both mentions the important items to protect your health and safety so strictly follow them by any means.

- · Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation Keep the installation manual together with owner's manual at a place where any user can read
  - protective clothing, groves, etc., and then perform the installation works. Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
  - If unusual noise can be heard during operation, consult the deale The meanings of "Marks" used here are shown as follows:





| <ul> <li>below.</li> <li>Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.</li> <li>Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.</li> <li>Locations where vibration can be amplified and transmitted due to insufficient strength of structure.</li> <li>Locations where vibration and operation sound generated by the outdoor unit can affect by high harmonics.</li> <li>Locations where a ded rom).</li> <li>Locations where a ded rom).</li> <li>Locations where drainage cannot run off safely.</li> </ul>  |   |  |  |
|---|---|--|--|
| of combustible gases can occur.<br>If leaked gases accumulate around the unit, it can cause fire.<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not install the unit where corrosive gas (such as<br>• Do not use the unit for special purposes such as | <ul> <li>below.</li> <li>Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.</li> <li>Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.</li> <li>Locations where vibration can be amplified and transmitted due to insufficient strength of structure.</li> <li>Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).</li> <li>Locations where varianage cannot run off safely. It can affect surrounding environment and cause a claim.</li> <li>Do not install the unit near the location where leakage of combustible gases acound the unit, it can cause fire.</li> </ul> | <ul> <li>Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.</li> <li>Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.</li> <li>Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.</li> <li>Do not install the outdoor unit in a location where insects and small animals can inhabit.</li> <li>Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.</li> <li>Do not use the base flame for outdoor unit which is</li> </ul> | Connecting the circuit with copper wire or other metal<br>thread can cause unit failure and fire.<br>• Do not touch any buttons with wet hands.<br>It can cause electric shocks.<br>• Do not touch any refrigerant pipes with your hands<br>when the system is in operation.<br>During operation the refrigerant pipes become extremely hot<br>or extremely cold depending the operating condition, and it<br>can cause burn injury or frost injury.<br>• Do not touch the suction or aluminum fin on the<br>outdoor unit.<br>This may cause injury.<br>• Do not put anything on the outdoor unit and operating<br>unit.<br>This may cause damage the objects or injury due to falling<br>to the object. |

thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances

Using an old and damage base flame can cause the unit

falling down and cause personal injury

- preservation of animals, plants or art.
- Do not clean up the unit with water

#### Check before installation work

|   | <u>ں</u>        | Option porto                      | Q'ty |                      | Necessary tools for the installation work   | 9   | Wrench key (Hexagon) [4m/m]                         |
|---|-----------------|-----------------------------------|------|----------------------|---|-----|---|
| <ul><li>Model name and power source</li><li>Refrigerant piping length</li></ul> |                 | Option parts                      |      |                      | Necessary loois for the installation work   | 10  | Vacuum pump   |
|   |                 | <ul> <li>Sealing plate</li> </ul> | 1    | 1 Plus headed driver |   | 11  | Vacuum pump adapter (Anti-reverse flow type)        |
| <ul> <li>Piping, wiring and miscellaneous small particular</li> </ul>           | arts            | 6 Sleeve                          | 1    | 2                    | Knife                                       | 1'' | (Designed specifically for R410A)                   |
| <ul> <li>Indoor unit installation manual</li> </ul>                             |                 | C Inclination plate               | 1    | 3                    | Saw   | 12  | Gauge manifold (Designed specifically for R410A)    |
|   |                 | Putty                             | 1    | 4                    | Tape measure                                | 13  | Charge hose (Designed specifically for R410A)       |
| Accessories for outdoor unit Q'i  |                 | Drain hose (extension<br>hose)    | 1    | 5                    | Hammer                                      | 14  | Flaring tool set (Designed specifically for R410A)  |
| Accessories for outdoor unit  | <sup>y</sup> ty | hose)                             |      | 6                    |   |     | Gas leak detector (Designed specifically for R410A) |
| Grommet (Heat pump type only)   | 1               | Piping cover (for insulation      | 1    | 7                    | Torque wrench [14.0~62.0N·m (1.4~6.2kgf·m)] | 16  | Gauge for projection adjustment (Used when flare is |
| Drain elbow (Heat pump type only) 1   |                 | of connection piping)             |      | 8                    | Hole core drill (65mm in diameter)          | 1'0 | made by using conventional flare tool)              |

## SELECTION OF INSTALLATION LOCATION

#### Install at location that meets the following conditions after getting approval from the customer.

- Where the following installation space is available, and where air does not gather.
- Where rain and sunlight do not directly hit the unit, and where there is enough air circulation. Also, where the unit cannot be buried by snow.
- a location which can sustain the weight of the unit, and where noises and vibrations are not enhanced
- Where blasts of cold or hot air and noise do not bother the neighbors.

• In installing the unit, fix the unit's legs with bolts specified on the left. • The protrusion of an anchor bolt on the front side must be kept within 15 mm.

• Install the unit in a level area. (With a gradient of 5 mm or less.)

• Refer to the above illustrations for information regarding concrete foundations.

• Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.


- Where the unit does not receive heat radiation from other heat sources.
- Where there are no obstructions (animals, plants, etc.) to the suction inlet and blowing outlet.
- Where water may drain out.
- \* Please avoid the following locations.
- Where there is constant exposure to harsh winds such as the top floors of a building. Also, locations with exposure to salty air.
- Where there are oil splashes, vapor, and smoke.
- Where there are possibilities of flammable gas leaks.


Installation

1

#### ① Anchor bolt fixed position

2 Notabilia for installation








1 Installation Space (on a flat surface)

or is overhead, the sufficient space between the unit and wall shall be secured.

OWhen the unit is installed, the space of the following dimension and above shall be secured.



Measurement B (mm)

Clutch type

1.0~1.5


Clutch typr flare tool for R410A

0.0~0.5

Conventional (R22) flare tool

Wing nut type


1.5~2.0



#### 3 **CONNECTION OF REFRIGERANT PIPINGS**

[Connection of pipes]

- NOTE
- Cover the pipes with tape so that dust and sand do not enter the pipe until they are connected.
- When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon aas or oil.
- Make sure to match the pipes between the indoor unit and the outdoor unit with the correct operation valves



Copper pipe

*φ*6.35


diameter

- 159 -




### NOTE : Fully open the operation valves (on both liquid and gas sides) after completing air purging.

- Since the system uses service ports differing in diameter from those found on the conventional models, a charge hose (for R22) presently in use is not applicable. Please use one designed specifically for R410A.
- Remove the cap on both gas and liquid sides before starting operation. • After completing the operation, do not forget to tighten the cap (gas may leak).
- Procedure
- (1) Secure all flare nuts on both indoor and outdoor sides to prevent leaks from the pipes. (2) Connect the operation valves, charge hose, manifold
- valve and vacuum pump as shown in the right figure. (3) Fully open the handle Lo for the manifold valve, and
- pump a vacuum for 15 minutes. Ensure that the meter
- is indicating -0.1MPa (-76cmHg). (4) After vacuuming, fully open the operation valve (both liquid and gas sides) with a hexagon wrench.




- Please use an anti-reverse flow type vacuum pump adapter so as to prevent vacuum pump oil from running back into the system. Oil running back into an air-conditioning system may cause the refrigerant cycle to break down.
- Conduct air purging for all connected indoor units



(6) Repeat the above steps (1) ~ (5) for all connected indoor units.

(5) Remove the charge hose from service port.

(7) Ensure that there are no gas leaks from the joints in the indoor and outdoor units.



O The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

AND

FOUR SEC OFF

DISCHARGE PIPE SENSOR ERBOR

## RPC012A916C

MULTI TYPE AIR CONDITIONER R410A REFRIGERANT USED

#### (2) Models SCM50ZJ-S1, 60ZJ-S1

This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 173 to 208.
When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between

indoor and outdoor units, power supply voltage and etc.) and installation spaces

## SAFETY PRECAUTIONS

Work in order to protect yoursent.
 The precationary items mentioned below are distinguished into two levels, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>WARNING</u> and <u>Fractuationary items mentioned below are distinguished into two levels</u>, <u>Fractuationary items mentioned below</u>, <u>Fractuationary items mentioned below</u>, <u>Fractuationary items mentioned below</u>, <u>Fractuationary items mentioned below</u>, <u>Fractuationary items</u>, <u>Fractu</u>

circumstances.

Both mentions the important items to protect your health and safety so strictly follow them by any means. • Be sure to confirm no anomaly on the equipment by commissioning after completed installation

and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

# • Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself. • Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.

- ACAUTION.
   Acaution and the second second



| $\bigcap$  |  |  |   |
|------------|--|--|---|
| •          | <ul> <li>Installation must be carried out by the qualified installer.</li> <li>If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installat.</li> <li>Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li> <li>Be sure to use only for household and residence. If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li> <li>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</li> <li>If the density of refrigerant exceeds the limit, please consult the dealer and installation.</li> <li>If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li> <li>Install the unit in a location with good support.</li> <li>Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li> <li>Ensure the unit is table when installed, so that it can withstand earthquakes and strong winds.</li> <li>Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.</li> <li>Ventilate the working area well in the event of refrigerant leakage and personal injury.</li> <li>Ventilate the working area well in the event of refrigerant leakage and personal injury.</li> </ul> | <ul> <li>Use the prescribed pipes, flare nuts and tools for R410A.</li> <li>Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.</li> <li>Tighten the flare nut by torque wrench with specified method.</li> <li>If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.</li> <li>Do not open the operation valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.</li> <li>If the compressor is operated in state of opening operation valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause bust or personal injury due to anomalously high pressure in the refrigerant.</li> <li>The electrical installation must be carried out by the qualified electrician wark can cause electric shocks and the system must be connected to the dedicated circuit.</li> <li>Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks, unit failure or incorrect function of equipment.</li> <li>Be sure to shut off the power can cause electric shocks, unit failure or the cables conformed to safety standard and cable ampacity for power distribution work.</li> <li>Unconformable cables can cause electric leak, anomalous heat production or fire.</li> </ul> | <ul> <li>This appliance must be connected to main power supply by means of a circuit breaker or switch (fuse:25A) with a contact separation of at least 3mm.</li> <li>Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.</li> <li>Incorrect installation may result in overheating and fire.</li> <li>Use the prescribed cables for electrical connection, tighten the cables securely in terminal block. And relieve the cables correctly to prevent overloading the terminal blocks.</li> <li>Loose connections or cable mountings can cause anomalous heat production or fire.</li> <li>Be sure to fix up the service panels.</li> <li>Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water.</li> <li>If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.</li> <li>Stop the compressor before removing the pipe after shutting the service valve on pump down work.</li> <li>If the pipe is removed when the compressor is in operation with the service valve on pump down work.</li> <li>If the pipe is removed when the cooling cycle.</li> <li>Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.</li> <li>Be sure to wear protective goggles and gloves while at work.</li> </ul> |
| $\oslash$  | <ul> <li>Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.</li> <li>If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.</li> <li>Do not processing, splice the power cord, or share a socket with other power plugs.</li> <li>This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.</li> </ul>  | <ul> <li>Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.</li> <li>This may cause fire or heating.</li> <li>Do not run the unit with removed panels or protections.</li> <li>Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.</li> </ul>  | <ul> <li>Do not perform any change of protective device itself<br/>or its setup condition.</li> <li>The forced operation by short-circuiting protective device of<br/>pressure switch and temperature controller or the use of<br/>non specified component can cause fire or burst.</li> </ul>  |
|            |  | ▲ CAUTION  |   |
| Ð          | Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lig short-circuiting.   | htning conductor or telephone line's ground lead. Incorrect grou   | inding can cause unit faults such as electric shocks due to   |
| •          | <ul> <li>Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.</li> <li>Using the incorrect one could cause the system failure and fire.</li> <li>Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations.</li> <li>The isolator should be locked in OFF state in accordance with EN60204-1.</li> <li>After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.</li> <li>Secure a space for installation, inspection and maintenance specified in the manual.</li> </ul>  | Insufficient space can result in accident such as personal<br>injury due to falling from the installation place.<br>• Take care when carrying the unit by hand.<br>If the unit weights more than 20kg, it must be carried by two<br>or more persons. Do not carry by the plastic straps, always<br>use the carry handle when carrying the unit by hand. Use<br>gloves to minimize the risk of cuts by the aluminum fins.<br>• Dispose of any packing materials correctly.<br>Any remaining packing materials can cause personal injury<br>as it contains nails and wood. And to avoid danger of<br>suffocation, be sure to keep the plastic wrapper away from<br>children and to dispose after tear it up.<br>• Be sure to insulate the refrigerant pipes so as not to<br>condense the ambient air moisture on them.<br>Insufficient insulation can cause condensation, which can<br>lead to moisture damage on the ceiling, floor, furniture and<br>any other valuables.  | <ul> <li>When perform the air conditioner operation (cooling<br/>or drying operation) in which ventilator is installed in<br/>the room. In this case, using the air conditioner in<br/>parallel with the ventilator, there is the possibility that<br/>drain water may backflow in accordance with the<br/>room lapse into the negative pressure status.<br/>Therefore, set up the opening port such as<br/>incorporate the air into the room that may appropriate<br/>to ventilation (For example; Open the door a little). In<br/>addition, just as above, so set up the opening port if<br/>the room lapse into the negative pressure status due to<br/>register of the wind for the high rise apartment etc.</li> </ul>   |
| $\bigcirc$ | <ul> <li>Do not install the unit in the locations listed below.</li> <li>Locations where carbon fiber, metal powder or any powder is floating.</li> <li>Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>Vehicles and ships.</li> <li>Locations where cosmetic or special sprays are often used.</li> <li>Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> </ul>  | <ul> <li>Locations where any machines which generate high frequency harmonics are used.</li> <li>Locations with salty atmospheres such as coastlines.</li> <li>Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).</li> <li>Locations where the unit is exposed to chimney smoke.</li> <li>Locations with antitude (more than 1000m high).</li> <li>Locations where heat radiation from other heat source can affect the unit.</li> <li>Locations without good air circulation.</li> </ul>  | <ul> <li>Locations with any obstacles which can prevent inlet and outlet air of the unit.</li> <li>Locations where short circuit of air can occur (in case of multiple units installation).</li> <li>Locations where strong air blows against the air outlet of outdoor unit.</li> <li>Locations where something located above the unit could fall.</li> <li>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</li> </ul>  |

| ▲ CAUTION   |  |
|---|--|
| <ul> <li>Do not install the outdoor unit in the locations listed below.</li> <li>Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.</li> <li>Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.</li> <li>Locations where vibration can be amplified and transmitted due to insufficient strength of structure.</li> <li>Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).</li> <li>Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).</li> <li>Locations where drainage cannot run off safely. It can affect surrounding environment and cause a claim.</li> <li>Do not install the unit where crorosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas suffurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible by substances are</li> </ul> | Connecting the circuit with copper wire or other metal<br>thread can cause unit failure and fire.<br>• Do not touch any buttons with wet hands.<br>It can cause electric shocks.<br>• Do not touch any refrigerant pipes with your hands<br>when the system is in operation.<br>During operation the refrigerant pipes become extremely hi<br>or extremely cold depending the operating condition, and i |

#### ( Check before installation work )

| <ul> <li>Model name and power source</li> </ul>                  | _   |                              |           | _                |   |                                   |   |  |
|--|-----|------------------------------|-----------|------------------|---|-----------------------------------|---|--|
| Refrigerant piping length  |     | Option parts                 |           |                  | Necessary tools for the installation work   | 9                                 | Wrench key (Hexagon) [4m/m]                         |  |
| <ul> <li>Piping, wiring and miscellaneous small parts</li> </ul> |     |                              | Q'ty      |                  | Necessary tools for the installation work   |                                   | Vacuum pump   |  |
| Indoor unit installation manual                                  | a   | Sealing plate                | 1         | 1                | 1 Plus headed driver                        |                                   | Vacuum pump adapter (Anti-reverse flow type)        |  |
|  |     | Sleeve                       | 1 2 Knife |                  | 1   | (Designed specifically for R410A) |   |  |
| Accessories for outdoor unit Q'ty                                | ] @ | Inclination plate            | 1         | 3                | Saw   | 12                                | Gauge manifold (Designed specifically for R410A)    |  |
| Accessories for outdoor unit                                     | d   | Putty                        | 1         | 4 Tape measure 1 |   |                                   | Charge hose (Designed specifically for R410A)       |  |
| Grommet (Heat pump type only)     1                              | 6   | Drain hose (extension        | 4         | 5                | Hammer                                      | 14                                | Flaring tool set (Designed specifically for R410A)  |  |
| ② Drain elbow (Heat pump type only) 1                            | 16  | hose)                        | '         | 6                | Spanner wrench                              | 15                                | Gas leak detector (Designed specifically for R410A) |  |
| Variable diameter joint SCM50 1                                  | 1 G | Piping cover (for insulation | 1         | 7                | Torque wrench [14.0~62.0N·m (1.4~6.2kgf·m)] | 16                                | Gauge for projection adjustment (Used when flare is |  |
| Ø 9.52⇒φ12.7 SCM60 2   | 114 | of connection piping)        |           | 8                | Hole core drill (65mm in diameter)          | 1''                               | made by using conventional flare tool)              |  |
| Note: Provide flare nuts when using the variable                 |     |                              |           |                  |   |                                   |   |  |

diameter joint (for \$\$\phi12.7\$).

**CAUTION** • This model requires a minimum of 2 indoor units.


#### 1 SELECTION OF INSTALLATION LOCATION

#### Install at location that meets the following conditions after getting approval from the customer.


- Where the following installation space is available, and where air does not gather.
- Where rain and sunlight do not directly hit the unit, and where there is enough air circulation. Also, where the unit cannot be buried by snow.
- a location which can sustain the weight of the unit, and where noises and vibrations are not enhanced.
- Where blasts of cold or hot air and noise do not bother the neighbors.
- Where the unit does not receive heat radiation from other heat sources
- Where there are no obstructions (animals, plants, etc.) to the suction inlet and blowing outlet.
- Where water may drain out.
- \* Please avoid the following locations.
- Where there is constant exposure to harsh winds such as the top floors of a building. Also, locations with exposure to salty air.
- Where there are oil splashes, vapor, and smoke.
  Where there are possibilities of flammable gas leaks.


#### Installation

#### ① Anchor bolt fixed position



2 Notabilia for installation





Use a thicker block to anchor deeper


• In installing the unit, fix the unit's legs with bolts specified on the left.


- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the above illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5 mm or less.)

Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

① Installation Space (on a flat surface)

- OBlowing out port and suction port on the back side of the unit can be installed at a distance of 10cm from walls.
  - In case the barrier is 1.2m or above in height, or is overhead, the sufficient space between the unit and wall shall be secured.
- OWhen the unit is installed, the space of the following dimension and above shall be secured.







Connection

Outdoor




OTighten the nuts to the following torque.
 Liquid side : 14.0−18.0N·m (1.4−1.8kgf·m)
 Gas side (φ9.52): 33.0−42.0N·m (3.3−42.2kgf·m)
 (φ12.7): 49.0∼61.0N·m (4.9∼6.1kgf·m)

Gas Leakage Test

oil to the flared surface

Do not apply refrigerating machine


•Ensure that there are no gas leaks from the pipe joints by using a leak detector or soap water.



Copper pipe

Flaring

block



 The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

#### (3) Models SCM71ZJ-S1, 80ZJ-S1

#### RPC012A913B

MULTI TYPE AIR CONDITIONER R410A REFRIGERANT USED

• This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page173 to 208. . When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

## SAFETY PRECAUTIONS

• The precautionary items mentioned below are distinguished into two levels, 🕅 WARNING and • For installing qualified personnel, take precautions in respect to themselves by using suitable WARNING : Wrong installation would cause serious consequences such as injuries or death. • Please pay attention not to fall down the tools, etc. when installing the unit at the high position


CAUTION : Wrong installation might cause serious consequences depending on circumstances Both mentions the important items to protect your health and safety so strictly follow them by

any means.

- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation
   Keep the installation manual together with owner's manual at a place where any user can read
   at any time. Moreover if necessary, ask to hand them to a new user.
  - protective clothing, groves, etc., and then perform the installation works
  - . If unusual noise can be heard during operation, consult the dealer
  - . The meanings of "Marks" used here are shown as follows







**CAUTION** • This model requires a minimum of 2 indoor units.


### 1 SELECTION OF INSTALLATION LOCATION

#### Install at location that meets the following conditions after getting approval from the customer.


- Where the following installation space is available, and where air does not gather.
- Where rain and sunlight do not directly hit the unit, and where there is enough air circulation.
   Also, where the unit cannot be buried by snow.
- a location which can sustain the weight of the unit, and where noises and vibrations are not enhanced.
- Where blasts of cold or hot air and noise do not bother the neighbors.
- Where the unit does not receive heat radiation from other heat sources.
- Where there are no obstructions (animals, plants, etc.) to the suction inlet and blowing outlet.
   Where water may drain out.
- \* Please avoid the following locations.
- Where there is constant exposure to harsh winds such as the top floors of a building. Also,
- locations with exposure to salty air.
- Where there are oil splashes, vapor, and smoke.
  Where there are possibilities of flammable gas leaks.

#### Installation

① Anchor bolt fixed position



(2) Notabilia for installation



• In installing the unit, fix the unit's legs with bolts specified on the left.


- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the above illustrations for information regarding concrete foundations.


• Install the unit in a level area. (With a gradient of 5 mm or less.)

Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.


1 Installation Space (on a flat surface)

- Blowing out port and suction port on the back side of the unit can be installed at a distance of 10cm from walls.
- In case the barrier is 1.2m or above in height, or is overhead, the sufficient space between the unit and wall shall be secured.
- OWhen the unit is installed, the space of the following dimension and above shall be secured.





- When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon gas or oil.
- Make sure to match the pipes between the indoor unit and the outdoor unit with the correct operation valves.



# 

Do not apply excess torque to the flared nuts. Otherwise, the flared nuts may crack depending on the conditions and refrigerant leak may occur.

#### Connection






- ○Connect the pipes on both liquid and gas sides. ○Tighten the nuts to the following torque. Liquid side :  $14.0-18.0N \cdot m (1.4 - 1.8kgf \cdot m)$ Gas side ( $\phi$ 9.52):  $33.0 - 42.0N \cdot m (3.3 - 4.2kgf \cdot m)$ ( $\phi$ 12.7):  $49.0 - 61.0N \cdot m (4.9 - 6.1kgf \cdot m)$
- When the total refrigerant pipe lenght for all the rooms exceeds the lenght of the uncharged pipe (40m), additional refrigerant is required.
   (If 40m or less, additional charge is not required.)
   Additional charge amount per meter = 20g/m


Gas Leakage Test

**▲** CAUTION


Do not apply refrigerating machine oil to the flared surface.

•Ensure that there are no gas leaks from the pipe joints by using a leak detector or soap water.





| piping length                            | one indoor unit MAX 25m<br>all indoor unit MAX 70m             |
|--|--|
| hight difference                         | MAX 20m<br>MAX 20m<br>MAX 20m<br>MAX 20m<br>MAX 20m<br>MAX 20m |
| length of chargeless<br>refrigerant pipe | 40m  |



O The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

#### (4) Models SCM100ZJ-S1, 125ZJ-S1

#### RPC012A918 *R*

#### MULTI TYPE AIR CONDITIONER **R410A REFRIGERANT USED**

• This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to the respective installation manuals supplied with the units. . When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces

## SAFETY PRECAUTIONS


WARNING: Wrong installation would cause serious consequences such as injuries or death. **CAUTION** : Wrong installation might cause serious consequences depending on

circumstances Both mentions the important items to protect your health and safety so strictly follow them by

any means. Be sure to confirm no anomaly on the equipment by commissioning after completed installation

- and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation
   Keep the installation manual together with owner's manual at a place where any user can read
   at any time. Moreover if necessary, ask to hand them to a new user.
- The precautionary items mentioned below are distinguished into two levels, 🕅 WARNING and For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works
  - Please pay attention not to fall down the tools, etc. when installing the unit at the high position If unusual noise can be heard during operation, consult the dealer
  - . The meanings of "Marks" used here are shown as follows





| $\bigcap$ |   |   |   |
|-----------|---|---|---|
| 0         | <ul> <li>Do not install the outdoor unit in the locations listed below.</li> <li>Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.</li> <li>Locations where outlet air of the outdoor unit blows directly to plants. The outlet air can affect adversely to the plant etc.</li> <li>Locations where vibration can be amplified and transmitted due to insufficient strength of structure.</li> <li>Locations where a nequipment affected by high harmonics is placed (IV set or radio receiver is placed whitin 1 m).</li> <li>Locations where drainage cannot run off safely. It can affect surrounding environment and cause a claim.</li> <li>Do not install the unit mer the location where leakage of combustible gases accumulate around the unit, it can cause fire.</li> <li>Do not install the unit where corrosive gas (such as suffurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are</li> </ul> | <ul> <li>handled.</li> <li>Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.</li> <li>Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics.</li> <li>Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment. Instruct the user to keep the surroundings clean.</li> <li>Do not use the base flame for outdoor unit which is corroded or damaged due to long periods of operation.</li> <li>Using an old and damage base flame can cause the unit falling down and cause personal injury.</li> </ul> | <ul> <li>Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.</li> <li>Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.</li> <li>Do not touch any buttons with wet hands. It can cause electric shocks.</li> <li>Do not touch any refrigerant pipes with your hands when the system is in operation.</li> <li>During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury.</li> <li>Do not touch the suction or aluminum fin on the outdoor unit.</li> <li>This may cause injury.</li> <li>Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.</li> <li>Do not clean up the unit with water.</li> </ul> |

#### Check before installation work

| <ul> <li>Model name and power source</li> <li>Refrigerant piping length</li> </ul>                        |      | Option parts                      | Q'ty | 1 [                  |   |     | Wrench key (Hexagon) [4m/m]                         |
|---|------|-----------------------------------|------|----------------------|---|-----|---|
| <ul> <li>Piping, wiring and miscellaneous small parts</li> <li>Indoor unit installation manual</li> </ul> |      |                                   |      |                      | Necessary loois for the installation work     | 10  | Vacuum pump   |
|   |      | <ul> <li>Sealing plate</li> </ul> | 1    | 1 Plus headed driver |   | 11  | Vacuum pump adapter (Anti-reverse flow type)        |
|   |      | (b) Sleeve                        | 1    | 2                    | 2 Knife                                       | 1'' | (Designed specifically for R410A)                   |
| Accessories for outdoor unit  | Q'ty | C Inclination plate               | 1    | 3                    | 3 Saw   | 12  | Gauge manifold (Designed specifically for R410A)    |
| Accessories for outdoor unit  | Qiy  | Putty                             | 1    | 4                    | 1 Tape measure                                | 13  | Charge hose (Designed specifically for R410A)       |
| Grommet (Heat pump type only)   | 2    | Distant data i                    | 4    | 15                   | 5 Hammer                                      | 14  | Flaring tool set (Designed specifically for R410A)  |
| Drain elbow (Heat pump type only)   | 1    | hose)                             | 1    | 6                    | 3 Spanner wrench                              | 15  | Gas leak detector (Designed specifically for R410A) |
| ③ Variable diameter joint   | 3    | Piping cover (for insulation      | 4    | 17                   | 7 Torque wrench [14.0~82.0N·m (1.4~8.2kgf·m)] | 16  | Gauge for projection adjustment (Used when flare is |
| ④ Variable diameter joint   | 2    | of connection piping)             | 1    | 8                    | B Hole core drill (65mm in diameter)          | 1'0 | made by using conventional flare tool)              |

diameter joint (for  $\phi$ 12.7,  $\phi$ 15.88).

This model requires normally a minimum of 4 indoor units.

CAUTION • This model requires a minimum of 3 indoor units in case of SRK-ZK-S, SRK-ZJX-S, FDEN type combination only.

• This model requires a minimum of 2 indoor units in case of SRK71ZK-S type only.

#### 1 SELECTION OF INSTALLATION LOCATION

#### Install at location that meets the following conditions after getting approval from the customer.


- Where the following installation space is available, and where air does not gather.
- Where rain and sunlight do not directly hit the unit, and where there is enough air circulation.
- Also, where the unit cannot be buried by snow.
   A location which can sustain the weight of the unit, and where
- Where blasts of cold or hot air and noise do not bother the
- Where the unit does not receive heat radiation from other heat
- sources.Where there are no obstructions (animals, plants, etc.) to the
- where there are no obstructions (animals, plants, etc.) to the suction inlet and blowing outlet.
- Where water may drain out.
- \* Please avoid the following locations.
- Where there is constant exposure to harsh winds such as the top floors of a building. Also, locations with exposure to salty air.
- Where there are oil splashes, vapor, and smoke.
- Where there are possibilities of flammable gas leaks.

#### Installation


- In installing the unit, fix the unit's legs with bolts specified on the right.
- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the right illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5 mm or less.) Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.


① Installation Space (on a flat surface)

- Walls surrounding the unit in the four sides are not acceptable.
- There must be a 1-meter or large space in the above.
- Where a danger of short-circuiting exists, install guide louvers.
- When more than one unit are installed, provide sufficient intake space
- consciously so that short-circuiting may not occur.
  When piling snow can bury the outdoor unit, provide proper snow guards.




#### 1 Anchor bolt fixed position





(2) Notabilia for installation

olt fixed position



 Regarding the change in the sizes of gas side pipes (usage of the variable joints); If a 5.0, 6.0 kW class indoor unit (gas side pipe 12.7) or 7.1 kW class indoor unit (gas side pipe 15.88) is going to be connected to theoperation valves (9.52), variable joints available as accessories must be applied to the gas side operation valves • Securely fit the copper packing between the operation valve and the variable


• Cover the pipes with tape so that dust and sand do not enter the pipe until they are


diameter joint to prevent shifting


[Connection of pipes]

NOTE


Outdoor









Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use. If a conventional flare tool is used, please use copper pipe gauge or a similar instrument to check protrusion so that you can keep measurement B to a correct value.









indoor unit


indoor unit

indoor unit

indoor unit

50m

- 171 -



- Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

## 5.2 Indoor units

(1) Wall mounted tyde (SRK)

- (a) Models SRK20~35ZJX-S, 50, 60ZJX-S1
- This installation manual illustrates the method of installing an indoor
- unit
- · For electrical wiring work, please see instructions set out on the backside.
- · For outdoor unit installation and refrigerant piping, please refer to page 157 to 172.

### SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself · The precautionary items mentioned below are distinguished into two levels,
- AWARNING and ACAUTION.

 $\neg$ 

 $\omega$ 

- WARNING : Wrong installation would cause serious consequences such as iniuries or death.
- **CAUTION** : Wrong installation might cause serious consequences
- depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.
- · Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user
  - using suitable protective clothing, groves, etc., and then perform the installation works

When install the unit, be sure to check whether the selection of

RKY012A007B

- · Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- . The meanings of "Marks" used here are shown as follows:

00 circumstances nstruction.

#### **∧** WARNING Installation must be carried out by the qualified installer. If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except . the by qualified installer. Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire. Be sure to use only for household and residence. If this appliance is installed in inferior environment such as machine shop • Be sure to shut off the power before starting electrical work. and etc. it can cause malfunction Use the original accessories and the specified components for installation If parts other than those prescribed by us are used, It may cause water leaks, electric shocks, fire and personal injury. Install the unit in a location with good support. or fire Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury Ventilate the working area well in the event of refrigerant leakage at least 3mm. during installation. If the refrigerant comes into contact with naked flames, poisonous gas is produced. When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage. referred by the formula (accordance with ISO5149). If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which • Arrange the wiring in the control box so that it cannot be pushed up can cause serious accident. After completed installation, check that no refrigerant leaks from

- the system. If refrigerant leaks into the room and comes into contact with an oven or
- other hot surface, poisonous gas is produced. Use the prescribed pipes, flare nuts and tools for R410A. Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.
- Do not put the drainage pipe directly into drainage channels where Do not processing, splice the power cord, or share a socket with poisonous gases such as sulphide gas can occur. Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak. Ensure that no air enters in the refrigerant circuit when the unit is
  - installed and removed. If air enters in the refrigerant circuit, the pressure in the refrigerant circuit
  - becomes too high, which can cause burst and personal injury.

· For installing qualified personnel, take precautions in respect to themselves by

supply voltage and etc.) and installation spaces.

. If unusual noise can be heard during operation, consult the dealer

Never do it under any Always do it according to the

#### · Tighten the flare nut by torque wrench with specified method. If the flare nut were tightened with excess torque, this may cause burst an refrigerant leakage after a long period. The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit. $\bigcirc$ Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire. Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment. Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work. Unconformable cables can cause electric leak, anomalous heat production This appliance must be connected to main power supply by means of a circuit breaker or switch (fuse:16A) with a contact separation of When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used. Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat production or fire. further into the box. Install the service panel correctly. Incorrect installation may result in overheating and fire · Be sure to switch off the power supply in the event of installation, inspection or servicing. If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan. Be sure to wear protective goggles and gloves while at work. Earth leakage breaker must be installed. unit. If the earth leakage breaker is not installed, it can cause electric shocks. structure

- other power plugs. This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc. · Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.
- This may cause fire or heating.

 $\bigcirc$  Do not vent R410A into the atmosphere : R410A is a fluorinated · Do not perform any change of protective device itself or its setup greenhouse gas, covered by the Kyoto Protocol with Groval condition. Warming Potential (GWP)=1975. The forced operation by short-circuiting protective device of pressure Do not run the unit with removed panels or protections. can cause fire or burst Touching rotating equipments, hot surfaces or high voltage parts can cause A wired remote control unit is supplied separately as an optional part personal injury due to entrapment, burn or electric shocks installation place, power supply specifications, usage limitation (piping **∧** CAUTION length, height differences between indoor and outdoor units, power Carry out the electrical work for ground lead with care such as electric shocks due to short-circuiting. Use the circuit breaker of correct capacity. Circuit breaker should falling from the installation place. be the one that disconnect all poles under over current. Using the incorrect one could cause the system failure and fire Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations. ambient air moisture on them. The isolator should be locked in OEE state in accordance with EN60204-1. Be sure to install indoor unit properly according to the installation manual in order to run off the drainage smoothly. Improper installation of indoor unit can cause dropping water into the room and damaging personal property Install the drainage pipe to run off drainage securely according to the installation manual Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property. Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings

**WARNING** 

- Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.
  - Secure a space for installation, inspection and maintenance specified in the manual Insufficient space can result in accident such as personal injury due to

#### Do not install the unit in the locations listed below.

- Locations where any substances that can affect the unit such as sulphide. gas, chloride gas, acid and alkaline can occur.
- Vehicles and shins
- · Locations where cosmetic or special sprays are often used
- machine plant.
- are used
- · Locations with salty atmospheres such as coastlines
- Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).

- · Locations without good air circulation.
- Locations where short circuit of air can occur (in case of multiple units installation).
- · Locations where something located above the unit could fall.
- It can cause remarkable decrease in performance, corrosion and damage
- of components, malfunction and fire.
- to install the indoor unit according to the installation manual for
- Locations with any obstacles which can prevent inlet and outlet air of the
- · Locations where vibration can be amplified due to insufficient strength of
- · Locations where the infrared receiver is exposed to the direct sunlight or
- the strong light beam (in case of the infrared specification unit). · Locations where an equipment affected by high harmonics is placed (TV
- set or radio receiver is placed within 5m). Locations where drainage cannot run off safely
- It can affect performance or function and etc.
- Do not install the unit near the location where leakage of combustible gases can occur.

# switch and temperature controller or the use of non specified component

Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults · For installation work, be careful not to get injured with the heat exchanger, piping flare portion or screws etc. Be sure to insulate the refrigerant pipes so as not to condense the Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables. When perform the air conditioner operation (cooling or drving operation) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. If leaked gases accumulate around the unit, it can cause fire. Locations where carbon fiber, metal powder or any powder is floating. · Do not install the unit where corrosive gas (such as sulfurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled. Corrosive gas can cause corrosion of heat exchanger, breakage of plastic Locations with direct exposure of oil mist and steam such as kitchen and parts and etc. And combustible gas can cause fire. Do not use the indoor unit at the place where water splashes may Locations where any machines which generate high frequency harmonics occur such as in laundries. Since the indoor unit is not waterproof, it can cause electric shocks and fire · Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics. Equipment such as inverters, standby generators, medical high frequency Locations where the unit is exposed to chimney smoke equipments and telecommunication equipments can affect the system and Locations at high altitude (more than 1000m high). cause malfunctions and breakdowns. The system can also affect medical · Locations with ammonic atmospheres. equipment and telecommunication equipment, and obstruct its function or · Locations where heat radiation from other heat source can affect the unit. cause iamming · Do not place any variables which will be damaged by getting wet Locations with any obstacles which can prevent inlet and outlet air of the unit. under the indoor unit. When the relative humidity is higher than 80% or drainage pipe is clogged. condensation or drainage water can drop and it can cause the damage of · Locations where strong air blows against the air outlet of outdoor unit. valuables Do not install the remote control at the direct sunlight. It can cause malfunction or deformation of the remote control. · Do not use the unit for special purposes such as storing foods, Do not install the indoor unit in the locations listed below (Be sure cooling precision instruments and preservation of animals, plants or art. each model because each indoor unit has each limitation). It can cause the damage of the items. Do not use any materials other than a fuse with the correct rating

in the location where fuses are to be used.

Do not touch any buttons with wet hands.

unit failure and fire

frost iniury.

It can cause electric shocks.

system is in operation.

Connecting the circuit with copper wire or other metal thread can cause Do not touch any refrigerant pipes with your hands when the During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or


#### BEFORE INSTALLATION


O Before installation check that the power supply matches the air conditioner.


| S   | tandard accessories (Installation kit)<br>Accessories for indoor unit | Q'ty |
|-----|---|------|
| 1   | Installation board<br>(Attached to the rear of the indoor unit)       | 1    |
| 2   | Wireless remote control   | 1    |
| 3   | Remote control holder   | 1    |
| 4   | Tapping screws<br>(for installation board 4dia. by 25mm)              | 4    |
| (5) | Wood screw<br>(for remote control switch holder 3.5(mm). by 16mm)     | 2    |
| 6   | Battery [R03(AAA,Micro) 1.5V]   | 2    |
| 1   | Air-cleaning filters  | 2    |
| 8   | Filter holders<br>(Attached to the front panel of indoor unit)        | 2    |
| 9   | Insulation (#486 50 x 100 t3)   | 1    |
|     | Option parts  | Q'tv |


|   | Option parts  |   |  |  |  |  |  |  |
|---|---|---|--|--|--|--|--|--|
| a | Sealing plate   | 1 |  |  |  |  |  |  |
| b | Sleeve  | 1 |  |  |  |  |  |  |
| © | Inclination plate                                     | 1 |  |  |  |  |  |  |
| đ | Putty   | 1 |  |  |  |  |  |  |
| e | Drain hose (extention hose)                           | 1 |  |  |  |  |  |  |
| Ð | Piping cover<br>(for insulation of connection piping) | 1 |  |  |  |  |  |  |
|   |   |   |  |  |  |  |  |  |

|    | Necessary tools for the installation work  |
|----|--|
| 1  | Plus headed driver   |
| 2  | Knife  |
| 3  | Saw  |
| 4  | Tape measure   |
| 5  | Hammer   |
| 6  | Spanner wrench   |
| 7  | Torque wrench $\begin{pmatrix} 14.0 \sim 61.0 \text{N·m} \\ (1.4 \sim 6.1 \text{kgf·m}) \end{pmatrix}$ |
| 8  | Hole core drill (65mm in diameter)   |
| 9  | Wrench key (Hexagon) [4m/m]  |
| 10 | Flaring tool set (Designed specifically<br>for R410A)  |
| 11 | Gas leak detector (Designed specifically<br>for R410A  |
| 12 | Gauge for projection adjustment<br>(Used when flare is made by using)<br>conventional flare tool       |
| 13 | Pipe bender  |










'11 • SCM-SM-110



#### Test run

- Air conditioning operation is normal.
- No abnormal noise.
- Water drains smoothly.
- Protective functions are not working.
- The remote control is normal.
- Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer) When the air conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

## HOW TO RELOCATE OR DISPOSE OF THE UNIT

- O In order to protect the environment, be sure to pump down (recovery of refrigerant). Forced cooling operation O Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.
- <How to pump down>

176

- Connect charge hose to service port of outdoor unit.
- 2 Liquid side : Close the liquid valve with hexagon wrench key. Gas side : Fully open the gas valve Carry out cooling operation . (If indoor temperature is low, operate
- forced cooling operation.) ③ After low pressure gauge become 0.01MPa, stop cooling operation and close the gas valve.

| breed eboling operation  |  |
|--|--|
| urn on a power supply again after a while after turn off a power supply. |  |
| nen press continually the ON/OFF button 5 seconds or more.               |  |



## CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

① Remove the front panel and lid of control.

- (2) There is a terminal (respectively marked with CNS) for the indoor control board. In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control
- box with the clamp supplied with the kit. For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".

#### (b) Models SRK25ZJR-S. 35ZJR-S

#### RLA012A012B

SRK20ZJ-S, 25ZJ-S, 35ZJ-S, 50ZJ-S

 This installation manual illustrates the method of installing an indoor unit. For electrical wiring work, please see instructions set out on the

backside. · For outdoor unit installation and refrigerant piping, please refer to

page 157 to 172.

#### SAFETY PRECAUTIONS

- · Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself. . The precautionary items mentioned below are distinguished into two levels,
- WARNING and CAUTION

the by qualified installer

and etc. it can cause malfunction

material damage and personal injury.

shocks and fire

installation.

during installation.

can cause serious accident.

installed and removed.

produced.

the system

- WARNING : Wrong installation would cause serious consequences such
- as injuries or death. CAUTION : Wrong installation might cause serious consequences
- depending on circumstances. Both mentions the important items to protect your health and safety so strictly
- follow them by any means.

· Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

Installation must be carried out by the qualified installer.

Be sure to use only for household and residence

leaks, electric shocks, fire and personal injury.

Install the unit in a location with good support.

If you install the system by yourself, it may cause serious trouble such as

Install the system in full accordance with the installation manual.

If this appliance is installed in inferior environment such as machine shop

Use the original accessories and the specified components for

If parts other than those prescribed by us are used, It may cause water

Unsuitable installation locations can cause the unit to fall and cause

Ventilate the working area well in the event of refrigerant leakage

If the refrigerant comes into contact with naked flames, poisonous gas is

If the density of refrigerant exceeds the limit, please consult the dealer and

install the ventilation system, otherwise lack of oxygen can occur, which

After completed installation, check that no refrigerant leaks from

If refrigerant leaks into the room and comes into contact with an oven or

Using existing parts (for R22 or R407C) can cause the unit failure and

Poisonous gases will flow into the room through drainage pipe and

seriously affect the user's health and safety. This can also cause the

corrosion of the indoor unit and a resultant unit failure or refrigerant leak.

Ensure that no air enters in the refrigerant circuit when the unit is

If air enters in the refrigerant circuit, the pressure in the refrigerant circuit

becomes too high, which can cause burst and personal injury.

Use the prescribed pipes, flare nuts and tools for R410A.

serious accidents due to burst of the refrigerant circuit.

poisonous gases such as sulphide gas can occur.

When installing in small rooms, take prevention measures not to

exceed the density limit of refrigerant in the event of leakage.

referred by the formula (accordance with ISO5149).

other hot surface, poisonous gas is produced.

Incorrect installation may cause bursts, personal injury, water leaks, electric

• A wired remote control unit is supplied separately as an optional part. When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

- . Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user. · For installing qualified personnel, take precautions in respect to themselves by
  - using suitable protective clothing, groves, etc., and then perform the installation works
- · Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- . If unusual noise can be heard during operation, consult the dealer The meanings of "Marks" used here are shown as follows:



## MARNING

 Tighten the flare nut by torque wrench with specified method If the flare nut were tightened with excess forgue, this may cause burst and water leaks, electric shocks, fire and personal injury as a result of a system refrigerant leakage after a long period malfunction. Do not carry out the installation and maintenance work except ... The electrical installation must be carried out by the qualified

#### electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit

Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire

· Be sure to shut off the power before starting electrical work. Failure to shut off the power can cause electric shocks, unit failure or

#### incorrect function of equipment · Be sure to use the cables conformed to safety standard and cable

ampacity for power distribution work. Unconformable cables can cause electric leak, anomalous heat production

or fire. . This appliance must be connected to main power supply by means

of a circuit breaker or switch (fuse:16A) with a contact separation of at least 3mm.

. When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used

- · Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to
- prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat
- production or fire.

 Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.

Incorrect installation may result in overheating and fire. . Be sure to switch off the power supply in the event of installation, inspection or servicing.

- If the power supply is not shut off, there is a risk of electric shocks, unit
- failure or personal injury due to the unexpected start of fan. · Be sure to wear protective goggles and gloves while at work.
- · Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it can cause electric shocks.

#### On not put the drainage pipe directly into drainage channels where • Do not processing, splice the power cord, or share a socket with other power plugs.

This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc. . Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it

This may cause fire or heating.

M WARNING • Do not vent R410A into the atmosphere : R410A is a fluorinated · Do not perform any change of protective device itself or its setup  $\bigcirc$ greenhouse gas, covered by the Kyoto Protocol with Groval condition. Warming Potential (GWP)=1975. The forced operation by short-circuiting protective device of pressure Do not run the unit with removed panels or protections. switch and temperature controller or the use of non specified component Touching rotating equipments, hot surfaces or high voltage parts can cause can cause fire or burst. personal injury due to entrapment, burn or electric shocks **∧** CAUTION · Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting. Use the circuit breaker of correct capacity. Circuit breaker should falling from the installation place be the one that disconnect all poles under over current. . For installation work, be careful not to get injured with the heat Using the incorrect one could cause the system failure and fire. exchanger, piping flare portion or screws etc. Install isolator or disconnect switch on the power supply wiring in . Be sure to insulate the refrigerant pipes so as not to condense the accordance with the local codes and regulations. ambient air moisture on them. The isolator should be locked in OFF state in accordance with EN60204-1. Insufficient insulation can cause condensation, which can lead to moisture Be sure to install indoor unit properly according to the installation damage on the ceiling, floor, furniture and any other valuables. manual in order to run off the drainage smoothly. When perform the air conditioner operation (cooling or drving operation) in which ventilator is installed in the room. In this case, using the Improper installation of indoor unit can cause dropping water into the room air conditioner in parallel with the ventilator, there is the possibility and damaging personal property. Install the drainage pipe to run off drainage securely according to that drain water may backflow in accordance with the room lapse into the installation manual the negative pressure status. Therefore, set up the opening port such Incorrect installation of the drainage pipe can cause dropping water into the as incorporate the air into the room that may appropriate to ventilaroom and damaging personal property. tion (For example: Open the door a little). In addition, just as above, so Be sure to install the drainage pipe with descending slope of 1/100 set up the opening port if the room lanse into negative pressure status due to register of the wind for the high rise anartment etc. or more and not to make trans and air-bleedings Check if the drainage runs off securely during commissioning and ensure Be sure to perform air tightness test by pressurizing with nitrogen the space for inspection and maintenance gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant Secure a space for installation inspection and maintenance specified in the manual leakage in the small room, lack of oxygen can occur, which can cause Insufficient space can result in accident such as personal injury due to serious accidents Do not install the unit in the locations listed below. If leaked gases accumulate around the unit, it can cause fire. . Locations where carbon fiber, metal powder or any powder is floating. · Do not install the unit where corrosive gas (such as sulfurous acid . Locations where any substances that can affect the unit such as sulphide gas etc.) or combustible gas (such as thinner and petroleum gases) gas, chloride gas, acid and alkaline can occur. can accumulate or collect, or where volatile combustible Vehicles and ships. substances are handled. · Locations where cosmetic or special sprays are often used. Corrosive gas can cause corrosion of heat exchanger, breakage of plastic . Locations with direct exposure of oil mist and steam such as kitchen and parts and etc. And combustible gas can cause fire. • Do not use the indoor unit at the place where water splashes may machine plant. Locations where any machines which generate high frequency harmonics occur such as in laundries. Since the indoor unit is not waterproof, it can cause electric shocks and fire are used. Locations with salty atmospheres such as coastlines. Do not install nor use the system close to the equipment that I ocations with heavy snow (If installed, be sure to provide base flame and generates electromagnetic fields or high frequency harmonics. snow hood mentioned in the manual). Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and Locations where the unit is exposed to chimney smoke cause malfunctions and breakdowns. The system can also affect medical Locations at high altitude (more than 1000m high). Locations with ammonic atmospheres. equipment and telecommunication equipment, and obstruct its function or Locations where heat radiation from other heat source can affect the unit. cause iamming. Do not place any variables which will be damaged by getting wet Locations without good air circulation. I ocations with any obstacles which can prevent inlet and outlet air of the unit. under the indoor unit. Locations where short circuit of air can occur (in case of multiple units) When the relative humidity is higher than 80% or drainage pipe is clogged, installation). condensation or drainage water can drop and it can cause the damage of · Locations where strong air blows against the air outlet of outdoor unit valuables. Locations where something located above the unit could fall. Do not install the remote control at the direct sunlight. It can cause remarkable decrease in performance, corrosion and damage It can cause malfunction or deformation of the remote control. of components, malfunction and fire Do not use the unit for special purposes such as storing foods. Do not install the indoor unit in the locations listed below (Be sure cooling precision instruments and preservation of animals, plants or to install the indoor unit according to the installation manual for art. each model because each indoor unit has each limitation). It can cause the damage of the items. I ocations with any obstacles which can prevent inlet and outlet air of the . Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used. unit. Locations where vibration can be amplified due to insufficient strength of Connecting the circuit with copper wire or other metal thread can cause structure. unit failure and fire . Locations where the infrared receiver is exposed to the direct sunlight or Do not touch any buttons with wet hands. the strong light beam (in case of the infrared specification unit). It can cause electric shocks. . Locations where an equipment affected by high harmonics is placed (TV Do not touch any refrigerant pipes with your hands when the set or radio receiver is placed within 1m system is in operation. · Locations where drainage cannot run off safely. During operation the refrigerant pipes become extremely hot or extremely It can affect performance or function and etc. cold depending the operating condition, and it can cause burn injury or Do not install the unit near the location where leakage of frost injury. combustible gases can occur


# -1-1-• SCM-SM-110

#### BEFORE INSTALLATION

O Before installation check that the power supply matches the air conditioner.

| S   | tandard accessories (Installation kit)<br>Accessories for indoor unit | Q'ty |
|-----|---|------|
| 1   | Installation board<br>(Attached to the rear of the indoor unit)       | 1    |
| 2   | Wireless remote control   | 1    |
| 3   | Remote control holder   | 1    |
| 4   | Tapping screws<br>(for installation board ø4 X 25mm)                  | 5    |
| (5) | Wood screws<br>(for remote control switch holder ø3.5 X 16mm)         | 2    |
| 6   | Battery [R03 (AAA, Micro) 1.5V]                                       | 2    |
| 1   | Air-cleaning filters  | 2    |
| 8   | Filter holders<br>(Attached to the front panel of indoor unit)        | 2    |
| 9   | Insulation (#486 50 x 100 t3)   | 1    |

|     | Option parts  | Q'ty |
|-----|---|------|
| (a) | Sealing plate   | 1    |
| b   | Sleeve  | 1    |
| ©   | Inclination plate                                     | 1    |
| Ø   | Putty   | 1    |
| e   | Drain hose (extension hose)                           | 1    |
| ſ   | Piping cover<br>(for insulation of connection piping) | 1    |
|     |   |      |



## SELECTION OF INSTALLATION LOCATION


- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed. A solid place where the unit or the wall will not vibrate. A place where there will be enough space for servicing. (Where space mentioned below can be secured)
- Where wiring and the piping work will be easy to conduct. The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting. A place where it can be easily drained.
- A place separated at least im away from the television or the radio. (To prevent interference to images and sounds.) ) Places where this unit is not affected by the high frequency equipment or electric equipment. Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.

#### Wireless remote control

- A place where the air conditioner can be received the signal surely during operating the wireless remote control. Places where there is no affected by the TV and radio etc.
- O Do not place where exposed to direct sunlight or near heat devices such as a stove.

## **INSTALLATION OF INDOOR UNIT**






#### Drilling of holes and fixture of sleeve (Option parts)

Sufficient care must be taken not to damage

the panel when connecting pipes.



Left downward

Fixing on concrete wall

Nut


board

(M6)

Mounting

Max.10


Use of nut anchor




hexagonal wrench etc

5 cm minimum


from the wall





6.5 cm minimum from the ceiling





#### (Install at location that meets the following conditions, after getting approval from the customer) Indoor unit











# HOW TO RELOCATE OR DISPOSE OF THE UNIT

In order to protect the environment, be sure to pump down (recovery of refrigerant).
 Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

#### <How to pump down>

- Connect charge hose to check joint of outdoor unit.
   Liquid side : Close the liquid valve with hexagon wrench key.
- Gas side : Fully open the gas valve. Carry out cooling operation. (If indoor temperature is low, operate
- forced cooling operation.) ③ After low pressure gauge become 0.01MPa, stop cooling operation and close the cas valve.

 Forced cooling operation Turn on a power supply again after a while after turn off a power supply. Then press continually the ON/OFF button 5 seconds or more.




# CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

Remove the front panel and lid of control.
 Remove the control.

There is a terminal (respectively marked with CNS) for the indoor control board. In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection is IS-CBIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit.

#### For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".



## (c) Model SRK71ZK-S

#### **RKW012A400A**

- This installation manual illustrates the method of installing an indoor unit
- · For electrical wiring work, please see instructions set out on the backside.

• For outdoor unit installation and refrigerant piping, please refer to page 169.

. When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, powe supply voltage and etc.) and installation spaces.

• A wired remote control unit is supplied separately as an optional part.

## SAFETY PRECAUTIONS

 Bead the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself. . The precautionary items mentioned below are distinguished into two levels,

- WARNING and ACAUTION. WARNING : Wrong installation would cause serious consequences such
- as injuries or death. CAUTION : Wrong installation might cause serious consequences
- depending on circumstances Both mentions the important items to protect your health and safety so strictly
- follow them by any means. Be sure to confirm no anomaly on the equipment by commissioning after com
- pleted installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual
- · For installing gualified personnel, take precautions in respect to themselves by
- installation works
- the high position.



# M WARNING

# Installation must be carried out by the qualified installer.

- If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except • The electrical installation must be carried out by the gualified the by qualified installer.
- Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric ehocke and fire

#### Be sure to use only for household and residence

If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.

#### Use the original accessories and the specified components for installation.

- If parts other than those prescribed by us are used. It may cause water leaks, electric shocks, fire and personal injury.
- Install the unit in a location with good support.
- Unsuitable installation locations can cause the unit to fall and cause
- material damage and personal injury. Ventilate the working area well in the event of refrigerant leakage
- during installation. If the refrigerant comes into contact with naked flames, poisonous gas is
- produced. When installing in small rooms, take prevention measures not to
- exceed the density limit of refrigerant in the event of leakage referred by the formula (accordance with ISO5149).
- If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which
- can cause serious accident. After completed installation, check that no refrigerant leaks from
- the system.
- If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.
- Use the prescribed pipes, flare nuts and tools for R410A.
- Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.

#### O • Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.

Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak • Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.

- If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.
- Tighten the flare nut by torque wrench with specified method. If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period. electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire Be sure to shut off the power before starting electrical work. Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment. Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work Unconformable cables can cause electric leak, anomalous heat production or fire This appliance must be connected to main power supply by means of a circuit breaker or switch (fuse:20A) with a contact separation of at least 3mm When plugging this appliance, a plug conforming to the norm IEC60884-1 must be used. · Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat production or fire. Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly. Incorrect installation may result in overheating and fire. Be sure to switch off the power supply in the event of installation. inspection or servicing. If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan. · Be sure to wear protective goggles and gloves while at work. · Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it can cause electric shocks Do not processing, splice the power cord, or share a socket with other power plugs. This may cause fire or electric shock due to defecting contact, defecting

insulation and over-current etc. . Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it. This may cause fire or heating

Do not run the unit with removed panels or protections. switch and temperature controller or the use of non specified component Touching rotating equipments, hot surfaces or high voltage parts can cause can cause fire or burst. personal injury due to entrapment, burn or electric shocks **∧** CAUTION Carry out the electrical work for ground lead with care. A Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting • Use the circuit breaker of correct capacity. Circuit breaker should falling from the installation place be the one that disconnect all poles under over current. Using the incorrect one could cause the system failure and fire Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations. The isolator should be locked in OFF state in accordance with EN60204-1. Be sure to install indoor unit properly according to the installation manual in order to run off the drainage smoothly. Improper installation of indoor unit can cause dropping water into the room and damaging personal property. Install the drainage pipe to run off drainage securely according to the installation manual Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property. Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings. Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance. Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to serious accidents Do not install the unit in the locations listed below  $\bigcirc$ . Locations where carbon fiber, metal powder or any powder is floating. . Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur. · Vehicles and ships. · Locations where cosmetic or special sprays are often used. Locations with direct exposure of oil mist and steam such as kitchen and machine plant.

• Do not vent R410A into the atmosphere : R410A is a fluorinated

Warming Potential (GWP)=1975.

greenhouse gas, covered by the Kyoto Protocol with Groval

- Locations where any machines which generate high frequency harmonics
- are used. · Locations with salty atmospheres such as coastlines.
- I ocations with heavy snow (If installed, be sure to provide base flame and
- snow hood mentioned in the manual).
- Locations where the unit is exposed to chimney smoke.
- . Locations at high altitude (more than 1000m high).
- · Locations with ammonic atmospheres. Locations where heat radiation from other heat source can affect the unit.
- · Locations without good air circulation.
- . Locations with any obstacles which can prevent inlet and outlet air of the unit. under the indoor unit. . Locations where short circuit of air can occur (in case of multiple units installation).
- . Locations where strong air blows against the air outlet of outdoor unit.
- . Locations where something located above the unit could fall.
- It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire
- Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).
- Locations with any obstacles which can prevent inlet and outlet air of the unit.
- Locations where vibration can be amplified due to insufficient strength of structure.
- Locations where the infrared receiver is exposed to the direct sunlight or
- the strong light beam (in case of the infrared specification unit). . Locations where an equipment affected by high harmonics is placed (TV
- set or radio receiver is placed within 1m). · Locations where drainage cannot run off safely
- It can affect performance or function and etc.
- Do not install the unit near the location where leakage of combustible gases can occur.

· For installation work, be careful not to get injured with the heat exchanger, piping flare portion or screws etc. . Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them. Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables. When perform the air conditioner operation (cooling or drving operation) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.

Do not perform any change of protective device itself or its setup

The forced operation by short-circuiting protective device of pressure

condition

 Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant

leakage in the small room, lack of oxygen can occur, which can cause

If leaked gases accumulate around the unit, it can cause fire. · Do not install the unit where corrosive gas (such as sulfurous acid

gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled

Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire

#### Do not use the indoor unit at the place where water splashes may occur such as in laundries.

Since the indoor unit is not waterproof, it can cause electric shocks and fire Do not install nor use the system close to the equipment that

generates electromagnetic fields or high frequency harmonics. Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or

cause iamming. . Do not place any variables which will be damaged by getting wet

When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables

#### Do not install the remote control at the direct sunlight.

It can cause malfunction or deformation of the remote control Do not use the unit for special purposes such as storing foods. cooling precision instruments and preservation of animals, plants of

#### art. It can cause the damage of the items.

 Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.

Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.

· Do not touch any buttons with wet hands.

#### It can cause electric shocks . Do not touch any refrigerant pipes with your hands when the system is in operation

During operation the refrigerant pipes become extremely hot or extremely

cold depending the operating condition, and it can cause burn injury or frost iniury

-11 SCM-SM-110

- - Always do it according to the
- . Keep the installation manual together with owner's manual at a place where
- · Please pay attention not to fall down the tools, etc. when installing the unit at
- . If unusual noise can be heard during operation, consult the dealer.
  - . The meanings of "Marks" used here are shown as follows:
- any user can read at any time. Moreover if necessary, ask to hand them to a new user using suitable protective clothing, groves, etc., and then perform the

#### BEFORE INSTALLATION

O Before installation check that the power supply matches the air conditioner.

| S | tandard accessories (Installation kit)<br>Accessories for indoor unit | Q'ty |
|---|---|------|
| 1 | Installation board<br>(Attached to the rear of the indoor unit)       | 1    |
| 2 | Wireless remote control   | 1    |
| 3 | Remote control holder   | 1    |
| 4 | Tapping screws<br>(for installation board ø4 X 25mm)                  | 10   |
| 5 | Wood screws<br>(for remote control switch holder ø3.5 X 16mm)         | 2    |
| 6 | Battery [R03 (AAA, Micro) 1.5V]                                       | 2    |
| 1 | Air-cleaning filters  | 2    |
| 8 | Filter holders<br>(Attached to the front panel of indoor unit)        | 2    |
| 9 | Insulation (#486 50 x 100 t3)   | 1    |

| Option parts                                   |           |
|--|-----------|
| ⓐ Sealing plate                                | 1         |
| b Sleeve                                       | 1         |
| © Inclination plate                            | 1         |
| @ Putty  | 1         |
| Drain hose (extension hose)                    | ) 1       |
| Piping cover     (for insulation of connection | piping) 1 |

|    | Necessary tools for the installation work  |
|----|--|
| 1  | Plus headed driver   |
| 2  | Knife  |
| 3  | Saw  |
| 4  | Tape measure   |
| 5  | Hammer   |
| 6  | Spanner wrench   |
| 7  | Torque wrench $\begin{pmatrix} 14.0 \sim 82.0 \text{N·m} \\ (1.4 \sim 8.2 \text{kgf·m}) \end{pmatrix}$ |
| 8  | Hole core drill (65mm in diameter)   |
| 9  | Wrench key (Hexagon) [4m/m]  |
| 10 | Flaring tool set (Designed specifically<br>for R410A)  |
| 11 | Gas leak detector (Designed specifically for R410A   |
| 12 | Gauge for projection adjustment<br>(Used when flare is made by using)<br>conventional flare tool       |
| 13 | Pipe bender  |

# SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer)

#### Indoor unit


- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed. A solid place where the unit or the wall will not vibrate
- A place where there will be enough space for servicing. (Where space mentioned below can be secured) Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting. A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.) ) Places where this unit is not affected by the high frequency equipment or electric equipment. ) Avoid installing this unit in place where there is much oil mist.
- Places where there is no electric equipment or household under the installing unit.

#### Wireless remote control

- A place where the air conditioner can be received the signal surely during operating the wireless remote control. Places where there is no affected by the TV and radio etc.
- O Do not place where exposed to direct sunlight or near heat devices such as a stove.

# INSTALLATION OF INDOOR UNIT

Installation of Installation board



5 cm minimum

from the wall

dewina.

Completely seal the hole on

furniture, or other, may be wetted by leaked water or

the wall with putty. Otherwise,

Indoor side

Outdoor side

6.5 cm minimum from the ceiling

Sleeve (sold separately)


Installation board


10 cm minimum


from the wall

SN -


# Ξ • SCM-SM-110








# Front panel





# HOW TO RELOCATE OR DISPOSE OF THE UNIT

O In order to protect the environment, be sure to pump down (recovery of refrigerant). O Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.


#### <How to pump down>

- ① Connect charge hose to check joint of outdoor unit. 2 Liquid side : Close the liquid valve with hexagon wrench key
- Gas side : Fully open the gas valve. Carry out cooling operation. (If indoor temperature is low, operate
- forced cooling operation.) ③ After low pressure gauge become 0.01MPa, stop cooling operation and close the gas valve.

 Forced cooling operation Turn on a power supply again after a while after turn off a power supply. Then press continually the ON/OFF button 5 seconds or more.

Unit ON/OFF button

CONCERNING TERMINAL CONNECTION FOR AN INTERFACE Control cove (1) Remove the air inlet panel, lid and front panel, (2) Remove the control cover. (Remove the screw.) ③ There is a terminal (respectively marked with CNS) for the indoor control board. Indoor unit PCB In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit. For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".



# (2) Floor standing type (SRF)

#### Models SRF25, 35ZJX-S, 50ZJX-S1

• This installation manual illustrates the method of installing an indoor unit.

· For electrical wiring work, please see instructions set out on the backside.

· For outdoor unit installation and refrigerant piping, please refer to page 157 to 172.

# SAFETY PRECAUTIONS

· Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.

#### The precautionary items mentioned below are distinguished into two levels.

 WARNING and CAUTION.
 WARNING : Wrong installation would cause serious consequences such as injuries or death.

CAUTION : Wrong installation might cause serious consequences depending on circumstances.

Both mentions the important items to protect your health and safety so strictly follow them by any means.

. Be sure to confirm no anomaly on the equipment by commissioning after com-pleted installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's

manual. Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.

supply voltage and etc.) and installation spaces.

. For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the

RFB012A002B

... .

installation works. . Please pay attention not to fall down the tools, etc. when installing the unit at the high position.

• A wired remote control unit is supplied separately as an optional part.

installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power

. When install the unit, be sure to check whether the selection of

. If unusual noise can be heard during operation, consult the dealer . The meanings of "Marks" used here are shown as follows:

 $\bigcirc$ Never do it under anv Always do it according to the circumstances instruction.

### **A** WARNING

| • | <ul> <li>Installation must be carried out by the qualified installer.<br/>If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and presonal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer.</li> <li>Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.</li> <li>Be sure to use only for household and residence.<br/>If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction.</li> <li>Use the original accessories and the specified components for installation.</li> <li>If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.</li> <li>Install the unit in a location with good support.</li> <li>Unsuitable installation locations can cause the unit to fall and cause material damage and personal linjury.</li> <li>Ventilate the working area well in the event of refrigerant leakage during installation.</li> <li>If the refigerant comes into contact with naked flames, poisonous gas is produced.</li> <li>When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).</li> <li>If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation, system, otherwise lack of oxygen can occur, which can cause serious accident.</li> <li>After completed installation, check that no refrigerant leaks from the system.</li> <li>If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.</li> <li>Use the prescribed pipes, fire nuts and tools for R410A. Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circui</li></ul> | <ul> <li>Tighten the flare nut b         If the flare nut wer light         refrigerant leakage after:         Intelectrical installat         electrical         inspective         alure to shut off the         Failure to shut off the         failure to shut off the         or fire.         This appliance must b         of a circuit breaker or         at least 3mm.         When plugging this ap         IEC60884-1 must be u         Use the prescribed ca         cables securely in terr         production or fire.         Arrange the wiring in 1         further into the box. In         loncorrect installation may         Be sure to switch off t         inspection or servicing         if the power supply is no         failure or personal injury.         Be sure to wear prote         Earth leakage breaker         if the earth leakage breaker</li></ul> |
|---|--|--|
| 0 | <ul> <li>Do not put the drainage pipe directly into drainage channels where<br/>poisonous gases such as sulphide gas can occur.</li> <li>Poisonous gases will flow into the room through drainage pipe and<br/>seriously affect the user's health and safety. This can also cause the<br/>corrosion of the indoor unit and a resultant unit failure or refrigerant leak.</li> <li>Ensure that no air enters in the refrigerant circuit when the unit is<br/>installed and removed.</li> <li>If air enters in the refrigerant circuit.</li> </ul>   | Do not processing, sp<br>other power plugs.<br>This may cause fire or eli<br>insulation and over-curre<br>Do not bundling, wind<br>not deforming the pow<br>This may cause fire or here  |

# becomes too high, which can cause burst and personal injury.

| nut by torque wrench with specified method.<br>tightened with excess torque, this may cause burst and<br>after a long period.<br>tallation must be carried out by the qualified<br>ordance with "the norm for electrical work" and<br>equilation", and the system must be connected to   |   | Check if the drainage runs off securely during of<br>the space for inspection and maintenance.<br>Secure a space for installation, inspection<br>specified in the manual.<br>Insufficient space can result in accident such a  |
|--|---|--|
| guardinit, and the system must be connected to<br>juit.<br>Insufficient capacity and incorrect function done by<br>cause electric shocks and fre.<br>If the power before starting electrical work.<br>The power can cause electric shocks, unit failure or<br>t equipment.<br>The ables conformed to safety standard and cable<br>er distribution work.<br>Jess can cause electric leak, anomalous heat production<br>ust be connected to main power supply by means<br>er or switch (fuse:16A) with a contact separation of<br>the appliance, a plug conforming to the norm<br>be used.<br>I d cables for electrical connection, tighten the<br>terminal blocks.<br>or cable mountings can cause anomalous heat<br>g in the control box so that it cannot be pushed up<br>ox. Install the service panel correctly.<br>In may result in overheating and fire.<br>of the power supply in the event of installation,<br><i>icing.</i><br>is not shut off, there is a risk of electric shocks, unit<br>jury due to the unexpected start of fan.<br>rotective gogles and gloves while at work.<br>taker must be installed, it can cause electric shocks. | 0 | <ul> <li>Do not install the unit in the locations liste</li> <li>Locations where ary substances that can aff<br/>gas, chloride gas, acid and alkaline can occu</li> <li>Vehicles and ships.</li> <li>Locations where or swetic or special sprays i<br/>Locations where provide the system of all mist and<br/>machine plant.</li> <li>Locations with direct exposure of all mist and<br/>machine plant.</li> <li>Locations with salty atmospheres such as co<br/>Locations with salty atmospheres.</li> <li>Locations of mentioned in the manual).</li> <li>Locations with all suitude (more than 1000m<br/>Locations with all read crospheres.</li> <li>Locations with any obstacles which can prever<br/>Locations with any obstacles which can prever<br/>Locations where short circuit of air can occur<br/>installation).</li> <li>Locations where strong air blows against the<br/>Locations and the indoor unit in the locatio<br/>to install the indoor unit in the locatio<br/>to install the indoor unit in the location<br/>to install the indoor unit in the location the is<br/>each model because each indoor unit can prever<br/>unit.</li> </ul> |
| g, splice the power cord, or share a socket with<br>s.<br>or electric shock due to defecting contact, defecting<br>current etc.<br>winding or processing for the power cord. Or, do<br>power plug due to tread it.<br>or heating.  |   | <ul> <li>Locations where the infrared receiver is expo<br/>the strong light beam (in case of the infrared<br/>locations where an equipment affected by hi<br/>set or radio receiver is placed within 1m).</li> <li>Locations where drainage cannot run off safe<br/>tic can affect performance or function and etc.</li> </ul>   |
| or nouring.  |   | a san anset performance or function and etc.   |

#### Do not install the unit near the location where leakage of combustible gases can occur

• Do not vent R410A into the atmosphere : R410A is a fluorinated

• Do not run the unit with removed panels or protections.

Warming Potential (GWP)=1975.

greenhouse gas, covered by the Kyoto Protocol with Groval

Touching rotating equipments, hot surfaces or high voltage parts can cause can cause fire or burst.

|   | louching rotating equipments, hot surfaces or high voltage parts can cause<br>personal injury due to entrapment, burn or electric shocks.  | can cause fire or burst.  |
|---|--|---|
|   | A CAU  | TION  |
| Ð | Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conduct such as electric shocks due to short-circuiting.  | tor or telephone line's ground lead. Incorrect grounding can cause unit faults  |
| • | Using the incorrect one could cause the system failure and fire.<br>• Install isolator or disconnect switch on the power supply wiring in<br>accordance with the local codes and regulations.<br>The isolator should be locked in OFF state in accordance with EN60204-1.<br>• Be sure to install indoor unit properly according to the installation<br>manual in order to run off the drainage smoothly.<br>Improper installation of indoor unit can cause dropping water into the room<br>and damaging personal property.<br>• Install the drainage pipe to run off drainage securely according to<br>the installation of the drainage pipe can cause dropping water into the<br>room and damaging personal property.<br>• Be sure to install the drainage pipe with descending slope of 1/100<br>or more, and not to make traps and air-bleedings.  | falling from the installation place.<br>• For installation work, be careful not to get injured with the heat<br>exchanger, piping flare portion or screws etc.<br>• Be sure to insulate the refrigerant pipes so as not to condense the<br>ambient air moisture on them.<br>Insufficient insulation can cause condensation, which can lead to moisture<br>damage on the ceiling, floor, furniture and any other valuables.<br>• When perform the air conditioner operation (cooling or drying opera-<br>tion) in which ventilator is installed in the room. In this case, using the<br>air conditioner in parallel with the ventilator, there is the possibility<br>that drain water may backflow in accordance with the room lapse into<br>the negative pressure status. Therefore, set up the opening port such<br>as incorporate the air into the room that may appropriate to ventila-<br>tion (For example; Open the door a little). In addition, just as above, so<br>set up the opening port if the room lapse into negative pressure status<br>due to register of the wind for the high rise apartment etc.<br>• Be sure to perform air tightness test by pressurizing with nitrogen<br>gas after completed refrigerant piping work.<br>If the density of refrigerant exceeds the limit in the event of refrigerant<br>leakage in the small room, lack of oxygen can occur, which can cause<br>serious accidents. |
| 0 | <ul> <li>Do not install the unit in the locations listed below.</li> <li>Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>Vehicles and ships.</li> <li>Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.</li> <li>Vehicles and ships.</li> <li>Locations where any machines which generate high frequency harmonics are used.</li> <li>Locations with direct exposure of oil mist and steam such as kitchen and machine plant.</li> <li>Locations with ally atmospheres such as coastlines.</li> <li>Locations with salty atmospheres such as coastlines.</li> <li>Locations with ally atmospheres such as coastlines.</li> <li>Locations with eavy snow (fi installed, be sure to provide base flame and snow hood mentioned in the manua).</li> <li>Locations where the unit is exposed to chirmey smoke.</li> <li>Locations with ally atmospheres.</li> <li>Locations with athy atmospheres.</li> <li>Locations with athy obstacles which can prevent inlet and outlet air of the unit.</li> <li>Locations where their circulation.</li> <li>Locations where strict of air can occur (in case of multiple units installation).</li> <li>Locations where some thing located above the unit could fall.</li> <li>It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.</li> <li>Do thistall the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation).</li> <li>Locations where vibration can be amplified due to insufficient strength of structure.</li> <li>Locations where wibration can be amplified due to insufficient strength of structure.</li> <li>Locations where existent index of the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).</li> <li>Locations where divaling accord of specification unit).</li> <li>Locations where hinfrared receiver is exposed to</li></ul> | Équipment such as inverters, standby generators, medical high frequency<br>equipments and telecommunication equipments can affect the system, and<br>cause malfunctions and breakdowns. The system can also affect medical<br>equipment and telecommunication equipment, and obstruct its function or<br>cause jamming.<br>• Do not place any variables which will be damaged by getting wet  |

▲ WARNING

condition.

• Do not perform any change of protective device itself or its setup

The forced operation by short-circuiting protective device of pressure

switch and temperature controller or the use of non specified component


ot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.


SCM-SM-110


#### BEFORE INSTALLATION


OBefore installation check that the power supply matches the air conditioner


| nsta | allatio | n check that the power supply matches the air of                      | conditio |
|------|---------|---|----------|
|      | s       | tandard accessories (Installation kit)<br>Accessories for indoor unit | Q'ty     |
|      | 1       | Installation board<br>(Attached to the rear of the indoor unit)       | 1        |
|      | 2       | Wireless remote control   | 1        |
|      | 3       | Remote control holder   | 1        |
|      | 4       | Tapping screws<br>(for installation board 4dia. by 25mm)              | 9        |
|      | 5       | Wood screws<br>(for remote control switch holder 3.5(mm). by 16mm)    | 2        |
|      | 6       | Battery [R03(AAA,Micro) 1.5V]   | 2        |
|      | Ø       | Air-cleaning filters  | 2        |
|      | 8       | Filter holders<br>(Attached to the front panel of indoor unit)        | 2        |
|      | 9       | Pipe cover (200mm)  | 1        |
|      | 0       | Band  | 2        |














# **INSTALLATION TEST CHECK POINTS**

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

# After installation

- The power supply voltage is correct as the rating.
  No gas leaks from the joints of the operational valve.
  - Power cables and crossover wires are securely fixed to the terminal board.
    Operational valve is fully open.
- The pipe joints for indoor and outdoor pipes have been insulated.
- The screw of the lid is tightened securely.

#### Test run

- Air conditioning operation is normal. Operation of the unit has been explained to the customer. No abnormal noise. (Three-minutes restart preventive timer) Water drains smoothly. When the air conditioner is restarted or when changing
- Protective functions are not working.
  The remote control is normal.
- (Three-minutes restart preventive timer) When the air conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

# CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

- 1 Remove the front panel and lid of control.
- There is a terminal (respectively marked with CNS) for the indoor control board. In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit. For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".

#### Ceiling concealed type (SRR)

Models SRR25~60ZJ-S

#### RJD012A201B

 $\bigcirc$ 

• This installation manual illustrates the method of installing an indoor

· For electrical wiring work, please see instructions set out on the backside.

· For outdoor unit installation and refrigerant piping, please refer to page 157 to 172.

• Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it

during the installation work in order to protect yourself. The precautionary items mentioned below are distinguished into two levels.

A WARNING and A CAUTION

WARNING : Wrong installation would cause serious consequences such as injuries or death.

CAUTION : Wrong installation might cause serious consequences

depending on circumstances Both mentions the important items to protect your health and safety so strictly

follow them by any means Be sure to confirm no anomaly on the equipment by commissioning after com-

pleted installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

• A wired remote control unit is supplied separately as an optional part. . When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, powe supply voltage and etc.) and installation spaces.

#### SAFETY PRECAUTIONS

. Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user

 For installing gualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.

· Please pay attention not to fall down the tools, etc. when installing the unit at the high position

 If unusual noise can be heard during operation, consult the dealer The meanings of "Marks" used here are shown as follows:



# ∧ WARNII

# Installation must be carried out by the qualified installer.

If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except . Th the by qualified installer.

#### Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric

shocks and fire. Be sure to use only for household and residence.

#### If this appliance is installed in inferior environment such as machine shop

and etc., it can cause malfunction.

Use the original accessories and the specified components for installation

If parts other than those prescribed by us are used, It may cause water leaks, electric shocks, fire and personal injury.

Install the unit in a location with good support.

- Unsuitable installation locations can cause the unit to fall and cause
- material damage and personal injury. Ventilate the working area well in the event of refrigerant leakage

during installation. If the refrigerant comes into contact with naked flames, poisonous gas is

produced. When installing in small rooms, take prevention measures not to

exceed the density limit of refrigerant in the event of leakage referred by the formula (accordance with ISO5149)

If the density of refrigerant exceeds the limit please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which

can cause serious accident After completed installation, check that no refrigerant leaks from the system

If refrigerant leaks into the room and comes into contact with an oven or

other hot surface, poisonous gas is produced. Use the prescribed pipes, flare nuts and tools for R410A. Lising existing parts (for B22 or B407C) can cause the unit failure and

serious accidents due to burst of the refrigerant circuit.

#### • Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.

Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak. Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.

If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.

| RNING  |   |
|--|---|
| Tighten the flare nut by torque wrench with specified method.     If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period.     The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.     Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.     Els sure to sub toff the power can cause electric shocks, unit failure or incorrect function of equipment.     Se sure to use the cables conformed to safety standard and cable | C |
| ampacity for power distribution work.<br>Unconformable cables can cause electric leak, anomalous heat production<br>or fire.<br>• This appliance must be connected to main power supply by means<br>of a circuit breaker or switch (fuse:16A) with a contact separation of<br>at least 3mm.  |   |
| When plugging this appliance, a plug conforming to the norm<br>IEC60884-1 must be used.     Use the prescribed cables for electrical connection, tighten the<br>cables securely in terminal block and relieve the cables correctly to<br>prevent overloading the terminal blocks.<br>Loose connections or cable mountings can cause anomalous heat   |   |
| production or fire.<br>• Arrange the wiring in the control box so that it cannot be pushed up<br>further into the box. Install the service panel correctly.<br>Incorrect installation may result in overheating and fire.<br>• Be sure to switch off the power supply in the event of installation,<br>inspection or servicing.<br>If the power supply is not shut off, there is a risk of electric shocks, unit<br>failure or personal injury due to the unexpected start of fan.<br>• Be sure to wear protective goggles and gloves while at work.<br>• Earth leakage breaker must be installed.<br>If the earth leakage breaker is not installed, it can cause electric shocks.   |   |
| <ul> <li>Do not processing, splice the power cord, or share a socket with<br/>other power plugs.</li> </ul>  |   |

other power plugs This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc. Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it.

This may cause fire or heating.

Warming Potential (GWP)=1975 The forced operation by short-circuiting protective device of pressure Do not run the unit with removed panels or protections switch and temperature controller or the use of non-specified component. Touching rotating equipments, bot surfaces or bind voltage parts can cause can cause fire or burst personal injury due to entrapment, burn or electric shocks **∧** CAUTION Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting. • Use the circuit breaker of correct capacity. Circuit breaker should falling from the installation place . For installation work, be careful not to get injured with the heat be the one that disconnect all poles under over current. Lising the incorrect one could cause the system failure and fire exchanger, piping flare portion or screws etc. Install isolator or disconnect switch on the power supply wiring in . Be sure to insulate the refrigerant pipes so as not to condense the accordance with the local codes and regulations. ambient air moisture on them The isolator should be locked in OEE state in accordance with EN60204-1 Insufficient insulation can cause condensation, which can lead to moisture Be sure to install indoor unit properly according to the installation damage on the ceiling, floor, furniture and any other valuables. manual in order to run off the drainage smoothly. When perform the air conditioner operation (cooling or drving opera-Improper installation of indoor unit can cause dropping water into the room and damaging personal property Install the drainage pipe to run off drainage securely according to the installation manual Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property. Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings. due to register of the wind for the high rise apartment etc. Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance. gas after completed refrigerant piping work. Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to serious accidents. Do not install the unit in the locations listed below. If leaked gases accumulate around the unit, it can cause fire. . Do not install the unit where corrosive gas (such as sulfurous acid Locations where carbon fiber, metal powder or any powder is floating. . Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur. · Vehicles and ships. substances are handled. Locations where cosmetic or special sprays are often used. Locations with direct exposure of oil mist and steam such as kitchen and parts and etc. And combustible gas can cause fire Do not use the indoor unit at the place where water splashes may machine plant Locations where any machines which generate high frequency harmonics. occur such as in laundries are used Locations with salty atmospheres such as coastlines. Locations with heavy snow (if installed, be sure to provide base flame and
 generates electromagnetic fields or high frequency harmonics. snow bood mentioned in the manual) Equipment such as inverters, standby generators, medical high frequency Locations where the unit is exposed to chimney smoke Locations at high altitude (more than 1000m high). · Locations with ammonic atmospheres. . Locations where heat radiation from other heat source can affect the unit. cause jamming. · Locations without good air circulation. . Do not place any variables which will be damaged by getting wet . Locations with any obstacles which can prevent inlet and outlet air of the unit. under the indoor unit. . Locations where short circuit of air can occur (in case of multiple units When the relative humidity is higher than 80% or drainage pipe is clogged. installation). . Locations where strong air blows against the air outlet of outdoor unit. valuables Do not install the remote control at the direct sunlight. Locations where something located above the unit could fall It can cause remarkable decrease in performance, corrosion and damage It can cause malfunction or deformation of the remote control of components, malfunction and fire Do not install the indoor unit in the locations listed below (Be sure) to install the indoor unit according to the installation manual for art. each model because each indoor unit has each limitation). It can cause the damage of the items. . Locations with any obstacles which can prevent inlet and outlet air of the · Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used. unit. . Locations where vibration can be amplified due to insufficient strength of Connecting the circuit with copper wire or other metal thread can cause structure. unit failure and fire. . Locations where the infrared receiver is exposed to the direct sunlight or . Do not touch any buttons with wet hands. the strong light beam (in case of the infrared specification unit). It can cause electric shocks . Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m). system is in operation.

condition

Do not vent R410A into the atmosphere : R410A is a fluorinated

greenhouse gas, covered by the Kyoto Protocol with Groval

- Locations where drainage cannot run off safely
- It can affect performance or function and etc.

Do not install the unit near the location where leakage of combustible gases can occur.

tion) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status Be sure to perform air tightness test by pressurizing with nitrogen If the density of refrigerant exceeds the limit in the event of refrigerant

Do not perform any change of protective device itself or its setup

leakage in the small room, lack of oxygen can occur, which can cause

#### gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible

Corrosive gas can cause corrosion of heat exchanger, breakage of plastic

Since the indoor unit is not waterproof, it can cause electric shocks and fire • Do not install nor use the system close to the equipment that

equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or

condensation or drainage water can drop and it can cause the damage of

 Do not use the unit for special purposes such as storing foods. cooling precision instruments and preservation of animals, plants o

#### . Do not touch any refrigerant pipes with your hands when the

During operation the refrigerant pipes become extremely hot or extremely

cold depending the operating condition, and it can cause burn injury or frost injury.

-1-1-• SCM-SM-110

#### **BEFORE INSTALLATION**

O Before installation check that the power supply matches the air conditioner.

#### Indoor unit accessories

Plate (display)

| Symbol     | Part name  | Units |
|------------|--|-------|
| 1          | Wireless remote control  | 1     |
| 2          | Remote control holder  | 1     |
| 3          | Wireless receiver  | 1     |
| (4)        | Installation frame (for wireless receiver)                     | 1     |
| (5)        | Drain hose   | 1     |
| 6          | Clamp (for drain hose)   | 1     |
| $\bigcirc$ | Battery [R03 (AAA, Micro) 1.5V]                                | 2     |
| 8          | Large washer (for hanging bolt M8)                             | 8     |
| 9          | Flat head wood screw (for remote control holder \$\phi 3.5x16) | 2     |
| 10         | Flat head machine screw (for wireless receiver M3.5x10)        | 2     |
| 1          | Tapping screw (for clamp, $\phi 4x8$ )                         | 1     |
|            |  |       |

| Symbol | Part name                                | Units |
|--------|--|-------|
| a      | Blowout duct joint model RFJ22           | 1     |
| b      | Drain up kit model RDU12E                | 1     |
| ©      | Back side suction filter set model RBF12 | 1     |
| d      | Lower suction grill set model RTS12      | 1     |

#### Parts to be prepared by the operative side

| Symbol | Part name                  | Units |
|--------|----------------------------|-------|
| A      | Drain hose                 | 1     |
| B      | Ceiling hanging bolts (M8) | 4     |
| C      | Nuts (M8)                  | 8     |
| D      | Spring lock washers (M8)   | 4     |

# Necessary tools for the installation work

- Plus headed driver
- Knife
- Saw
- Tape measure
- Hammer
- Spanner wrench
- Torque wrench [14.0 ~ 62.0 N·m (1.4 ~ 6.2 kgf·m)]
- Hole core drill (65mm in diameter)
- Wrench key (Hexagon) [4 m/m]
- Vacuum pump
- Vacuum pump adapter (Anti-reverse flow type) (Designed specifically for R410A)
- Gauge manifold (Designed specifically for R410A)
- Charge hose (Designed specifically for R410A)
- Flaring tool set (Designed specifically for R410A)
- Gas leak detector (Designed specifically for R410A)
- Gauge for projection adjustment
- (Used when flare is made by using conventional flare tool)

# 1 SELECTION OF INSTALLING LOCATION

(Install the unit with the customer's consent at a location that meets the following conditions.)

1

#### Indoor unit

12

190


- Where there are no barriers to the breeze, and where cool/hot air may diffuse throughout the room.
- A firm location that may sustain the weight of the unit, and do not cause the unit or the ceiling to vibrate.
- A location that allows room for maintenance.
- Where wiring and plumbing may be performed with ease.
- Where water may be drained easily.
- Where the unit is not influenced by the television, stereo, radio, or the lights.
- Where the unit is not influenced by high frequency equipment and wiring equipment.
- Where oil splashes do not occur frequently.
- Where sunlight and strong lights do not directly hit the receiver.
- A flat ceiling surface (bottom of ceiling).
- Where the suction inlet of the unit is located far from the air inlet on the ceiling, the entire inside of ceiling acts as an air suction duct so that the capacity is reduced at the startup. In such occasion, it is recommended to install a duct at the air suction side.
- Where the suction inlet of the unit does not match the air inlet and there is not sufficient clearance between the unit and the ceiling face, the capacity is reduced. It is necessary to enable the air suction from the back by using optional parts © (Back side suction filter set model RBF12).

#### Wireless remote control

- Where the main unit can definitely detect the signals from the wireless remote control.
- Where it is not influenced by television or stereo.
- Avoid locations with direct sunlight or around heaters.
- Do not attach to weak walls such as a mud wall.

#### Maximum pipe length


The maximum lengths and height differences for the pipes differ according to their outdoor unit. Please refer the Installation Instructions for the outdoor unit.




Clamp

#### Installation of wireless remote control

#### Mounting method of battery






P9

Drain hose

(Connection opening diameter ø16)

135 78 Liquid side pipes



<u>A</u>

Air filte


L£

Unit main body



Plan

₹ }



- The drain hose should be set in a downward slope (over 1/100), and it should not have any bumps or traps along its route
- O When you are obliged to route the drain hose with a trap in its way or in an ascending gradient, please use an option part Drain up kit (RDU12E) (b)
- O The indoor drain hose must be insulated.

#### **3** CONNECTION OF REFRIGERANT PIPINGS

• Regarding the change in the sizes of gas side pipes (usage of the variable joints): If the 5.0 kw and 6.0 kw class indoor units (gas side pipe 12.7) is going to be connected to the operation valves (9.52), variable joints available as accessories must be applied to the gas side operation valves.


#### [Connection of pipes]

#### NOTE

192

• Cover the pipes with tape so that dust and sand do not enter the pipe until they are connected. • When connecting the pipes to the outdoor unit, be careful about the discharge of fluorocarbon gas or oil. Make sure to match the pipes between the indoor unit and the outdoor unit with the correct operation valves.

#### (1) Preparations



Liquid side : 14.0 ~ 18.0 N·m (1.4 ~ 1.8 kgf·m) Gas side (  $\phi$  9.52) : 33.0 ~ 42.0 N·m (3.3 ~ 4.2 kgf·m)

 $(\phi 12.7)$ : 49.0 ~ 61.0 N·m (4.9 ~ 6.1 kgf·m)

#### (2) Connection



HEAT INSULATION FOR JOINTS 4 Heat insulation for joints Finish and fixing Cover the joint with Pipe clamp Apply exterior tape and insulation material shape along the place Position so Pines Vinvl tape for the indoor unit where the pipes will be the slit and tape it. - Exterior tape routed. Secure to the comes on top COU wall with a pipe clamp. Crossover wires Be careful not to s P Drain hose damage the pipes and Tapping screw the wires.

#### 5 TEST RUN AND HANDLING INSTRUCTIONS

#### Installation test check points

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the instruction manual. If the compressor does not operate after the operation has started, wait for 5-10 minutes. (This may be due to delayed start.)

(Three-minute restart preventive timer)

When the air conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3minutes. This is to protect the unit and it is not a malfunction.

Test run

No abnormal noise.

UWater drains smoothly.

#### After installation

- ☐ The power supply voltage is correct as the rating.
- □ No gas leaks from the joints of the operation valve.
- Power cables and crossover wires are securely fixed to
- the terminal board.
- Each indoor and outdoor unit is properly connected (no wrong wiring or piping).
- Operation valve is fully open.
- Refrigerant has been additionally charged (when the total pipe length exceeds the refrigerant charged pipe length).
- The pipe joints for indoor and outdoor pipes have been
- insulated.
- Earthing work has been conducted properly.
- The screw of the control lid is tightened securely.

#### EARTHING WORK

- O Earth work shall be carried out without fail in order to prevent electric shock and noise generation.
- O The connection of the earth cable to the following substances causes dangerous failures, therefore it shall never be done. (City water pipe, Town gas pipe, TV antenna, lightning conductor, telephoneline, etc.)

#### GAS LEAK DETECTOR • Check that there are no gas leaks from the pipe joints using a leak detector or soap water. Indoor unit inspection point

Air conditioning and heating are normal.

Protective functions are not working.

The wireless remote control is normal.

Operation of the unit has been

explained to the customer.

# (4) Ceiling cassette-4way compact type (FDTC)

PJA012D786

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to the electrical wiring work installation manual. For remote controller installation, refer to the installation manual attached to a remote controller. For wireless kit installation, refer to the installation manual attached to a wireless kit. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 157 to 172. This unit must always be used with the panel.

## SAFETY PRECAUTIONS

• Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself. The precautionary items mentioned below are distinguished into two levels, <u>AWARNING</u> and <u>ACAUTION</u>. <u>AWARNING</u>: Wrong installation would cause serious consequences such as injuries or death. <u>ACAUTION</u>: Wrong installation might cause serious consequences depending on circumstances. customer show "SAFETY PREOAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit. Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed. 

| Alastellation should be as formed by the second if at  |                          |
|--|--------------------------|
| Installation should be performed by the specialist. If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.                             | U                        |
| Install the system correctly according to these installation manuals.  |                          |
| Improper installation may cause explosion, injury, water leakage, electric shock, and fire.  | Ð                        |
| When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the   | -                        |
| event of leakage, referred by the formula (accordance with ISO5149).   |                          |
| If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of   | Ð                        |
| oxygen can occur, which can cause serious accidents.   |                          |
| Use the genuine accessories and the specified parts for installation.  |                          |
| If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overtum of the unit.  | U                        |
| Ventilate the working area well in case the refrigerant leaks during installation.   | Ø                        |
| If the refrigerant contacts the fire, toxic gas is produced.   | •                        |
| Install the unit in a location that can hold heavy weight.   | Q                        |
| Improper installation may cause the unit to fall leading to accidents.   | Ŀ                        |
| Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.   | Ø                        |
| Improper installation may cause the unit to fall leading to accidents.   | Ŀ                        |
| Do not mix air in to the cooling cycle on installation or removal of the air conditioner.  | $\sim$                   |
| If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.   | $\overline{\mathcal{O}}$ |
| Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.  | Q                        |
| Power source with insufficient capacity and improper work can cause electric shock and fire.   | U                        |
| Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in   |                          |
| order not to apply unexpected stress on the terminal.  | Ø                        |
| Loose connections or hold could result in abnormal heat generation or fire.  | _                        |
| Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services  |                          |
| panel property.<br>Improper fitting may cause abnormal heat and fire.  | U                        |
| Check for refrigerant gas leakage after installation is completed.   | _                        |
| If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.  | Ø                        |
| Use the specified pipe, flare nut, and tools for R410A.  | -                        |
| Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.  | e                        |
| • Tighten the flare nut according to the specified method by with torque wrench.   |                          |
| If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.  | Ø                        |
| Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.  | -                        |
| Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also   | $ \land $                |
| cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.   | $\bigcirc$               |
| Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.   | -                        |
| If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due  | e                        |
| to abnormal high pressure in the system.   | _                        |
| • Stop the compressor before removing the pipe after shutting the service valve on pump down work.   | -                        |
| If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit<br>and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle. | U                        |
| •Only use prescribed optional parts. The installation must be carried out by the qualified installer.  |                          |
| If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.  | e                        |
| •Do not repair by yourself. And consult with the dealer about repair.  | $\overline{}$            |
| Improper repair may cause water leakage, electric shock or fire.   | $\mathcal{O}$            |
| Consult the dealer or a specialist about removal of the air conditioner.   |                          |
| Improper installation may cause water leakage, electric shock or fire.   | U                        |
| •Turn off the power source during servicing or inspection work.  |                          |
| If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.   | Ø                        |
| Do not run the unit when the panel or protection guard are taken off.  | -                        |
|  | $\sim$                   |
| Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine to get   | $( \setminus$            |
| Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.   | 0                        |
|  |                          |

| $\left( \right)$ | ▲ CAUTION   |                       |
|------------------|---|-----------------------|
|                  | Perform earth wiring surely.<br>Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could<br>cause unit failure and electric shock due to a short circuit.<br>Earth leakage breaker must be installed.  | 0                     |
|                  | If the earth leakage breaker is not installed, it can cause electric shocks.<br>9 Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all  | •                     |
|                  | poles under over current.<br>Using the incorrect one could cause the system failure and fire.   |                       |
|                  | Do not use any materials other than a fuse of correct capacity where a fuse should be used.   | $\overline{\bigcirc}$ |
|                  | Connecting the circuit by wire or copper wire could cause unit failure and fire. Do not install the indoor unit near the location where there is possibility of flammable gas leakages. If the gas leaks and gathers around the unit, it could cause fire.  | $\overline{\bigcirc}$ |
|                  | Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled. It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.  | $\bigcirc$            |
|                  | Secure a space for installation, inspection and maintenance specified in the manual.<br>Insufficient space can result in accident such as personal injury due to falling from the installation place.   | 0                     |
|                  | Do not use the indoor unit at the place where water splashes such as laundry.   | <u>त</u>              |
|                  | Indoor unit is not waterproof. It could cause electric shock and fire.  Do not use the indoor unit for a special purpose such as food storage, cooling for precision  | $\frac{3}{3}$         |
|                  | instrument, preservation of animals, plants, and a work of art.<br>It could cause the damage of the items.  | $\bigcirc$            |
|                  | Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.<br>Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication<br>equipment might influence the air conditioner and cause a matfunction and breakdown. Or the air conditioner might<br>influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.   | $\bigcirc$            |
|                  | Do not install the remote controller at the direct sunlight.<br>It could cause breakdown or deformation of the remote controller.   | $\bigcirc$            |
|                  | Do not install the indoor unit at the place listed below.   |                       |
|                  | Places where flammable gas could leak.     Places where cosmetics or special sprays are     Places where cosmetics or special sprays are     Places where the substances which affect the air conditioner are generated     such as suffix gas, add, alkal or annonic, atmospheres.     Places where the system is affected by     Places where the system is affected by     smoke from a chinney.     Phaces where machinery which enerates high harmonics is used.   | $\odot$               |
|                  | Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation) Locations with any obstacles which can prevent inite and outlet air of the unit Locations where vibration can be amplified due to insufficient strength of structure. Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit) Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m) Locations where drainage cannot run off safely. It can affect performance or function and etc | $\bigcirc$            |
|                  | Do not put any valuables which will break down by getting wet under the air conditioner.<br>Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.   | $\bigcirc$            |
|                  | Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.<br>It could cause the unit falling down and injury.   | $\bigcirc$            |
|                  | Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.<br>If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water.<br>To avoid damaging, keep the indoor unit packed or cover the indoor unit.  | 0                     |
|                  | Install the drain pipe to drain the water surely according to the installation manual.<br>Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.  | 0                     |
|                  | Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and safety.   | $\odot$               |
|                  | Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.<br>If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can<br>occur, which can cause serious accidents.  | 0                     |
|                  | For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.<br>Check if the drainae is correctly done during commissioning and ensure the space for inspection and maintenance.   |                       |
|                  | Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.   | 0                     |
|                  | Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.  Do not install the outdoor unit where is likely to be a nest for insects and small animals.   |                       |
|                  | Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to<br>keep the surroundings clean. Pay extra attention, carrying the unit by hand.  | $\bigcirc$            |
|                  | Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit<br>by hand. Use protective gloves in order to avoid injury by the aluminum fin.  | 0                     |
|                  | make sure to uspose or the packaging material.<br>Leaving the materials may cause injury as metals like nail and woods are used in the package.<br>Do not operate the system without the air filter.  |                       |
|                  | It may cause the breakdown of the system due to clogging of the heat exchanger.   | $\bigcirc$            |
|                  | Do not touch any button with wet hands.<br>It could cause electric shock.   | $\bigcirc$            |
|                  | Do not touch the refrigerant piping with bare hands when in operation.<br>The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbile.   | $\bigcirc$            |
|                  | The pipe daming operation in real accessing why increase and accessing on the operating containing and in course cause a sum of restance.<br>Do not clean up the air conditioner with water.<br>It could cause electric shock.  | $\overline{\Diamond}$ |
|                  | Do not turn off the power source immediately after stopping the operation.  | $\overline{\Diamond}$ |
|                  | Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown. Do not control the operation with the circuit breaker.  |                       |
|                  | It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.  | $\bigcirc$            |

# ① Before installation

- Install correctly according to the installation manual.

 Confirm the following points:
 O Unit type/Power supply specification O Pipes/Wires/Small parts O Accessory items

| For unit             | hanging                     |                                       | For refrigerant pipe  |                          |   | For dra                                   | om pipe    |                            |
|----------------------|-----------------------------|---------------------------------------|-----------------------|--------------------------|---|---|------------|----------------------------|
| Flat washer<br>(M10) | Level gauge<br>(Insulation) | Pipe cover(big)                       | Pipe cover<br>(small) | Strap                    | Pipe cover(big)                           | Pipe cover(small)                         | Drain hose | Hose clamp                 |
| $\bigcirc$           |                             | 5                                     | 6                     | F                        | $\bigcirc$                                | Ø   | ø          | Ø                          |
| 8                    | 4                           | 1                                     | 1                     | 4                        | 1   | 1   | 1          | 1                          |
|                      | in hoisting in the          | For heat<br>insulation<br>of gas pipe |                       | For pipe cover<br>fixing | For heat<br>insulation<br>of drain socket | For heat<br>insulation<br>of drain socket |            | For drain hose<br>mounting |


#### 2 Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user

- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling. Areas where there is enough space to install and service.
- Areas where it can be drained properly. Areas where drain pipe descending slope can be taken. Areas where there is no obstruction of airflow on both air return grille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%. This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air conditioner is operated under the severer condition than mentioned above If there is a possibility to use it under such a condition, attach additional insulation of 10 to
- 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.) Areas where any items which will be damaged by getting wet are not placed such as food, table
- wares, server, or medical equipment under the unit. Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer. Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.
- A beam from lighting device sometimes affects the infrared receiver for the wireless remote controller and the air conditioner might not work properly.)
- 2 Check if the place where the air conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling. ③ If there are 2 units of wireless type, keep them away for more than 5m to avoid malfunction due to
- cross communication
- When plural indoor units are installed nearby, keep them away for more than 4m.

#### Space for installation and service


- When it is not possible to keep enough space between indoor unit and wall or between indoor units close the air supply port where it is not possible to keep space and confirm there is no short circuit of airflow
- Install the indoor unit at a height of more than 2.5m above the floor



#### **③** Preparation before installation

- If suspension bolt becomes longer, do reinforcement of earthquake resistant. O For grid ceiling
- When suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt. O In case the unit is hanged directly from the slab and is installed on the ceiling plane which has
- enough strength. When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.
- Prepare four (4) sets of suspension bolt, nut and spring washer (M10 or M8) on site.

#### Ceiling opening, Suspension bolts pitch, Pipe position




## ④ Installation of indoor unit

#### Work procedure

- This units is designed for 2 x 2 grid ceiling.
- If necessary, please detach the T bar temporarily before you install it. If it is installed on a ceiling other than 2 x 2 grid ceiling, provide an inspection port on the control box
- side
- Arrange the suspension bolt at the right position (530mm×530mm).
- Make sure to use four suspension bolts and fix them so as to be able to hold 500N load. 3 Ensure that the lower end of the suspension bolt should be 45mm above the ceiling plane. Temporarily put the four lower nuts 88mm above the ceiling plane and the upper nuts on distant place from the lower nuts in order not to obstruct hanging the indoor unit or adjust the indoor unit position, and then hang the indoor unit.



Adjust the indoor unit position after hanging it by inserting the level gauge attached on the package into the air supply port and checking if the gap between the ceiling plane and the indoor unit is appropriate. In order to adjust the indoor unit position, adjust the lower nuts while the upper nuts are put on distant place. Confirm there is no backlash between the hanger plate for suspension bolt and the lower nut and washer.



#### ④ Installation of indoor unit (continued)

- Make sure to install the indoor unit horizontally. Confirm the levelness of the indoor unit with a level gauge or transparent hose filled with water. Keep the height difference at both ends of
- the indoor unit within 3mm Tighten four upper nuts and fix the unit after height and levelness adiustment
- Caution
- Do not adjust the height by adjusting upper nuts. It will cause unexpected stress on the indoor unit and it will lead to deformation of the unit, failure of attaching a panel, and generating noise from the fan.
- Make sure to install the indoor unit horizontally and set the gap between the unit underside and the ceiling plane properly. Improper installation may cause air leakage, dew condensation, water leakage and noise.
- Even after decorative panel attached, still the unit height can be adjusted finely. Refer to the
  installation manual for decorative panel for details.
- Make sure there is no gap between decoration panel and ceiling surface, and between decoration panel and the indoor unit. The gap may cause air leakage, dew condensation and water leakage.
   In case decorative panel is not installed at the same time, or ceiling material is installed after the
- unit installed, put the cardboard template for installation attached on the package (packing material of cardboard box) on the bottom of the unit in order to avoid dust coming into the indoor unit.

# **⑤** Refrigerant pipe

#### Caution

- Use the new refrigerant pipe
- When re-using the existing pipe system for R22 or R407C, pay attention to the following items. Change the flare nuts with the attached ones (JIS category 2), and reprocess the flare parts.
- Do not use thin-walled pipes.
   Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H3300) for refrigeration pipe installation.

- refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes. Do not use any refrigerant other than R410A. Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc. Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dir or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown etc.
- compressor breakdown, etc.
  Use special tools for R410 refrigerant.

#### Work procedure

- Remove the flare nut and blind flanges on the pipe of the indoor unit
- Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them
- Clas may come out at this time, but it is not abnormal.)
   Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
- 2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit. 8 Bend the pipe with as big gradius as possible and do not bend the pipe repeatedly. In addition, do not twist and crush the pipes.
  - \* Do a flare connection as follows:
  - Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them
- When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table below. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe. Cover the flare connection part of the indoor unit with attached insulation material after a gas
- 3. eakage inspection, and tighten both ends with attached straps.
   Make sure to insulate both gas pipes and liquid pipes completely
- ※ Incomplete insulation may cause dew condensation or water dropping.

Refrigerant is charged in the outdoor unit. As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

|               |                       | Strap (Accessory) Pipe cover (Accessory)            |
|---------------|-----------------------|---|
| Pipe diameter | Tightening torque N-m |   |
| φ 6.35        | 14 to 18              |   |
| φ 9.52        | 34 to 42              |   |
| φ 12.7        | 49 to 61              | TTTTTT ATTTTTT                                      |
| φ 15.88       | 68 to 82              |   |
| φ 19.05       | 100 to 120            | The thickness of insulation should be 20mm or more. |

#### 6 Drain pipe

#### Caution


- Install the drain pipe according to the installation manual in order to drain properly. Imperfection in draining may cause flood indoors and wetting the household goods etc. Do not put the drain pipe directly into the dirth where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious
- damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell. Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe property to avoid condensation drop.
   Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance


# 6 Drain pipe (continued)

#### Work procedure

Indoor unit

- 1. Make sure to insert the drain hose (the end mode of soft PVC) to the end of the step part of drain socket
  - Attach the hose clamp to the drain hose around 10mm from the end, and fasten the screw within 5mm left to the nut
  - Do not apply adhesives on this end.






- Prepare a joint for connecting VP-20 pipe, adhere and connect the joint to the drain hose (the end made of rigid PVC), and adhere and connect VP-20 pipe (prepare on site). 2.
  - \* As for drain pipe, apply VP-20 made of rigid PVC which is on the market.
  - Make sure that the adhesive will not get into the supplied drain hose.
  - It may cause the flexible part broken after the adhesive is dried up and gets rigid. Do not bend or make an excess offset on the drain hose as shown in the picture Bend or excess offset will cause drain leakage.



- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway
  - Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
  - Do not set up air vent.




• When sharing a drain pipe for more than one unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP-30 or bigger size for main drain pipe.



- Insulate the drain pipe. ding s • Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause
- dew condensation and water leakage. % After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.

#### Drain up

 The position for drain pipe outlet can be raised up to 600mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



# 6 Drain pipe (continued)

# Drain test


- After installation of drain pipe, make sure that drain system work in good condition and no water leakage from joint and drain pan. Check if the motor sound of drain pump is normal or not.
- Do drain test even if installation of heating season. For new building cases, make sure to complete the test before
- hanging the ceiling. 1. Pour water of about 1000cc into the drain pan in the indoor unit by
- pump so as not to get the electrical component wet. Make sure that water is drained out properly and there is no water leakage from any joints of the drain pipe at the test.
- Confirm that the water is properly drained out while the drain motor is operating. At the drain socket (transparent), it is possible to check if the water is drained out properly. 3. Unplug the drain plug on the indoor unit to remove remaining water
- on the drain pan after the test, and re-plug it. And insulate the drain pipe properly finally.

#### Drain pump operation

- O In case electrical wiring work finished
- Drain pump can be operated by remote controller (wired). For the operation method, refer to Operation for drain pump in the installation manual for wiring
- work.
- O In case electrical wiring work not finished
- The case electrical mining work not instead Drain pump will run continuously when the dip switch "SW7-1" on the indoor unit PCB is turned ON, the Connector CNB is disconnected, and then the power supply (220-240VAC on the terminal block [ ① and ②] or [ ① and ⑧ ] ) is turned ON. Make sure to turn OFF "SW7-1" and reconnect the Connector CNB after the test.

# ⑦ Wiring-out position and wiring connection

- Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country. Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause
- miscommunication and malfunction. Be sure to do D type earth work.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring work.
- Remove a lid of the control box (1 screws).



#### (8) Panel installation

- After wiring work finished, install the panel on the indoor unit.
- Refer to attached panel installation manual for details.

#### Accessory items

O

Drain plug

| 1 | Hook  | 749  | 1 piece  | For fixing temporarily   |
|---|-------|--|----------|--------------------------|
| 2 | Chain | recorder   | 2 pieces |                          |
| 3 | Bolt  | () Jamma   | 4 pieces | For installing the panel |
| 4 | Screw | (Jan Barra and B | 1 piece  | For attaching a hook     |
| 5 | Screw | (Jun   | 2 pieces | For attaching a chain    |
|   |       |  |          |                          |

Attach the panel on the indoor unit after electrical wiring work.

Refer to attached manual for panel installation for details. (See next page)

#### (9) Check list after installation

Check the following items after all installation work completed.

| Check if   | Expected trouble                  | Check |
|--|-----------------------------------|-------|
| The indoor and outdoor units are fixed securely?             | Falling, vibration, noise         |       |
| Inspection for leakage is done?                              | Insufficient capacity             |       |
| Insulation work is properly done?                            | Water leakage                     |       |
| Water is drained properly?                                   | Water leakage                     |       |
| Supply voltage is same as mentioned in the model name plate? | PCB burnt out, not working at all |       |
| There is mis-wiring or mis-connection of piping?             | PCB burnt out, not working at all |       |
| Earth wiring is connected properly?                          | Electric shock                    |       |
| Cable size comply with specified size?                       | PCB burnt out, not working at all |       |
| Any obstacle blocks airflow on air inlet and outlet?         | Insufficient capacity             |       |

PJAO12D786


[Figure 1]


[Figure 2]

C- G--

# PANEL INSTALLATION MANUAL

Please read this manual together with the indoor unit's installation manual.





# 5 Panel installation


Install the panel on the unit after completing the electrical wiring.


#### Accessories

| 1 | Hook  | 769       | 1 piece  | For fixing temporarily |
|---|-------|-----------|----------|------------------------|
| 2 | Chain | vaccopoor | 2 pieces |                        |
| 3 | Screw | Dama      | 4 pieces | For hoisting the panel |
| 4 | Screw | Thu       | 1 piece  | For attaching a hook   |
| 5 | Screw | 6 jun     | 2 pieces | For attaching a chain  |

- Screw in two bolts out of the four supplied with the panel by about slightly less than 5mm.
   (● mark ⑧ ⑧) [Figure 1]
- Attach the hook supplied with the panel to the main body with the hook fixing screw (1 screw). [Figure 2]
- 3. Open the intake grille.
- 4. Please remove the screw of a corner panel and remove a corner panel. (four places)

5. A panel is hooked on two bolts (
 mark 
B).






PFA012D621B


# (5) Ceiling suspended type (FDEN)

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to the electrical wiring work installation manual. For remote controller installation, refer to the installation manual attached to a remote controller. For wireless kit installation, refer to the installation manual attached to a wireless kit. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to Page 165 to 172.

| SAFETY PRECAUTIONS<br>Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the instal<br>in order to protect yourself.<br>The precautionary items mentioned below are distinguished into two levels, <u>AWARNING</u> and <u>AWARNING</u> .<br><u>WARNING</u> : Wrong installation would cause serious consequences such as injuries or death.<br><u>GAURION</u> : Wrong installation might cause serious consequences depending on circumstance.   |                     |
|---|---------------------|
| in order to protect yourself. The precautionary items mentioned below are distinguished into two levels, <u>AWARNING</u> and <u>XWARNING</u> : Wrong installation would cause serious consequences such as injuries or death.   |                     |
| The precautionary items mentioned below are distinguished into two levels, [AWARNING] and [AWARNING]: Wrong installation would cause serious consequences such as injuries or death.  |                     |
| WARNING: Wrong installation would cause serious consequences such as injuries or death.   |                     |
|   | ZONOTION .          |
|   | 20                  |
| Both mentions the important items to protect your health and safety so strictly follow them by a  |                     |
| The meanings of "Marks" used here are as shown as follows:  | ny means.           |
| Image: Initial initialinitial initinitial initial initial initial initial initial init                      |                     |
| After completing the installation, do commissioning to confirm there are no abnormalities, and ex   | nlain to tho        |
| customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (   |                     |
| cleaning, operation method and temperature setting method) with user's manual of this unit.   |                     |
| Ask your customers to keep this installation manual together with the user's manual. Also, ask then   | m to hand           |
| over the user's manual to the new user when the owner is changed.   | n to nanu           |
| · · · · · · · · · · · · · · · · · · ·   |                     |
| <b>▲ WARNING</b>  |                     |
| Installation should be performed by the specialist.   | 0                   |
| If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the  | unit.               |
| Install the system correctly according to these installation manuals.   | •                   |
| Improper installation may cause explosion, injury, water leakage, electric shock, and fire.  When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in   | the                 |
| event of leakage, referred by the formula (accordance with IS05149).  |                     |
| If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack o   | , <b>D</b>          |
| If the density of reinigerant exceeds the limit, prease consult the dealer and install the ventilation system, otherwise fack of<br>oxygen can occur, which can cause serious accidents.  |                     |
|   |                     |
| Use the genuine accessories and the specified parts for installation.   |                     |
| If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the  | ulit.               |
| Ventilate the working area well in case the refrigerant leaks during installation.  |                     |
| If the refrigerant contacts the fire, toxic gas is produced.  | •                   |
| Install the unit in a location that can hold heavy weight.  |                     |
| Improper installation may cause the unit to fall leading to accidents.  | • •                 |
|   |                     |
| Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes   | • 0                 |
| Improper installation may cause the unit to fall leading to accidents.  |                     |
| Do not mix air in to the cooling cycle on installation or removal of the air conditioner.   | $\sim$              |
| If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.  | U U                 |
| Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.   |                     |
| Power source with insufficient capacity and improper work can cause electric shock and fire.  | • •                 |
|   |                     |
| Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable secure<br>order not to apply unexpected stress on the terminal.  | <sup>#y III</sup> 🚺 |
|   |                     |
| Loose connections or hold could result in abnormal heat generation or fire.   |                     |
| Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the service and any set of the set of the service and set of the set |                     |
| panel property.   | • •                 |
| Improper fitting may cause abnormal heat and fire.  |                     |
| Check for refrigerant gas leakage after installation is completed.  |                     |
| If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced  |                     |
| Ouse the specified pipe, flare nut, and tools for R410A.  | _                   |
|   | • •                 |
| Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.   |                     |
| Tighten the flare nut according to the specified method by with torque wrench.  | 0                   |
| If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.   | -                   |
| Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can or   | cur.                |
| Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also  | ~ `                 |
| cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.  |                     |
| -   |                     |
| Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.  | s due 🚺             |
| If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injurie<br>to abnormal binb pressure in the system   | s alle 🙂            |
| to determinal right product of the operation  |                     |
| Stop the compressor before removing the pipe after shutting the service valve on pump down work.  |                     |
| If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration of  | circuit 🕛           |
| and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.   |                     |
| Only use prescribed optional parts. The installation must be carried out by the qualified installer.  | 0                   |
| If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.   | •                   |
| Do not repair by yourself. And consult with the dealer about repair.  |                     |
| Improper repair may cause water leakage, electric shock or fire.  | $\sim$              |
|   |                     |
| Consult the dealer or a specialist about removal of the air conditioner.  | 0                   |
|   |                     |
| Improper installation may cause water leakage, electric shock or fire.  |                     |
| Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work.   |                     |
|   | 0                   |
| Turn off the power source during servicing or inspection work.<br>If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.  | -                   |
| <ul> <li>Turn off the power source during servicing or inspection work.</li> <li>If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.</li> <li>Do not run the unit when the panel or protection guard are taken off.</li> </ul>   | -                   |
| Turn off the power source during servicing or inspection work.<br>If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.  |                     |

|   | ▲ CAUTION  |                       |
|---|--|-----------------------|
|   | Perform earth wiring surely.<br>Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could<br>cause unit failure, electric shock and fire due to a short circuit.   | •                     |
|   | Earth leakage breaker must be installed.<br>If the earth leakage breaker is not installed, it can cause fire and electric shocks.  | 0                     |
|   | Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all<br>poles under over current.  | 0                     |
| _ | Using the incorrect one could cause the system failure and fire. Do not use any materials other than a fuse of correct capacity where a fuse should be used.   |                       |
|   | Connecting the circuit by wire or copper wire could cause unit failure and fire.<br>Do not install the indoor unit near the location where there is possibility of flammable gas leakages.   | $\underline{\otimes}$ |
|   | If the gas leaks and gathers around the unit, it could cause fire.   | $\bigcirc$            |
|   | Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such<br>as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled<br>it could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.  |                       |
|   | Secure a space for installation, inspection and maintenance specified in the manual.<br>Insufficient space can result in accident such as personal injury due to falling from the installation place.  | 0                     |
|   | Do not use the indoor unit at the place where water splashes such as laundry.  | $\overline{\Diamond}$ |
| • | Indoor unit is not waterproof. It could cause electric shock and fire. Do not use the indoor unit for a special purpose such as food storage, cooling for precision  |                       |
|   | instrument, preservation of animals, plants, and a work of art.<br>It could cause the damage of the items.   | $\odot$               |
|   | Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.<br>Equipments like inverter equipment, private power generator, high-frequency medical equipment, ori telecommunication<br>equipment might influences the air conditioner and cause a malfunction and breakdown. Of the air conditioner might<br>influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.  | $\bigcirc$            |
|   | Do not install the remote controller at the direct sunlight.<br>It could cause breakdown or deformation of the remote controller.  | $\bigcirc$            |
|   | Do not install the indoor unit at the place listed below.  |                       |
|   | Places where fammable gas could leak.     Places where cosmetics or special sprays an     Places where cosmetics or special sprays an     Places where cosmetics or special sprays an     Places where the substances which after the air conflorer are generated     such as utilde gas, chindre gas, aid, alkail or annoir atmospheres.     Places where cosmetics or special sprays an     Places where the system is affected by     Places where the system is affected by     Sindle stancing which generates high harmonics is used.     Alture over 1000m  | $\otimes$             |
|   | Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit<br>according to the installation manual for each model because each indoor unit has each limitation)<br>- Locations with any obstacles which can prevent inite and outlet air of the unit<br>- Locations where whatlor can be amplified due to insificient strength of structure.<br>- Locations where he infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the<br>infrared specification unit)<br>- Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)<br>- Locations where drainage cannot run off safely. | $\odot$               |
| • | Do not put any valuables which will break down by getting wet under the air conditioner.<br>Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.  | $\bigcirc$            |
| • | Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.  | $\overline{a}$        |
| • | It could cause the unit failing down and injury.<br>Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.<br>If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water.<br>To avoid damaging, keep the indoor unit packed or cover the indoor unit.   | 0                     |
|   | Install the drain pipe to drain the water surely according to the installation manual.<br>Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.   | 0                     |
| • | Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and safety.  | $\odot$               |
|   | Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.<br>If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can<br>occur, which can cause serious accidents.   | 0                     |
|   | For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps,<br>and not to make air-bleeding.<br>Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.  | 0                     |
|   | Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.<br>Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.  | 0                     |
|   | Do not install the outdoor unit where is likely to be a nest for insects and small animals.<br>Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to  | Õ                     |
|   | keep the surroundings clean.<br>Pay extra attention, carrying the unit by hand.<br>Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit  |                       |
|   | by hand. Use protective gloves in order to avoid injury by the aluminum fin. Make sure to dispose of the packaging material.   |                       |
|   | Leaving the materials may cause injury as metals like nail and woods are used in the package.<br>Do not operate the system without the air filter.   |                       |
|   | It may cause the breakdown of the system due to clogging of the heat exchanger. Do not touch any button with wet hands.  | 渕                     |
|   | It could cause electric shock.   | <u>N</u>              |
|   | Do not touch the refrigerant piping with bare hands when in operation.<br>The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbile.  | $\overline{\Diamond}$ |
|   | Do not clean up the air conditioner with water.<br>It could cause electric shock.  | $\bigcirc$            |
|   | Do not turn off the power source immediately after stopping the operation.<br>Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.  | $\bigcirc$            |
| _ | Do not control the operation with the circuit breaker.   |                       |





Caution

Work procedure

## **6**Refrigerant pipe


#### Caution


- Use the new refrigerant pipe
- When re-using the existing pipe system for R22 or R407C, pay attention to the following items Change the flare nuts with the attached ones (JIS category 2), and reprocess the flare parts Do not use thin-walled pipes.
- Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H3300) for refrigeration pipe installation In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes
- •Do not use any refrigerant other than R410A. Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc
- Store the copper pipes indoor and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
- •Use special tools for R410 refrigerant.

# Work procedure

- 1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
- %Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
- Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
   Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit. When taking out the pipe to rear or top, install it together with the electric wire<sup>®</sup>, passing them through the attached cover.
  - Seal clearances with putty, etc. to shut off dust.
  - \*Bend the pipe with as big radius as possible and do not bend the pipe repeatedly. In addition, do not twist and crush the pipes.
- \*Do a flare connection as follows:
- Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. •When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw
- the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table below. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
- Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps. Make sure to insulate both gas pipes and liquid pipes completely.
- Incomplete insulation may cause dew condensation or water dropping
   Refrigerant is charged in the outdoor unit.

As for the additional refrigerant charge for the indoor unit and piping, refer to the installation nanual attached to the outdoor unit







a hose clamp supplied as an accessory. % Give a drain hose a gradient of 10mm as illustrated in the right drawing by laying it without leaving a slack.

1. Insert drain hose completely to the

base, and tighten the drain hose clamp ecurely. ( adhesive must not be used.)

\* When plumbing on the left side, move the

rubber plug and the cylindrical insulating materials by the pipe connecting hole on

the left side of the unit to the right side. A Beware of a possible outflow of water that may occur upon removal of a drain plug.

2. Fix the drain hose at the lowest point with

- Take head of electrical cables so that
- they may not run beneath the drain hose.  $\triangle$  A drain hose must be clamped down with a hose clamp.
- There is a possibility that drain water overflows. Connect VP-20(prepare on site) to drain hose. (adhesive must not be used.) % Use commercially available rigid PVC general pipe VP-20 for drain pipe.

Install the drain pipe according to the installation manual in order to drain properly. Imperfection in draining may cause flood indoors and wetting the household goods, etc.

 Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the
other harmful and inflammable gas is generated. Toxic gas would flow into the room and ti would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell. Connect the pipe securely to avoid water leakage from the joint.

Insulate the pipe properly to avoid condensation drop. Check if the water can flow out properly from both the drain outlet on the

Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly


from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance

indoor unit and the end of the drain pipe after installation.

- Do not to make the up-down bending and trap in the mid-way while assum-ing that the drain pipes is downhill. (more than 1/100)
- Never set up air vent. 5. Insulate the drain pipe.
- . Insulate the drain hose clamp with the heat insulation supplied as accessories. When the unit is installed in a humid place, consider precautions against dew condensation such as heat insulation for the drain pipe.

#### Drain test

- After installation of drain pipe, make sure that drain system work in good
- condition and no water leakage from joint and drain pan.
- Do drain test even if installation of heating season



## (6) Duct connected Low/Middle static pressure type (FDUM)

# PJG012D001

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to the electrical wiring work installation manual. For remote controller installation, refer to the installation manual attached to a remote controller. For wireless kit installation, refer to the installation manual attached to a wireless kit. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 165 to 172.

#### SAFETY PRECAUTIONS


- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, [<u>AWARNING</u>] and [<u>ACAUTION</u>]. [<u>AWARNING</u>]: Wrong installation would cause serious consequences such as injuries or death. [<u>ACAUTION</u>]: Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to norther your health and safety so strictly follow them by any means
- Both mentions the important items to protect your health and safety so strictly follow them by any means. The meanings of "Marks" used here are as shown on the right: So Never do it under any circumstances. Atter completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning no precision method with user's manual of this unit
- detaning, operation method and temperature setting method) with user's manual of this unit. Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

#### 

| Installation should be performed by the specialist. If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn     of the unit.  | 0                        |
|---|--------------------------|
| Install the system correctly according to these installation manuals.   | 0                        |
| Improper installation may cause explosion, injury, water leakage, electric shock, and fire.   |                          |
| Check the density refered by the fournula (accordance with ISO5149).<br>If the density exceeds the limit density, please consult the dealer and installate the ventilation system.  | 0                        |
|   | -                        |
| • Use the genuine accessories and the specified parts for installation.<br>If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.   | 0                        |
| • Ventilate the working area well in case the refrigerant leaks during installation.  |                          |
| If the refrigerant contacts the fire, toxic gas is produced.  | Ð                        |
| Install the unit in a location that can hold heavy weight.  | •                        |
| Improper installation may cause the unit to fall leading to accidents.  | 0                        |
| Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.  | -                        |
| Improper installation may cause the unit to fall leading to accidents.  | 0                        |
| • Do not mix air in to the cooling cycle on installation or removal of the air conditioner.   | $\overline{\frown}$      |
| If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.  | $\underline{\heartsuit}$ |
| Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.<br>Power source with insufficient capacity and improper work can cause electric shock and fire.   | 0                        |
| Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.  | 0                        |
| Loose connections or hold could result in abnormal heat generation or fire.   |                          |
| Our ange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property. Improper fitting may cause abnormal heat and fire.   | 0                        |
| Check for refrigerant gas leakage after installation is completed.  | 0                        |
| If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.   | U                        |
| Use the specified pipe, flare nut, and tools for R410A.   | 0                        |
| Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.   |                          |
| Tighten the flare nut according to the specified method by with torque wrench.  | A                        |
| If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.   |                          |
| Ob not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur. Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also  | $\bigcirc$               |
| cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.  |                          |
| • Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.<br>If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due<br>to abnormal high pressure in the system. | 0                        |
| • Stop the compressor before removing the pipe after shutting the service valve on pump down work.  |                          |
| If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit<br>and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.  | Ð                        |
| Only use prescribed optional parts. The installation must be carried out by the qualified installer.<br>If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.   | 0                        |
| • Do not repair by yourself. And consult with the dealer about repair.  | $\overline{\frown}$      |
| Improper repair may cause water leakage, electric shock or fire.  | $\underline{\heartsuit}$ |
| • Consult the dealer or a specialist about removal of the air conditioner.  | 0                        |
| Improper installation may cause water leakage, electric shock or fire.  |                          |
| • Turn off the power source during servicing or inspection work.  | 0                        |
| If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.  | -                        |
| Do not run the unit when the panel or protection guard are taken off.<br>Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get<br>burned, or electric shock.  | $\bigcirc$               |
| Shut off the power before electrical wiring work.   |                          |
| It could cause electric shock, unit failure and improper running.   | •                        |
|   |                          |

| -   | ▲ CAUTION  |                       |
|---|--|-----------------------|
|   | Perform earth wiring surely.   | -                     |
|   | Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could  | Ð                     |
|   | cause unit failure and electric shock or fire due to a short circuit. Earth leakage breaker must be installed.   |                       |
| -   | f the earth leakage breaker is not installed, it could cause electric shocks or fire.  | Ð                     |
|   | Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all   |                       |
|   | poles under over current.<br>Using the incorrect one could cause the system failure and fire.  | Ð                     |
|   | Do not use any materials other than a fuse of correct capacity where a fuse should be used.  |                       |
|   | Connecting the circuit by wire or copper wire could cause unit failure and fire.   | $\odot$               |
|   | Do not install the indoor unit near the location where there is possibility of flammable gas leakages.   | $\overline{\bigcirc}$ |
|   | If the gas leaks and gathers around the unit, it could cause fire.   | $\odot$               |
|   | Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such<br>as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.   |                       |
| ľ   | t could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.  | S                     |
|   | Secure a space for installation, inspection and maintenance specified in the manual.   |                       |
|   | insufficient space can result in accident such as personal injury due to falling from the installation place.  | -                     |
|   | Do not use the indoor unit at the place where water splashes such as laundry.<br>Indoor unit is not waterproof. It could cause electric shock and fire.  | $\bigcirc$            |
|   | Do not use the indoor unit for a special purpose such as food storage, cooling for precision   | $\frac{\circ}{\circ}$ |
| i   | instrument, preservation of animals, plants, and a work of art.  | $(\bigcirc)$          |
|   | t could cause the damage of the items.   | $\sim$                |
|   | Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.<br>Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication  | $\sim$                |
| e   | equipment might influence the air conditioner and cause a malfunction and breakdown. Or the air conditioner might  | $\odot$               |
|   | influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.  |                       |
|   | Do not install the remote controller at the direct sunlight.<br>t could cause breakdown or deformation of the remote controller.   | $\bigcirc$            |
|   | Do not install the indoor unit at the place listed below.  |                       |
|   | Places where flammable gas could leak.  Places where cosmetics or special sprays are frequently used.  | 5                     |
|   | Places where carbon fiber, metal powder or any powder is floated.     Place where the substances which affect the air conditioner are generated     Highly salted area such as beach.  | S                     |
|   | such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres. Heavy snow area  |                       |
|   | Places exposed to oil mist or steam directly. Places where the system is affected by<br>On vehicles and ships smoke from a chimney.  |                       |
|   | Places where machinery which generates high harmonics is used. • Altitude over 1000m   |                       |
|   | Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit   |                       |
|   | according to the installation manual for each model because each indoor unit has each limitation)<br>Locations with any obstacles which can prevent inlet and outlet air of the unit   | $\sim$                |
|   | Locations where vibration can be amplified due to insufficient strength of structure.  | ( )                   |
|   | Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the<br>infrared specification unit)  | $\sim$                |
|   | Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)  |                       |
|   | · Locations where drainage cannot run off safely.<br>It can affect performance or function and etc   |                       |
|   | To not put any valuables which will break down by getting wet under the air conditioner.   |                       |
|   | Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.  | $\odot$               |
| •   | Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.  | $\overline{\bigcirc}$ |
|   | t could cause the unit falling down and injury.  | $\odot$               |
|   | Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.   |                       |
|   | f sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water.<br>To avoid damaging, keep the indoor unit packed or cover the indoor unit.  |                       |
|   |  | 0                     |
|   | Install the drain pipe to drain the water surely according to the installation manual.   | 0                     |
| 1   | Install the drain pipe to drain the water surely according to the installation manual.<br>mproper connection of the drain pipe may cause dropping water into room and damaging user's belongings.  | 0                     |
| •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.   | -                     |
| • [   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to   | -                     |
| • I<br>1<br>1   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and safety.  | $\odot$               |
| 1 •<br>1<br>1<br>1  | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and safety.<br>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.<br>If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can   | $\odot$               |
| • I<br>נ<br>• E<br>נ  | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Towic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and safety.<br>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.<br>If the density of refigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can<br>accur, which can cause serious accidents.   | $\bigcirc$            |
| I ●<br>I<br>I<br>I<br>I<br>I<br>I<br>I  | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and stafey.<br>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.<br>If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can<br>corcur, which can cause serious accidents.   |                       |
| 1 •<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1 | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.<br>Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.<br>Towic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to<br>user's health and safety.<br>Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.<br>If the density of refigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can<br>accur, which can cause serious accidents.   | $\bigcirc$            |
| 1 •<br>1<br>1<br>1<br>1<br>1<br>0<br>1<br>1<br>0<br>1<br>1<br>0<br>1<br>1<br>0                | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.  |                       |
| 1 •<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1<br>1   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and CHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can cour, which can cause serious acidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.  |                       |
|   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would winto room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and stafty. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents. The density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigerant is as a not to condense water. Incomplete insulation outdud cause condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspects and small animals.   |                       |
| 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation could cause contensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to  |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would winto room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and stafty. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents. The density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigerant is as a not to condense water. Incomplete insulation outdud cause condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspects and small animals.   |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.  Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.  Toxic exhaust gas would winto room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.  Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.  The density or ferfigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents.  The density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents.  The density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents.  The density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents.  The density of refrigerant exceeds the limit of the event of refrigerant on the space for inspection and maintenance.  Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.  Incomplete insulation could cause condensation and it would wet celling, floor, and any other valuables.  Do not install the outdoor unit where is likely to be a nest for inspects and small animals.  Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to eary the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit   |                       |
| 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 • 1 •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can be complete installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Dreck if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspects and final minals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surrounding clean. Pay extra attention, carrying the unit by hand. Day attention is order to avoid injury by the aluminum fin.   |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can cour, which can cause serious acidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not Install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to we the surrounding clean. Pay extra attention, carrying the unit by hand. Early the unit with 2 people if it is heavier than 2006, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use proteeting gloves in order to avid liny by the aluminum fin. Make sure to dispose of the packaging material.  |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and CHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and stafely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Reset and small animals could couse into the electonic components and cause breakdown and fire. Instruct the user to keep the surrounding clean. Pay extra attention, carrying the unit by hand. Carry the unit which peope if it is heavier than 2004, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin. Make sure to Glospose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package.   |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can cour, which can cause serious acidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not Install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to we the surrounding clean. Pay extra attention, carrying the unit by hand. Early the unit with 2 people if it is heavier than 2006, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use proteeting gloves in order to avid liny by the aluminum fin. Make sure to dispose of the packaging material.  |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Ga Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can court, which can cause serious actionts. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not shall the outfoor unit where is likely to be a neet for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 popelie if it is heavier than 2006, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid nigury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not operate the system without the air filter. To any buttow with wet hands.  |                       |
| 1 0<br>1 0<br>1 1<br>1 0<br>1 1<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0                            | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and CHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and safely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can cour, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Early the unit with 2 people if it is heavier than 20(kg, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid liquity by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not ouch any button with wet hands. t could cause electric shock.  |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would how into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and safely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and th vould wet celling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 2004, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin. Makes sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not operate the system without the air filter. The wase the breakdown of the system due to doging of the heat exchanger. Do not couch any button with wet hands. Loudi cause leater is shock. Do not touch the refrigerant piping with bare hands when in operation.  |                       |
| 1 • • • • • • • • • • • • • • • • • • •   | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some polsoning or deficiency of oxygen) to user's heath and stafty. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can accur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigerant invold wet celling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not ouch any buttom with wet hands. to caude cause electric shock. Do not chuch the refrigerant opping with bare hands when in operation. The pipe during operation would become very hot or cld according to the operation. The pipe during operation model cause a burn frostbile.  |                       |
| 1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0                            | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Ga Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can court, which can cause serious actionts. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not shall the outfoor unit where is likely to be a neet for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 popile if it is heavier than 20(%. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid nigury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not operate the system without the air filter. They cause the breakdown of the system due to doging of the heat exchanger. Do not cleause electric shock. Do not cleause lectric shock. Do not cleause the breakdown of the system due to doging of the heat exchanger. Do not cleause lectric shock. Do not cleause the air signing with bare hands when in operati |                       |
| 1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0                            | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's heath and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can cour, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not shall the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to exe the surrounding clean. Pay extra attention, carrying the unit by hand. Ency the materials may cause injury as metals like nail and woods are used in the package. Do not tauch any button with wet hands. It could cause electric shock. Do not clean whole on the system due to clogging of the heat exchanger. Do not clean any button with wet hands. It could cause electric shock. Do not clean up the air conditioner with water. It could cause electric shock.   |                       |
| 1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0<br>1 0                            | Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Ga Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can court, which can cause serious actionts. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. Do not shall the outfoor unit where is likely to be a neet for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 popile if it is heavier than 20(%. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid nigury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not operate the system without the air filter. They cause the breakdown of the system due to doging of the heat exchanger. Do not cleause electric shock. Do not cleause lectric shock. Do not cleause the breakdown of the system due to doging of the heat exchanger. Do not cleause lectric shock. Do not cleause the air signing with bare hands when in operati |                       |

OThis model is middle static ducted type air conditioning unit. Therefore, do not use this model for direct blow type air conditioning unit.



#### 2 Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.

- · Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use
- a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- Areas where there is enough space to install and service.
  Areas where it can be drained properly. Areas where drain pipe descending slope can be
- taken.

   Areas where there is no obstruction of airflow on both air return orille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air.
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
   This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity
   condition and confirmed there is no problem. However, there is some risk of condensation
   drop if the air conditioner is operated under the severer condition than mentioned above.
   If there is a possibility to use it under such a condition, attach additional insulation of 10 to
   20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
   Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- · Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
   Areas where lighting device such as fluorescent light or incandescent light doesn't affect
- Areas where ignuing device such as nucleosent light or incandescent light doesn't arect the operation.
- (A beam from lighting device sometimes affects the infrared receiver for the wireless remote controller and the air conditioner might not work properly.)
- ② Check if the place where the air conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.


#### Space for installation and service

Make installation altitude over 2.5m.


#### (Indoor Unit)

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit




Notes (a) There must not be obstacle to draw out fan motor. (
 marked area)
(b) Install refrigerant pipe, drain pipe, and wiring so as not to cross





#### **③Preparation before installation**

- If suspension bolt becomes longer, do reinforcement of earthquake resistant. OFor grid ceiling
  - When the suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
- Oin case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.
- When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt. Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.





Pipe locations UNIT: mm






#### ④Installation of indoor unit








#### **8**Wiring-out position and wiring connection

- Electrical installation work must be performed according to the installation manual by an
  electrical installation service provider qualified by a power provider of the country, and be
  executed according to the technical standards and other regulations applicable to electrical
  installation in the country.
  - Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring work.
- 1. Remove a lid of the control box (2 screws).
- Hold each wiring inside the unit and fasten them to terminal block securely.
- Fix the wiring with clamps.
- Install the removed parts back to original place.



#### **9** External static pressure setting

You can set External Static Pressure (E.S.P.) by either method of MANUAL SETTING or AUTO-MATIC SETTING by remote controller.

Indoor unit will control fan-speed to keep rated air flow volume at each fan speed setting (Lo-Uhi)

#### 1. MANUAL SETTING

You can set required E.S.P. by wired remote controller that calculated with the set air flow rate and pressure loss of the duct connected.

Select No.1-10 (10Pa-100Pa) from following table according to calculation result.

| Setting No.                   | 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10  |
|-------------------------------|----|----|----|----|----|----|----|----|----|-----|
| External Static Pressure (Pa) | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 |

When you set No.11-19 by remote controller, unit will control fan-speed with setting of No.10 Factory default is at No.5.

How to set E.S.P by wired remote controller

1 Push "  $\blacklozenge$  " marked button(E.S.P button).

(2) Select indoor unit No. by using  $\clubsuit$  button.

③ Select setting No. by using ◆ button and set E.S.P. by ◯ button. See detailed procedure in technical manual.



# Caution

Notice

Be sure to set E.S.P. according to actual duct connected.

You can NOT set E.S.P by wireless remote controller.

Wrong settings causes excessive air flow volume or water drop blown out.

2. AUTOMATIC SETTING

Indoor unit will recognize E.S.P. by itself automatically and select appropriate fan speed No.1-10.

#### How to start automatic setting

- ①, ②Same setting as MANUAL SETTING.
- ③ Select [AUT] by using ⇐ button and press button .
- O After setting E.S.P. at "AUT", operate unit in FAN mode with certain fan speed (Lo-Uhi).

## (9) External static pressure setting (continued)

Indoor unit fan will run automatically and recognize E.S.P. by itself.

The operation for automatic E.S.P recognition will last about 6 minutes, and it will be stopped after recognition is completed.

Caution

- Be sure to execute AUTOMATIC SETTING by remote controller AFTER ducting work is completed. When duct specification is changed after AUTOMATIC SETTING, be sure to execute AUTOMATIC SETTING again after power resetting and turning on again.
- Be sure to execute AUTOMATIC SETTING before trial cooling operation.
- (See ELECTRICAL WIRING WORK INSTRUCTION about trial cooling operation) • Before AUTOMATIC SETTING, be sure to check that return air filter in duct is installed and damper is opened.
- Wrong procedure causes excessive air flow or water drop blown out.

#### Notice

- During operation for automatic recognition (the Auto Operation), fan rotates with certain speeds regardless of set fan speed by remote controller.
- When duct is set with low static pressure (around 10-50Pa), even if indoor unit operate with higher air flow volume than rated one, but it is not abnormal.
- When you changed operation mode or stop operation with ON/OFF button during Auto Operation, the Auto operation will be canceled.
- $\cdot$  In such case, be sure to execute AUTOMATIC SETTING again according to above procedure.


# **OCheck list after installation**

Check the following items after all installation work completed.


| Check if   | Expected trouble                        | Check |
|--|---|-------|
| The indoor and outdoor units are fixed securely?             | Falling, vibration, noise               |       |
| Inspection for leakage is done?                              | Insufficient capacity                   |       |
| Insulation work is properly done?                            | Water leakage                           |       |
| Water is drained properly?                                   | Water leakage                           |       |
| Supply voltage is same as mentioned in the model name plate? | PCB burnt out, not working at all       |       |
| No mis-wiring or mis-connection of piping?                   | PCB burnt out, not working at all       |       |
| Earth wiring is connected properly?                          | Electric shock                          |       |
| Cable size comply with specified size?                       | PCB burnt out, not working at all       |       |
| Any obstacle blocks airflow on air inlet and outlet?         | Insufficient capacity                   |       |
| Is setting of E.S.P finished?                                | Excessive air flow, water drop blow out |       |

# (7) Replacement procedure of the fan unit (For FDUM model)

- Notes(1) The unit is a heavy item. It must be supported securely and handled with care not to drop when it is necessary toreplace. (2) For the maintenance space, to page 204.
- (a) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) in the figure.



(b) Take out the fan unit in the arrow direction.



# 6 TABLE OF FUNCTIONS CONNECTED WIRED REMOTE CONTROLLERS (RC-E4, E5)

If wired remote controller (optional part) is connected to the following indoor units, some of the functions cannot be used. Please see following table for details.

- Wall mounted type : SRK \* \* ZJX-S1,ZJX-S,ZJR-S,ZJ-S,ZK-S
- Floor standing type : SRF\*\*ZJX-S
- Ceiling concealed type : SRR \* \* ZJ-S


# O : OK, $\Delta$ : Conditionally OK, $\times$ : N/A

| NO. | Functions                                       | SRK | SRR | SRF | Outline of function  | Remarks   |
|-----|---|-----|-----|-----|--|---|
| 1   | Several remote controllers for 1unit            | 0   | 0   | 0   | Indoor unit can be connected max. 2 remote controllers.  |   |
| 2   | Control of several indoor units                 | 0   | 0   | 0   | One remote controller can be connected to a max. of 16 indoor unit.                                      |   |
| 3   | Plural Control                                  |     | ×   | ×   | One outdoor unit can be connected to a max. of 4indoor units.  | Only SRK50,60ZJX-S,S1   |
| 4   | Central control                                 | 0   | 0   | 0   | Signal of center mode from Center conslole can be restricted to operation of remote controller.          |   |
| 5   | Run/Stop  | 0   | 0   | 0   |  |   |
| 6   | Change operation mode                           | 0   | 0   | 0   | Display of operation mode range is automatically decided from the indoor unit's imformation.             |   |
| 7   | Adjust fan speed                                | 0   | 0   | 0   | Display of airflow range is automatically decided from the indoor unit's imformation.                    |   |
| 8   | Auto swing of flap                              | 0   | ×   | 0   | Display of airflow direction ON/OFF is automatically decided from the indoor unit's imformation.         | Flap control only. Louver cannot be controlled.   |
| 9   | Setting of air flow direction                   | ×   | ×   | ×   | Setting of air flow direction for indoor unit that can be changed airflow direction.                     |   |
| 10  | Setting of temperture                           | Δ   | Δ   | Δ   |  | Temperture range can be set from 18 degree to 30 degree. Carving $0.5^{\circ}$ C is rounded up. |
| 11  | Timer operation                                 | 0   | 0   | 0   | Sleep timer mode, Off timer mode, On timer mode,<br>Weekly timer mode.                                   | Worm up timer and sleep control of on timer mode is impossible.                                 |
| 12  | Grill auto mode                                 | ×   | ×   | ×   | Grill auto mode.   | RAC unit does not have this function.   |
| 13  | Setting of grill auto mode                      | ×   | ×   | ×   | Simple setting of grill auto mode.   | RAC unit does not have this function.   |
| 14  | Ventilation control                             | ×   | ×   | ×   | Air infiltration can be controlled by the indoor unit that has this function.                            | RAC unit does not have this function.   |
| 15  | Display of unit number                          | 0   | 0   | 0   | Display address number of remote control.  | Address setted by SC-BIK-N for RAC  |
| 16  | Service switch-1: Display of error data         | Δ   | Δ   | Δ   | Display and memorize the error code data that is checked finally.  | Only error code is used in the RAC unit.  |
| 17  | Service switch -2 display of operation data     | Δ   | Δ   | Δ   | Display operation data.  | RAC unit can be displayed some data.  |
| 18  | Trial run                                       | 0   | 0   | 0   | Cooling operation signal is sent to the indoor unit.   |   |
| 19  | Forced operation of drain pump                  | ×   | Δ   | ×   | Forced operation of drain pump is sent to the indoor unit.   | Option parts for SRR  |
| 20  | Setting of compressor frequency                 | 0   | 0   | 0   | Fixing compressor frequency.   |   |
| 21  | Quiet mode                                      | ×   | ×   | ×   | On timer in order to start quiet mode.   | RAC unit does not have this function.   |
| 22  | Auto address change from remote control         | ×   | ×   | ×   | Auto address can be changed from remote control.   | RAC unit does not have this function.   |
| 23  | Indoor unit's address set of master             | ×   | ×   | ×   | Adapt controller for 3 pipe system.  | RAC unit does not have this function.   |
| 24  | Filter reset                                    | ×   | ×   | ×   | Turning off signal display of filter sign and sending reset signal of operating time.                    | RAC unit does not have this function.   |
| 25  | Clear memory of error code in<br>remote control | 0   | 0   | 0   | Reset memory that remote controller has the error code.  |   |
| 26  | Clear memory of error code in the indoor unit   | 0   | 0   | 0   | Reset memory of error for the indoor unit.   |   |
| 27  | Clear address in indoor unit                    | ×   | ×   | ×   | Reset memory of address for the indoor unit.   | RAC unit does not have this function.   |
| 28  | Reset CPU                                       | 0   | 0   | 0   | Reset outdoor or indoor CPU.   |   |
| 29  | Function setting                                | Δ   | Δ   | Δ   | It is possible to set the function of remote control and indoor unit.                                    | RAC unit can be set a part of function.   |
| 30  | Setting of temperature range                    | Δ   | Δ   | Δ   | Set Max and Min temperature.   | For RAC models, only the range from $18^{\circ}$ C to $30^{\circ}$ C is available.              |
| 31  | External input                                  | 0   | 0   | 0   | External input from CNT terminal can be switched between all unit operation and individual operation.    |   |
| 32  | Auto adjustment of static pressure              | ×   | ×   | ×   | Change auto adjustment of static pressure.   | RAC unit does not have this function.   |
| 33  | Setting of static pressure                      | ×   | ×   | ×   | Displayed part blinks on and off when it recives a signal about auto adjustment of static pressure mode. | RAC unit does not have this function.   |
| 34  | Filter sign                                     | ×   | ×   | ×   | Displays filter sign via signal from indoor unit when counting time achieves target time.                | RAC unit does not have this function.   |

| NO. | Functions   | SRK | SRR | SRF | Outline of function   | Remarks   |
|-----|---|-----|-----|-----|---|---|
| 35  | Preparation of display of heating opration                | 0   | 0   | 0   | Display of preparative heating opration from indoor unit.   | Starting time of heating, thermo operation                                |
| 36  | Display of defrost operation                              | 0   | 0   | 0   | Display of defrost operation from indoor unit.  | Defrost operation   |
| 37  | Display of compressor protection operation                | ×   | ×   | ×   | Display of compressor protection operation from outdoor<br>unit during compressor soft starting.                            | RAC unit does not have this function.                                     |
| 38  | Missmatch operation mode                                  | ×   | ×   | ×   | Display it when Cooling only outdoor unit is received signal of heating operation.  | RAC unit does not have this function.<br>(RAC unit operates by fan mode.) |
| 39  | Periodic check  | ×   | ×   | ×   | Displays when Periodic check signal is received.  | RAC unit does not have this function.                                     |
| 40  | Display of check  | 0   | 0   | 0   | Display of checking in case of signal of error code address from remote control.  | RAC unit does not have this function.                                     |
| 41  | Display of auto cleaning operation                        | ×   | ×   | ×   | Displays it when it is received auto cleaning singnal from indoor unit.   | RAC unit does not have this function.                                     |
| 42  | Display of room temperature                               | 0   | 0   | 0   | Display room temperature.   |   |
| 43  | Display of demand control operation                       | ×   | ×   | ×   | Display of demand operation from indoor unit.   | RAC unit does not have this function.                                     |
| 44  | Display of operation on auto<br>adjusting static pressure | ×   | ×   | ×   | Display checking when it receives signal of auto adjusting static pressure operation.                                       | RAC unit does not have this function.                                     |
| 45  | External static pressure setting                          | ×   | ×   | ×   | It is available to select manual setting or automatic setting<br>for setting external static pressure by remote controller. | RAC unit does not have this function.                                     |


# 7 COMPONENT REPLACEMENT


# 7.1 Models SCM71ZJ-S1, 80ZJ-S1





# Fan and fan motor (FMo1)

- 7. Detach the clamps.
- 8. Pull out the cable.
- 9. Loose 4 nuts.
- 10. Remove the fan motor (FMo1).









# Compressor (CM)

- 10. Loosen a nut and remove the terminal cover.
- 11. Disconnect the faston connectors from compressor. U: Pink cable V: White cable W : Gray cable
- Note : Be sure to do above work after elapsing 3 minutes from power OFF.

12. Disconnect the pipes for suction and discharge by brazing. (It is available to cut suction and discharger pipes to remove the compressor)

Caution


When brazing, do not forget to disconnect suction pipe temperature sensor (Tho-S)


temperature sensor (Tho-D)


the heat during brazing.


and discharge pipe

from sockets.











#### Sub PCB (Lower layer)

- 1.After removing the Main PCB, disconnect all connectors on Sub PCB.
  - ①Disconnect the connector of CNEEV1. (for EEV1 & EEV2)
  - ②Disconnect the connector of CNEEV2. (for EEV3 & EEV4)
  - ③Disconnect the connector of CNTH. (for suction pipe temp.)
  - ④Disconnect the connector of CNMAIN. (Going to Main PCB)
  - ⑤Disconnect the connector of CNHEAT. (for crankcase heater)
  - ⑥Disconnect the connector of CN20S. (for 4-way valve)
- ⑦Disconnect the connector of CN20V. (Going to Main PCB)
- ⑧Disconnect the connectors of CNA, CNB, CNC and CND.
- 2.Loosen screws and disconnect the grounding cables.
- 3.Disconnect the fasten connector of the black cable.
- Note : Be sure to do above work after elapsing 3 minutes from power OFF.
- 4.Loosen a screw and pull up the right side of the upper TB to unlatch from the left side square hole.
- 5. Loosen the screw of N-terminal and disconnect the white cable.






### **EEV coils**

1. Remove the faulty EEV coil and disconnect the connector.


#### Note:

- When disconnecting the connector, be sure to check the color marked on the top of coil and the color of the connector.
- 2) When replace to a new coil, be sure to insert the socket attached to the coil to the pipe correctly.





# 4-way valve coil

- 1. Disconnect the connector.
- 2. Loosen a screw and remove the coil.



# 7.2 Models SCM100ZJ-S1, 125ZJ-S1







## Compressor (CM)


1. Loosen screws and remove the service panel and top panel.


- 2. Loosen screws and remove the cover and the terminal cover.
- 3. Loosen screws and disconnect all cables locally installed.

Caution Be sure to do above work after turning the power OFF by breaker.













#### Compressor (CM) [Front view] [Rear view] Crankcase heater 13. Loosen 3 nuts of compressor fixing bolts. 14. Remove the crankcase ۲ heater. Nut of compressor Nut of compressor fixing bolts fixing bolts [Side view] 15. Disconnect the pipes for Discharge pipe suction and discharge by brazing. Suction pipe (It is available to cut suction and discharger pipes to remove the compressor) Discharge pipe Suction pipe 16. Remove the compressor. 17. Replace to new compressor. Note: Before placing the new compressor, be sure Positions to be to mount the crankcase disconnected heater onto the new compressor properly. [Top view]








| Sub PCB (PWB4) on the  | 1st layer                         |   |
|--|-----------------------------------|---|
| 1. Disconnect all connectors from Sub PCB.                                   | [Before disconnecting connectors] | [After disconnecting connectors]  |
| Note: Be sure to do this work<br>after elapsing 3 minutes<br>from power OFF. | PK<br>OR<br>YE<br>BL<br>BR<br>RD  | CNEEV2<br>CNEEV3<br>CNEEV1<br>CNS2<br>CNX2<br>CNEEV1<br>CNS2<br>CNX2<br>CNB<br>CNS2<br>CNS2<br>CNS2<br>CNS2<br>CNS2<br>CNS2<br>CNS2<br>CNS2 |




#### Inverter PCB (PWB2) on the 2nd layer


- 1. Dismount the 1st layer according to the procedure for control PCB (PWB1) and Sub PCB (PWB4).
- 2. Loosen 3 screws and disconnect the cables for compressor.
- Note: Be sure to do this work after elapsing 3 minutes from power OFF.
- 3. Loosen 6 screws and disconnect the cables of P1, P2, P3 and N1, N2, N3.
- 4. Disconnect 3 connectors of CNI2, CNI4 and CNACT1.
- 5. Loosen 2 screws for fixing IPM and radiation fin.
- 6. Pinch the head of locking supports (8 pieces) and remove the Inverter PCB (PWB2).



#### Noise filter PCB (PCB3 & PCB5) on the back side of the 1st layer


Layout






## Noise filter PCB (PWB5) on the back side upper of the 1st layer

- 1. Dismount the 1st layer according to the procedure for control PCB (PWB1) and Sub PCB (PWB4).
- 2. Loosen 5 screws and disconnect the cables of TB3 TB7.
- Pinch the head of locking supports (4 pieces) and remove the N/F PCB (PWB5).
- Note: Be sure to do this work after elapsing 3 minutes from power OFF.






## **EEV** coils


1. Remove the faulty EEV coil and disconnect the connector.


#### Note:

- 1) When disconnecting the connector, be sure to check the color marked on the top of coil and the color of the connector.
- When replace to a new coil, be sure to insert the socket attached to the coil to the pipe correctly.




# 8 CHECKING PROCEDURE






#### <Sensor>



Suction pipe temp. sensor (Tho-S)


> Outdoor air temp. sensor-(Tho-A)


Discharge pipe temp. sensor (Tho-D)




Heat exchanger sensor (Tho-R)


| Name  | Color | Resistance(k Ω) |      |  |
|-------|-------|-----------------|------|--|
|       |       | 25°C            | 90°C |  |
| Tho-R | Black | 5.0             |      |  |
| Tho-A | Black | 5.0             |      |  |
| Tho-D | Black |                 | 4.6  |  |
| Tho-S | Black | 5.0             |      |  |









# 8.2 Models SCM100ZJ-S1, 125ZJ-S1









| CNI3   | CNI4 on PCB2          | 1-3 DC18V  |                                  |
|--------|-----------------------|------------|----------------------------------|
|        |                       | 2-3 DC15V  |                                  |
| CNA1   | Power transistor      | 280VDC     |                                  |
| CNW    |                       | 220-240VAC | PCB3 (N/F PCB)                   |
| CNN1   | 20S                   | 220-240VAC | for solenoid coil of 4 way valve |
| CNR1   | Crankcase heater      | 220-240VAC |                                  |
| CNA2   |                       | 280VDC     | green->P, white->N               |
| CNFAN1 | fan motor             |            | Refer to page 240                |
|        |                       | 1-2 5VDC   |                                  |
| CNI1   | CNI2 on PCB2          | 1-3 0-5VDC |                                  |
|        |                       | 1-4 0-5VDC |                                  |
| CNS1   | CNS2 on SUB PCB       | 13VDC      |                                  |
| CNL1   | High preassure sensor |            |                                  |
| CNP1   | Thermistor            |            | Tho-P                            |
| CNTH   | Thermistor            |            | Tho-R,Tho-D,Tho-S,Tho-A          |
| CNEEV1 | EEVH1                 |            |                                  |
| CNE    | For RAM checker       |            | For RAM checker                  |
| CNV    | For Mente PC          |            | For Mente PC                     |


%used only at our factory



#### <SUB PCB: PCB3>



| Connector | Connected to             | Normal value | Remark |
|-----------|--------------------------|--------------|--------|
| TB3       | TB5 on PCB5,L_IN on PCB4 | 220-240VAC   |        |
| TB4       | TB6 on PCB5,N_IN on PCB4 | 220-240VAC   |        |
| TB5       | Diode Module             | 220-240VAC   |        |
| TB6       | Diode Module             | 220-240VAC   |        |
| TB7       | Earth on control box     |              |        |



## INVERTER MULTI-SPLIT SYSTEM RESIDENTIAL AIR CONDITIONERS



Air-Conditioning & Refrigeration Systems Headquarters 16-5, Konan 2-chome, Minato-ku, Tokyo, 108-8215 Japan http://www.mhi.co.jp

Because of our policy of continuous improvement, we reserve the right to make changes in all specifications without notice. © Copyright MITSUBISHI HEAVY INDUSTRIES, LTD.